

TABLE OF CONTENTS

USERS MANUAL P/N 23190
4064XP-22; RZ TH1 ODRA
ATB on left side.

SECTION I GENERAL OPERATION, INSPECTION, AND MAINTENANCE

CRANE SAFETY RULES	F1122-B	1-1
INTRODUCTION	F1111-D	1-3
OPERATING RESTRICTIONS	F1112-E	1-4
OPERATING PRACTICES	F1112-E	1-4
INSPECTION AND MAINTENANCE	F1113-C	1-7
MONTHLY INSPECTION REPORT	F1123-B	1-9

SECTION II CRANE SYSTEMS AND TROUBLESHOOTING

OMNEX FM CONTROL SYSTEM	F1193-A	2-1
SAFETY SYSTEM	F1115-F	2-3
PROPORTIONAL HYDRAULIC SYSTEM	F1299-A	2-4
BASIC TROUBLESHOOTING CHART	F1117-E	2-6
TROUBLESHOOTING SAFETY SYSTEM	F1254-A	2-7
TROUBLESHOOTING PROPORTIONAL SYSTEM	F1303-A	2-8

SECTION III CRANE SPECIFICATIONS

LIFTING CAPACITIES	F1301-B	3-1
POWER FUNCTIONS AND SPEEDS	F1301-B	3-1
BOLT AND LUBRICATION SPECS	F1301-B	3-2
CRANE LUBRICATION POINTS	F1301-B	3-3

SECTION IV PARTS

BOX PARTS LIST	F1595-0	4-1
CRANE ASSEMBLY	DWG.58349-B	4-2
OMNEX FM CONTROL	DWG.50673-A	4-3
OMNEX FM ENGINE CONTROL RECEIVER (OPT.)	DWG.50674-A	4-4
TRAVEL BLOCK ASSEMBLY	DWG.22516-E	4-5
ANTI-TWO BLOCK ASSEMBLY	DWG.22908-A	4-6
BOOM-BODY ASSEMBLY	DWG.23056-0	4-7
ELEVATION CYLINDER ASSEMBLY	DWG.21521-C	4-8
BODY ASSEMBLY	DWG.23045-0	4-9
MANIFOLD ASSEMBLY	DWG.22245-A	4-10
MANIFOLD ASSEMBLY PART II	DWG.50667-0	4-11
BASE-HOUSING ASSEMBLY	DWG.23044-0	4-12
ROTATION SPEED REDUCER	DWG.21605-0	4-13
HYDRAULIC SWIVEL	DWG.23192-0	4-14



TABLE OF CONTENTS

USERS MANUAL P/N 23190
4064XP-22; RZ TH1 ODRA
ATB on left side.

BOOM ASSEMBLY – 22 FT.....	DWG.23055-0.....	4-15
BOOM OUTER ASSEMBLY – 22 FT.....	DWG.23052-0.....	4-16
BOOM INNER ASSEMBLY – 22 FT.....	DWG.23054-0.....	4-17
WINCH	DWG.22913-A	4-18
WINCH BRAKE.....	DWG.50594-0.....	4-19
ELECTRICAL SCHEMATIC	DWG.50672-A	4-20
HYDRAULIC SCHEMATIC.....	DWG.50613-0.....	4-21
DECAL DIAGRAM.....	DWG.58334-0.....	4-22

OMNEX MANUAL IS SEPARATE.

WARRANTY F1442-A



F1596-B
11/12/09

HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmoore.com

CRANE SAFETY RULES

CAUTION!

1. READ AND UNDERSTAND OPERATOR'S MANUAL.
2. INSPECT VEHICLE AND CRANE, INCLUDING ITS OPERATION, BEFORE DAILY USE.
3. USE THIS EQUIPMENT ONLY ON SOLID LEVEL GROUND WITH OUTRIGGERS OR JACKSTANDS PROPERLY SET.
4. BEFORE OPERATING THE CRANE REFER TO MAXIMUM LOAD CHART ON CRANE FOR OPERATING LOAD LIMITS.
5. BE SURE LOAD BEING LIFTED IS WITHIN SAFE WINCH CAPACITY AS WELL AS SAFE CRANE CAPACITY. MULTI-PART LINE OPERATION IS REQUIRED WHEN SINGLE LINE LOAD CAPACITY OF WINCH IS EXCEEDED.
6. DO NOT OPERATE, WALK, OR STAND UNDER THE BOOM OR ANY SUSPENDED LOAD.
7. ALWAYS PAY OUT LOAD LINE BEFORE EXTENDING BOOM. WIRE ROPE DAMAGE AND / OR BREAKAGE MAY OCCUR.
8. BOOM MUST BE IN ITS REST BEFORE MOVING VEHICLE.
9. BOOM TIP MUST BE DIRECTLY OVER THE LOAD BEFORE ANY LIFTING IS STARTED. DO NOT DRAG LOADS WITH THIS CRANE.
10. MAINTAIN THIS CRANE AS REQUIRED IN THE OWNER'S MANUAL.
11. DO NOT ALLOW PERSONNEL TO RIDE ON THE LOAD LINE, LOAD, OR BOOM OF THIS CRANE.
12. IT IS UNLAWFUL TO OPERATE THIS EQUIPMENT WITHIN TEN FEET OF HIGH VOLTAGE LINE



THIS PAGE INTENTIONALLY LEFT BLANK



F1122-B
05/12/08

HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmoore.com

INTRODUCTION

This crane is a powerful machine designed to lift and move heavy loads. There are many hazards associated with these operations. Liftmoore has designed this crane to be as safe as possible but -

IT IS THE OPERATOR'S RESPONSIBILITY TO PREVENT ACCIDENTS!

This takes pre-planning, attention, and knowledge of basic principles and rules. Even if you have used similar cranes, reading this manual in its entirety will help prevent damage, injury, or even loss of life; benefits well worth the short amount of time it takes to read these pages.

REGULATORY AUTHORITY

Use of this crane is governed by OSHA 29 CFR 1910.180 and may be governed by other federal, state, or local regulations.

IT IS THE OPERATOR'S RESPONSIBILITY TO UNDERSTAND AND COMPLY WITH ALL APPLICABLE REGULATIONS GOVERNING THE OPERATION, INSPECTION, AND MAINTENANCE OF THIS CRANE.

Personnel should be trained, tested, and certified, as recommended by OSHA and ANSI standards, before operating this crane.

USING THIS MANUAL

This manual assumes that the crane is mounted on a typical service body type or similar truck, which is powered by the vehicle electrical or hydraulic system, and is controlled by either the standard pendant control or FM radio control sold by Liftmoore, Inc.

This manual is supplied to provide basic guidelines for the safe use, routine maintenance, and general inspections of this crane.

Laws, regulations, standards, or policies may be more restrictive than this manual. If a conflict exists for any limit or condition, the safest or most prohibitive shall be used. Under no circumstances shall the load, moment, or stability ratings be exceeded.

Pay particular attention to the following:

WARNING! – Draws attention to hazards, conditions, or procedures that if not observed could result in injury or death.

CAUTION! – Draws attention to hazards, conditions, or procedures that if not observed could result in damage to the crane, load, or other equipment. Equipment failure could in turn lead to injury or death.

NOTE! – Draws attention to conditions or procedures that are essential to emphasize.

For questions, interpretations, or to report errors, please contact Liftmoore, Inc, Engineering Dept.



OPERATING PRACTICES

OPERATING RESTRICTIONS

DUTY CYCLE

For Electric Cranes the duty cycle time should be limited to 10%. This is limited by heat buildup in the motors and declining charge in the batteries. (Installing extra batteries near the crane helps keep the voltage at maximum.)

PERSONNEL

LIFTING OR MOVING OF PERSONNEL IS STRICTLY PROHIBITED! This crane was neither designed nor intended to lift personnel. Under no circumstances should anyone be allowed to ride on the crane, line, or load. All non-essential personnel must be kept away when using the crane. The load must never be moved over people, nor must anyone be allowed to pass or stand under a suspended load.

ELECTRICAL LINES

Consult ANSI B30.5 for operating procedures, minimum safe distances, and prohibited zones when working around electrical lines or poles.

When operating near electrical power lines, the crane must be positioned so that the distance from the crane to the lines or poles is equal to or greater than the length of the fully extended boom plus the minimum safe distance required.

All parts of the crane, line, and load must be kept a minimum safe distance from electrical power lines and poles. This distance is 10 feet for electrical lines carrying 50kV or less.

UNDER NO CIRCUMSTANCES SHOULD A CRANE BE OPERATED UNDER ELECTRICAL POWER LINES.

SETUP

POSITION The vehicle must be positioned so that the load is kept as close to the crane base as possible to reduce the moment on the crane. Consideration must be given to starting and ending position as well as firmness and slope of the ground and any obstructions.

OUTRIGGERS The outriggers or jackstands must be firmly set and the vehicle as level as possible. This will reduce the stresses on the rotation drive and keep the load off the vehicle's suspension. Keep in mind that the weight on the vehicle will shift as the crane and load is rotated.

MANUAL BOOM EXTENSION If the manual extension part of the boom is needed, it must be extended and the boom pin placed in the required position. Insert the pin and replace the pin's hairpin keeper before attempting to lift any load.

LOAD LIMIT The operator must understand the crane load chart. The operator must ensure that the load is within the load limits over the entire range which it will be moved. Be sure to include the weight of any lifting devices including the travel block.

The load limit chart is attached to the side of the crane to aid the operator.

The boom angle indicator and chart aids the operator in determining the load capacity at various boom angles and extensions. It also gives the load limit at that configuration.

STABILITY A stability chart must be posted near the crane. The operator must understand the stability chart. The crane may be de-rated over some areas of its operating radius.



TRAVEL BLOCK The operator must determine if the load is within the single line compatibility of the winch or if a multi-part line configuration is needed.

REEVING Ensure the proper routing of the rope through the sheaves and travel block. The rope must lie in the sheave groove and must not rub against any metal objects.

Ensure the rope is correctly wound on the winch drum. The crane assembly drawing will indicate if the rope must be wound over the top or bottom of the drum. The rope must never contact any part of the winch mounting.

WARNING!

If the winch winding direction is reversed the brake will not work and the load will fall.

ATTACHING THE LOAD

POSITION The boom tip must be moved over the load before lifting so that it will be lifted straight up.

CAUTION!

Never drag a load with the crane. Dragging a load puts very high stresses on the crane for which it was not designed.

ROPE Check the rope condition to ensure it is not frayed or damaged. Ensure that the rope is not kinked and that it does not contact any sharp edges or make any sharp bends.

If using double line configuration, ensure that the lines are not twisted.

CAUTION!

Never wrap the hoist rope around the load! Serious damage to the rope **WILL** occur.

HOOK Always make sure the load is applied to the throat of the hook. Never use a bent hook.

CAUTION!

Always lift with the throat of the hook. Never lift with the load applied to the tip of the hook. Doing so will bend the hook.

SLINGS If the load does not have a lifting eye, use a nylon, chain, or other type of sling designed for lifting and rated for loads greater than that being lifted.

BALANCE Ensure the load will be secure and balanced when lifted. Ensure that the load cannot shift in the sling and that the sling cannot slide across the hook should the load become unbalanced.

LIFTING THE LOAD

Before lifting, ensure that the load is free from all mountings and is no way attached or stuck to anything.

Ensure that at least five full wraps remain on the winch drum at all times.

Test the winch brake by lifting the load a few inches and ensuring that it does not slip.



HOLDING THE LOAD

The operator must keep the load in sight at all times once it is lifted.

The operator must never leave the controls once the load is lifted.

The operator must ensure that no one is allowed to pass or stand under a suspended load.

TRANSIT

While in transit, the crane must be stowed, preferably in a boom rest. The crane must be prevented from rotating and the hook prevented from swinging.

CAUTION!

Never move the vehicle with a suspended load. Doing so will put dynamic loads on the crane for which it was not designed.


MOVING THE LOAD

Before moving the load, make sure the path is free of any obstructions or people.

Avoid sudden accelerations or stops. Speeds must be kept to a minimum, especially rotation, to keep the load from swinging.

Avoid sudden reversing of direction. Do not reverse direction while the load is still moving.

Make sure that no part of the crane, boom, or load makes contact with any obstruction or comes within a minimum of ten feet from any electrical line.



INSPECTION AND MAINTENANCE

OSHA and ANSI require frequent and periodic inspections. Records of these inspections must be kept readily available. Liftmoore requires periodic maintenance to ensure proper operation and prolonged life of the crane.

INSPECTION

DAILY INSPECTION

OSHA 29CFR 1910.180 (d)(2)(i) requires the following be checked daily prior to use:

- All control mechanisms for maladjustment interfering with proper operation as well as for excessive wear of components and contamination by lubricants or other foreign matter.
- All safety devices for malfunction. This should include the anti-two block and pressure switch.
- Deterioration or leakage in air or hydraulic systems.
- Crane hooks with deformations or cracks. For hooks with cracks or having more than 15 percent in excess of normal throat opening or more than 10 deg. twist from the plane of the unbent hook.
- Electrical apparatus for malfunctioning, signs of excessive deterioration, dirt, and moisture accumulation. This should include the battery terminals, master disconnect switch, electrical swivel
- The wire rope shall be replaced if any of the following conditions are noted:
 - Kinking, crushing, bird-caging, or other damage

- Reductions from nominal diameter of more than one-sixty-fourth inch for diameters up to and including five-sixteenths inch, one-thirty-second inch for diameters three-eighths inch to and including one-half inch.
- Thimble is not in place or is damaged
- Any evidence of heat damage
- Six or more randomly distributed broken wires in 1 lay
- Three or more broken wires in 1 strand in 1 lay

MONTHLY INSPECTION

A thorough inspection of all ropes in use shall be made at least once a month and a certification record which includes the date of inspection, the signature of the person who performed the inspection and an identifier for the ropes shall be prepared and kept on file where readily available. All inspections shall be performed by an appointed or authorized person. Any deterioration, resulting in appreciable loss of original strength shall be carefully observed and determination made as to whether further use of the rope would constitute a safety hazard. Some of the conditions that could result in an appreciable loss of strength are the following:

- Reduction of rope diameter below nominal diameter due to loss of core support, internal or external corrosion, or wear of outside wires.
- A number of broken outside wires and the degree of distribution of concentration of such broken wires.
- Worn outside wires.



- Corroded or broken wires at end connections.
- Corroded, cracked, bent, worn, or improperly applied end connections.
- Severe kinking, crushing, cutting, or unstranding.

PERIODIC INSPECTION

An Annual Inspection Form is included in this manual. OSHA 29CFR 1910.180 (d)(2)ii requires periodic inspections of this crane. Liftmoore recommends an annual inspection using the included form.

MAINTENANCE PRECAUTIONS

Before any maintenance is performed, the vehicle should be out of the way and the crane secured.

WARNING!

Never perform any maintenance while the crane has any type of load on it. Use the manual operation procedure to lower the load if necessary.

WARNING!

Hydraulic cylinders may have high pressure stored in them even after hydraulic power is removed.

The counterbalance and pilot operated check valve in the cylinder will always hold some pressure in the cylinder. Slightly extending the cylinder then retracting a small amount will relieve most of the pressure in the cylinder. **DO NOT DEADHEAD THE CYLINDER!** This will store the maximum amount of pressure in the cylinder. Care should be taken when either valve is removed from the cylinder as some pressure will still remain.

After any maintenance has been performed the crane shall not be operated until all guards have been reinstalled, all safety devices reactivated, and maintenance equipment removed.

LUBRICATION Refer to the crane specification section for the periodic maintenance schedule and type of lubrication required.

BOLTS Bolts may loosen over time due to vibration; therefore they should be checked periodically. If bolts need to be replaced, make sure they are replaced with bolts of equal or greater strength. Check the periodic maintenance schedule (Crane Specification Section) for bolt specification and torque.

NOTE!

Sheave and boom and cylinder pivot bolts are not standard bolts. The shank and thread length of these bolts have been modified so that they do not pivot on the threads. Consult the parts section of this manual for part numbers of these bolts.

OTHER MAINTENANCE

Refer to parts drawings for any specific maintenance or adjustment procedures such as hydraulic winch brake, rotation drive gear set adjustment, ect.



MONTHLY INSPECTION REPORT

Crane Model No. _____ Serial Number _____

Are Boom Hitch Pins and Keepers in place?	Yes _____	No _____
Wire Line Hook with Safety Latch Working?	Yes _____	No _____
Is Hook OK, (Not bent)?	Yes _____	No _____
Is Thimble on Wire Rope OK?	Yes _____	No _____
Is Traveling Block in use?	Yes _____	No _____
Is Wire Rope OK, not kinked or frayed?	Yes _____	No _____
Are all Boom Sections straight?	Yes _____	No _____
Are Sheave Bolts in place and tight?	Yes _____	No _____
Do all Sheaves rotate easily?	Yes _____	No _____
Are Mounting Bolts tight?	Yes _____	No _____
Is Anti Two-Block functioning properly?	Yes _____	No _____
Is Boom Angle Indicator in place and functioning and is Chart legible?	Yes _____	No _____
Are Cylinder Mounting Bolts secure?	Yes _____	No _____
Are Winch Mounting Bolts tight?	Yes _____	No _____
When stopped does winch drift less than 1.0 Inches?	Yes _____	No _____
Is Load Chart in place and easily read?	Yes _____	No _____
Are functions on Pendant operating correctly?	Yes _____	No _____
Is Hydraulic Reservoir full?	Yes _____	No _____
Is Outrigger straight and functioning?	Yes _____	No _____

Any items checked 'No' must be repaired before using this crane.



THIS PAGE INTENTIONALLY LEFT BLANK



HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmoore.com

OMNEX FM CONTROL SYSTEM

(Refer to OMNEX Manual)

The OMNEX FM control system is a microprocessor-based radio/tethered remote control system. It allows the operator to control the crane using FM radio signals or the digital RS485 protocol when connected to the tether.

The system consists of a transmitter, crane receiver/control system, engine control radio receiver (optional), tether cable, and batteries.

RECEIVER (R160)

The crane receiver is a self-contained control system. It contains the FM receiver, limiting system, and proportional valve driver. It receives power and safety circuit inputs (Anti Two-Block and load sensor) from the crane. User inputs are received from the transmitter by FM radio signals or through the tether cable. Status LEDs are provided for user diagnostic. See the Omnex user manual insert for further details.

TRANSMITTER (T150)

The transmitter is a hand held unit which sends user input to the receiver by FM radio signals or by the tether cable. Its features consist of an on/off/emergency stop push button switch, double acting momentary contract switches for each function, a 5 pin connector for attaching the tether cable, low battery light, and a transmit light.

For a proportional control, a trigger is provided for speed control.

The transmitter is powered by 4 AA batteries or from the crane power source when attached to the tether cable. To conserve battery power the transmitter will turn itself off if idle for 10 minutes.

The red battery light will begin to flash when the power is getting low.

The transmit light will illuminate any time a user input is being transmitted.

REPLACEMENT OF COMPONENTS

Each transmitter is encoded with a digital ID that is programmed to its specific receiver. The receiver then only accepts signals from that transmitter so multiple cranes may be operated in the same vicinity without interference. If either component needs to be replaced, the receiver must be programmed to accept the new transmitter ID. See the Omnex manual insert.

OPERATION

The transmitter may be turned off using the Emergency Stop button, or will turn itself off if left idle.

Activation of any switch will turn on the transmitter, however as a safety feature, the **Emergency Stop must be pressed and released, or if already pressed, released within 10 seconds.**

Release the Emergency Stop by twisting the red cap. A green band will be visible under the red cap once it releases.

Turn on power to the crane and ensure the receiver is also receiving power.

Select a function and press the toggle switch in the desired direction as indicated on the label.

After the function switch is activated, SLOWLY squeeze the trigger to operate the function.

CAUTION!

If the trigger is pulled before a function switch is activated the crane will accelerate suddenly, causing the load to swing, and possibly fall or hit someone.



OPTIONAL ENGINE RECEIVER (R130)

This optional unit has toggle switches to control engine start and stop, engine idle advance and an auxiliary component.

(Please refer to the OMNEX manual for further information.)

TROUBLESHOOTING OMNEX REMOTE PROPORTIONAL VALVE DRIVER

The Omnex remote system has the proportional valve driver built into the R-160 receiver. Like most proportional valve drivers, including the standard one used by Liftmoore, it utilizes Pulse Width Modulation (PWM) to control the voltage signal and add dither. Unlike the standard Liftmoore valve driver, the Omnex driver monitors the amperage output rather than the voltage.

This amperage monitored output gives more precise and repeatable control since the resistance of the coil will change with temperature and other parameters. An important side effect of this is that **if the coil is disconnected then there is no signal output.**

The standard troubleshooting step of disconnecting the coil and measuring the output voltage will not work. **The voltage output must be measured with the coil connected.** This can easily be done at the DIN connector. If the connector is pulled back slightly, the terminals will be exposed enough to insert the test leads and still make contact with the connector.

If no functions work or if all functions are slow when controlled by the pendant, but work correctly when the manual operation button is pressed on the proportional valve then the problem is with the proportional control system.

CHECK VOLTAGE AT VALVE

Have the engine running to generate sufficient voltage (13-14V). Remove the manifold cover on the side of the crane. Connect a voltmeter between the two pins on the plug. As the trigger is pulled the voltage should start near zero, then jump to about 4.8V and increase steadily to at least 11.8V as the trigger is pulled.

If the voltages are not correct, see the Calibrating Proportional Control procedure in the Omnex manual insert.

CHECK RESISTANCE OF COIL

If the input voltages are correct, check the resistance across the coil. The DIN connector must be completely disconnected. It should be approximately 5.3Ω. If it is not, then replace the coil. If it is replace the valve.



SAFETY SYSTEM

The safety system is designed to help prevent damage to the crane that would be caused by overload or two-blocking. The system consists of a load sensor, anti-two block device (optional on smaller, electric cranes), and limiting system control board.

When the applicable switch detects an overload or two-block condition, the limiting system will prevent activation of winch up, boom down, and extend out since these directions would cause damage. Winch down, boom up, extend in, and power rotation will still function so that the crane can be moved to a safe configuration.

CAUTION!

Never de-activate or override safety functions. Doing so can result in serious damage to the crane and possibly injury or death.

LOAD SENSOR

A pressure activated switch in the elevation cylinder acts as a load sensor. This switch is normally closed and opens at the preset pressure corresponding to the load rating of the crane.

CAUTION!

The load sensor will not function when the elevation cylinder is fully retracted and is inaccurate when the boom is below horizontal.

CAUTION!

The operator must never rely strictly on the load sensor to determine overload conditions. The load and load limits must always be known and adhered to.

ANTI-TWO BLOCK

The anti-two block device (optional on smaller electric cranes), mounted on the boom crown plate, consists of a normally

open switch actuated by a lever. A weight is attached to the lever and holds the switch closed. If the weight is lifted by the hook or travel block the switch opens.

The power and signal wires are wired through the cord reel, which is in turn wired to the ATB switch.

LIMITING SYSTEM CONTROL

The limiting system control prevents output of winch up, boom down and extend out if it is not receiving a signal from either the ATB or load sensor.

The ATB does not trip boom down when winch is mounted on the boom.

There is a one second delay before deactivation of boom down when the load sensor is tripped to prevent false readings caused by pressure spikes.

MISCELLANEOUS

UP LIMIT SWITCH

The up limit switch prevents the elevation cylinder from reaching full extension. If the elevation cylinder were to "dead-head", the resulting pressure would activate the load sensor, preventing boom down. The boom would then have to be lowered using the manual operation buttons on the solenoid valves.

CIRCUIT BREAKER, FUSE

For electric cranes a 150 Amp circuit breaker is supplied with the crane. It should be installed as close to the battery as possible. For hydraulic cranes a 10 Amp blade type fuse is supplied.

DISCONNECT SWITCH

A power disconnect switch is supplied with the crane. Power to the crane should be turned off whenever not in use. This is to prevent inadvertent or unauthorized use and will help prevent corrosion at electrical connections.



HYDRAULIC SYSTEM

Sterling HYD Proportional

The hydraulic system consists of the hydraulic swivel, manifold with solenoid valves, and actuators (cylinders, motors). Hydraulic power is received from an external hydraulic source, typically a PTO driven pump attached to the vehicle transmission. The hydraulic manifold is plumbed in series and uses open center valves so that more than one function can be operated simultaneously.

SWIVEL

The hydraulic swivel is a two-port swivel that allows continuous, unlimited rotation. Refer to drawing for more information.

MANIFOLD

The hydraulic manifold contains the system relief valve, proportional flow control valve, and a directional control valve for each function.

The system relief valve prevents damage that would be caused by over pressurizing the system. It is a cartridge type valve located at the pump port of the manifold. Factory setting is 3000PSI.

The proportional valve is an electrically operated flow control valve. Regulated flow is directed to the manifold while excess flow is returned to tank. Before activation, all flow is returned directly to tank, minimizing heat build up. During operation the flow is regulated proportionally to the input voltage⁽¹⁾ allowing the operator to control the speed of the crane. The valve cracks at approximately 2V and allows approximately

7GPM at 6V. A screw on top of the valve is used to manually operate the valve.

(1) Technically, flow is directly proportional to amperage. Since the resistance is essentially constant, voltage is proportional to amperage. Within the accuracy required for this application, it can be said that the flow is directly proportional to the voltage.

Each hydraulically operated function is controlled by a 4 way, 3 position open center solenoid valve. It is electrically operated and spring biased to center. A manual operation feature is also incorporated.

CYLINDERS

Hydraulic cylinders are double acting cylinders with integrally mounted counterbalance valves. This valve performs 3 functions:

- Controls the rate of decent when lowering the load
- Keeps load from falling in the event of sudden loss of system pressure, such as when a hose bursts.
- Acts as a relief valve to prevent damage from induced load or thermal expansion.

It allows free flow to extend, then blocks flow until opened by pilot pressure to the retract port or when the relief pressure is reached.

Some cylinders utilize a pilot operated check valve on the retract port to prevent the cylinder from creeping out under no load conditions. This valve allows flow into, but prevents flow from the retract port, thus hydraulically locking the cylinder until opened by pilot pressure to the extend port.

MANUAL VALVE OPERATION

If electrical problems occur the proportional valve and function valves may be operated

manually. Refer to the manifold drawing for valve location and directions.

To operate the crane, both the function valve and the proportional valve must be opened. If only the proportional system is not



functioning, it will be easiest to manually set the proportional valve and operate the function with the pendant control. If the functions are not operating, it will be easiest to operate both the function valves and proportional valve manually.

To operate the function valves, pull the locking collar back to unlock it. The manual operation button may then be pushed or pulled depending on desired direction. The valve is spring bias to center so the function will stop when the manual operation button is released.

The proportional valve must also be opened for the crane to operate. It uses a screw type manual override that allows precise control of the speed. To set, operate a function valve, then turn knurled knob on the proportional valve counter-clockwise until the crane begins moving. Adjust until the desired speed is reached. When finished be sure to reset the valve by screwing the knob all the way in (clockwise).

CAUTION!

If the proportional valve is not reset the crane will operate without trigger input. This may result in unexpected motion of the crane, resulting in equipment damage or personal injury.

MANUAL LOWERING OF LOAD

WARNING!

The following procedure should be used in extreme cases only. Improper application of this procedure could result in injury or death.

WARNING!

The following procedure requires adjusting a safety valve. If the valve is not returned to the correct setting it may fail to hold a load, resulting in injury or death.

If hydraulic power is lost while a load is suspended, the load may be lowered by decreasing the setting on the counterbalance valve. This should only be done in extreme cases. The valve must be reset and tested before the crane is returned to normal use.

WARNING!

When the valve setting is decreased, the boom and cylinder may come down suddenly. Do not position yourself under the boom or position any part of your body between the cylinder and boom or between the cylinder and housing.

To decrease the setting, loosen the locknut on the valve, then **SLOWLY** turn the adjustment stem **CLOCKWISE** until the load begins to lower. Count the number of turns so that the valve can be immediately returned to its approximate setting.

Before the crane is returned to regular service, the valve must be precisely set and tested. Contact Liftmoore for exact setting and procedure information. The setting may be tested by lifting a known load near the moment rating.



BASIC TROUBLESHOOTING

The following chart gives a quick reference to help identify and correct problems. Refer to the following pages for more detailed information.

PROBLEM	PROBABLE CAUSE	CORRECTIVE ACTION
NO FUNCTIONS WORK	Not receiving electrical power Not receiving hydraulic power Control problem	Check all connections Check all fuses and circuit breakers Check for electrical power at first electrical connection and trace back to crane Check flow from pump Deadhead cylinder and check pressure at pump See control section
FUNCTION NOT WORKING Boom down, winch up, extension out not working Boom down, winch down, extension in not working Other function not working	No signal from ATB or Load sensor (switch tripped, bad switch, bad wiring or not receiving power) Relay card malfunction Not receiving enough pressure Faulty wiring Valve coils bad	Check input signal to relay board if no signal, trace back to switch Check LEDs on board for error codes and outputs Deadhead cylinder and check pressure at pump Check differential pressure valve for contamination Check relief valve for proper setting and possible contamination Check all wiring for breaks or shorts Check all ground wires for good connection Check coil resistance
ALL FUNCTIONS SLOW * These items only apply to cranes with proportional control systems.	Not receiving enough flow * Low battery voltage * Proportional valve problem * Control problem	Check fluid levels Check all filters and any other restrictions Check with engine running Charge battery Try manual operation of proportional valve Check voltage at valve for approx. at min and max(see troubleshooting form for specific valves) See control section



TROUBLESHOOTING SAFETY SYSTEM

DTCH Relay Card

To check functions controlled by the safety system check the status indicators. (See Relay Box Assembly drawing.) If only one of the safety functions is not working, activate that function and check for error codes and/or its output status indicator.

For non-FM systems, if the status indicator lights then the problem is in the wiring or in the solenoid coil. If the light does not illuminate, check the control pendant. If the control pendant is good then the crane control module needs to be replaced.

For FM systems, check for error codes. If none are present, see the FM Troubleshooting section.

If boom out, boom down and winch up are not working, confirm that the control board has power. Confirm that the board is receiving a signal from the ATB and load sensor.

If the error code is active, ensure that the crane is not overloaded and that the ATB lever is holding the switch closed. Check for voltage at the ATB and Load Sensor inputs.

CHECK LOAD SENSOR SWITCH

If the load sensor input is not receiving voltage, locate the load sensor connector inside the crane housing. The plug side will have a red wire and a gray wire, the receptacle side will have a red and a white wire.

Disconnect and check for continuity between the two pins on the receptacle (switch side). If there is no continuity then the load sensor is bad and needs to be replaced.

CHECK ATB SWITCH

If the ATB input is not receiving voltage remove the ATB housing cover and disconnect the connector. Check for continuity on the switch side. Lifting the weight should break the continuity. If either of these conditions is incorrect the switch is bad and needs to be replaced.

CHECK CORD REEL

Check the ATB switch if not done so already. Locate the ATB connector inside the crane housing. The plug side will have a red wire and a black wire. The receptacle side will have a white wire and a black wire.

Disconnect the plug going to the switch. Check for continuity between the two pins on the receptacle. Have someone lift the weight on the ATB and continuity should be broken. If either of these conditions are incorrect then the cord reel is bad and needs to be replaced.

CHECK POWER TO SAFETY SWITCHES

If the safety switch is good, check for voltage at pin 1 (the red wire) on the plug. If there is no voltage, follow the wire back to the 6-pin power distribution plug, checking for breaks or shorts.

Remove the power distribution receptacle (cap).

NOTE!

Removing the cap will disconnect power to all electrical components. Be sure to replace the cap before continuing.

Check the cap for bent pins. Check that all wires are fully seated in the plug. If they are not, then remove the green locking wedge and push the wires forward until seated. Reinstall the wedge ensuring that no wires are pushed back.



TROUBLESHOOTING THE WIRED PENDANT PROPORTIONAL SYSTEM

21398, HE Pendant, Sterling Prop Valve

If no functions work or if all functions are slow when controlled by the pendant, but work correctly when the proportional valve is operated manually, then the problem is with the proportional control system.

Proportional Valve Parameters

Cracking voltage	2.0V
Full open voltage	6.0V
Coil Resistance	5.1Ω

CHECK OUTPUT VOLTAGE TO VALVE

Have the engine running to generate sufficient voltage (13-14V). As the trigger is pulled the valve voltage should start near zero, jump to the valve cracking voltage after slight trigger travel, increase steadily as the trigger is pulled, reaching the full open voltage as the trigger nears its end of travel.

If the input voltages are correct, check the resistance across the coil. If the resistance differs significantly from the nominal resistance replace the coil. If the resistance is good replace the valve.

FOLLOWING FOR NON-FM ONLY!

See the FM Troubleshooting section for information.

Trigger Parameters

Input Voltage	4.5V
Signal Voltage	0.75–1.5V
Supply wire	RED
Signal wire	WHT
Ground wire	BLK

CHECK VALVE DRIVER BOARD

Remove the crane control module board from its enclosure. Ensure D3 is illuminated, indicating the board has power. If it is not, check the power and ground connections, correct as necessary.

Pull the trigger and check the proportional output LED and the error code LED. If Error Code 5 is not active and the proportional output LED does not light, then the driver card is malfunctioning and must be replaced. If the proportional output LED illuminates, then the valve driver needs to be calibrated.

CHECK TRIGGER

If Error Code 5 does not clear when the trigger is pulled the trigger must be checked. Since all connections must remain connected, the easiest place to measure is the back of the printed circuit board where pins attach to the board. Check Pin 5 for correct trigger supply voltage. Check Pin 8 for trigger signal voltage as the trigger is pulled.

If the board is receiving power (LED D3), but not supplying the trigger supply voltage, then it must be replaced. If the board is not receiving a trigger signal, check for power and ground at the trigger. Check for continuity between the trigger signal wire and Pin 8 at the board. Correct any if discrepancies found. If the trigger is receiving power and is grounded, but still not producing the correct trigger signal, then it must be repaired or replaced.

VALVE DRIVER CALIBRATION

If the trigger is functioning properly and the proportional valve is still not receiving proper voltage, then the valve driver needs to be calibrated

1. Remove the board from its enclosure
2. Pull the trigger slightly and adjust potentiometer R1 until the output is slightly below the valve cracking voltage.
3. Pull the trigger all the way and adjust potentiometer R2 to adjust the output to the full open voltage.

If the desired results cannot be achieved reset the potentiometers by turning each 21 turns CCW, then Turn R2 5 turn CW then repeat steps 2 and 3. Seal with fingernail polish when complete.



SECTION 3 CRANE SPECIFICATIONS

MODEL 4064 CRANES

MOMENT RATING 40 000 FT-LBS

MAX SINGLE LINE LOAD 3 200 LBS

MAX DOUBLE LINE LOAD 6 400 LBS

LIFTING CAPACITIES AT VARIOUS LOAD RADII

LOAD RADIUS (FT)	CAPACITY (LBS)
<6.25	6400
6	6667
8	5000
10	4000
12	3333
14	2857
16	2500
18	2222
20	2000
22	1818

POWERED FUNCTIONS AND EXPECTED TIMES

WINCH	UP: 3.3s	DOWN: 3.8s	1 REVOLUTION
BOOM ELEVATION	UP: 20s	DOWN: 20s	
BOOM EXTENSION	OUT: 41s	IN: 33s	
ROTATION	90° 15s		

HYDRAULIC REQUIREMENTS

PRESSURE	2750 PSI
FLOW	6 GPM

ELECTRICAL REQUIREMENTS

VOLTAGE	12 VDC
FUSE	15 AMP

NOTE: FUNCTION TIMES ARE BASED ON THESE INPUT VALUES




F1301-B
04/02/09

HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmoore.com

PERIODIC MAINTENANCE SCHEDULE		
MODEL 4064 CRANES		
BOLTS		
MOUNTING BOLTS	7/8-9 GRADE 8 TORQUE 600FT-LBS DRY	EVERY 4 MONTHS
BEARING BOLTS	5/8-11 GRADE 8 TORQUE 220FT-LBS DRY	EVERY 4 MONTHS
LUBRICATION		
GREASE FITTINGS	SEE DRAWING 50048	EVERY OTHER WEEK
HYDRAULIC FLUID	STANDARD Chevron AW Hydraulic Oil 46 or equivalent SAE 15 weight oil COLD WEATHER AW 32 or equivalent SAE 10 weight oil	CHECK DAILY, FILL AS NEEDED
WINCH GEARBOX	SAE 90, AGMA 5S	EVERY MONTH
ROTATION GEARBOX	EP 01 Grease	EVERY MONTH
BEARING (ZERK AND TEETH)	Oil Center Research PM 600 Military grease or equivalent Benton Based Grease NLGI Grade 2	EVERY 6 HOURS OF OPERATION
BOOM	Coat with "Slip Plate" made by Superior Graphite or similar solid lubricant coating	AS NEEDED



CRANE LUBRICATION POINTS



F1301-B
04/02/09

HOUSTON, TEXAS
 FAX: (800) 824-5559 (USA & Canada)
 FAX: (713) 688-6324
 PHONE: (713) 688-5533
 www.liftmoore.com

THIS PAGE INTENTIONALLY LEFT BLANK



F1301-B
04/02/09

HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmoore.com

LIST FOR BOX, CRANE PARTS 4064XP RZTH1

Items with * have detailed DWG's.


P/N 23191 - BOX, CRANE PARTS 4064XP-22 ODR
ROTZLER TH1; OMNEX FM DRA

- 1) P/N 23190 - MANUAL, CRANE 4064XP-22 ODRA..... 1pc
- 2) *P/N 22516 - BLOCK, TRAV ASSY 6.4K lbs/6.5D..... 1pc
- 3) P/N 19487 - CW, 10 GA X 300"..... 1pc
- 4) P/N 18457 - FUSE HOLDER, ATO 12GA SEALED..... 1pc
- 5) P/N 21154 - FUSE, 30 AMP BLADE..... 1pc
- 6) P/N 32613 - ADAPTER, 8MJ-10MJ..... 1pc
- 7) P/N 17012 - SWITCH, TOGGLE SPST MAINT. /S 1pc
- 8) P/N 17011 - BRACKET, SWITCH MNT. HYD. CRN..... 1pc
- 9) P/N 16781 - TERMINAL, RING 10-12 GA #8..... 2pcs
- 10) P/N 17013 - PLATE, ON-OFF FOR TOGGLE SWCH. 1pc
- 11) P/N 22431 - INSTALLATION INTS. 4064..... 1pc
- 12) P/N 18600 - PLATE, CRANE-TRUCK STABILITY CHART..... 1pc
- 13) P/N 22377 - DECAL, LOAD CAPACITY 40K 10-22..... 1pc



F1595-0
07/06/09

HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmoore.com



ITEMS WITH * HAVE DETAIL DRAWINGS

#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY
1	22386	SPACER, ELEV SWITCH MACH	1	18	21634	SCREW, HHC 0.50-13 X 8.50 PLT	2	35	33126	SCREW, MH RD 6-32 X 1.25	4
2	20851	SWITCH, LIMIT UP 2WNC-6 DTCH	1	19	30835	NUT, HEX NYLOC 0.50-13 GRADE 5	2	36	31124	WASHER, LOCK #6 GR2 PLATED	4
3	22392	SCREW, SOC HD 10-24 X 2.50 SS	2	20	34468	SCREW, SHEAVE SINGLE 1-8 3.25	2	37	31123	NUT, HEX 6-32 GR2 PLATED	4
4	33409	NUT, HEX NYLOC 10-24 GR2	2	21	30838	NUT, HEX NYLOC 1.00-8 GRADE 5	2	38	21274	BRACKET, CONTROL SOCKET 5P	1
5	23213	COVER, CONTROL SOCKET 4064 OMN	1	22	20541	SHEAVE ASSY 6.58PD X 0.37 ROPE	2	39	30809	SCREW, HHC 0.25-20 X 0.50 GR5	2
6	30989	SCREW, HWHSMS #8 X 0.50	4	23	22908	ATB ASSY, DEUTSCH CONNECTOR	1	40	30889	WASHER, LOCK 0.25 GR5 PLATED	2
7	22394	PENDULUM, LOAD RADIUS DIA. HD	2	24	32957	CLAMP, HOSE SUPPORT 0.62 ID	1	41	30809	SCREW, HHC 0.25-20 X 0.50 GR5	1
8	31017	SCREW, SHOULDER 0.31-18 X 0.75	2	25	32658	PIN, CLEVIS 0.87 X 3.50 PLATED	1	42	30889	WASHER, LOCK 0.25 GR5 PLATED	1
9	70012	BRACKET, CORD REEL	1	26	31948	CLIP, HAIRPIN 0.87 - 1.00	1	NOT SHOWN:			
10	30833	NUT, HEX NYLOC 0.25-20 GR2	2	27	22516	BLOCK, TRAV ASSY 6.4K lbs/6.5D	1				
11	31110	WASHER, FLAT 0.25 GR5 PLATED	2	28	22416	BOX, FM PARTS OMNEX XP	1	19847	CONNECTOR, DTCH 2P PLUG	1	
12	30457	SCREW, HHC 0.25-20 X 0.75 GR5	2	29	20842	BOX, FM PARTS OMNEX XP DRA	1	19845	CONNECTOR, DTCH 2P REPT	1	
13	33410	SCREW, MH RD 10-24 X 3.00	1	30	23264	SWITCH, PRES ASSY 2400PSI DTCH	1	19846	WEDGE, DEUTSCH 2P PLUG	1	
14	33409	NUT, HEX NYLOC 10-24 GR2	1	31	22391	SCREW, S.WALK 0.25-20 X 1.0 SS	1	19848	WEDGE, DEUTSCH 2P REPT	1	
15	20407	REEL, CORD 20 FT ASSY DTCH	1	32	22390	NUT, HEX JAM 0.25-20 SS	1	19916	CONNECTOR, DTCH 1P PLUG	1	
16	32384	ROPE, WIRE 0.37 X 95' W/THIMBLE	1	33	21198	PLATE, SERIAL 4064	1	21197	DECAL KIT 4064	1	
17	21631	ROLLER, ROPE 4064 NYLON	1	34	20740	EWH, DTCH HYD XP 4064 OMNEX FM	1				

Houston TX
(713)-688-5533
www.liftmoore.com

CRANE ASSY 4064XP-22 ODRA
WITH ATB ON LEFT SIDE; RZ TH1

DRWN BY: JC
DATE: 11/12/09

DRAWING NO.
58349-B





P/N 20831 CONTROL, FM TRANS OMNX XP DRA

P/N 20871 CONTROL, FM REC OMNX XP
(FOR CRANES WITH WINCH ON BOOM)

P/N 23155 CONTROL, FM REC OMNX XP
(FOR CRANES WITH WINCH ON BODY)

TRANSMITTER AND RECEIVERS ARE PROGRAMMED TO FORM A MATCHED SET SO THAT A TRANSMITTER ONLY OPERATES ONE CRANE. IF EITHER PART IS REPLACED, THE RECEIVER MUST BE PROGRAMMED TO ACCEPT THE NEW TRANSMITTER ID. SEE THE OMNEX MANUAL INSERT.



P1:12 PIN DEUTSCH DTM13-12PA

PIN#	DESCRIPTION	COLOR
1	NO CONNECTION	
2	NO CONNECTION	
3	GROUND	BRN
4	TRIGGER/PROP	WHT/BLK
5	NO CONNECTION	
6	POWER (9 TO 35 VDC)	RED
7	NO CONNECTION	
8	NO CONNECTION	
9	NO CONNECTION	
10	BOOM UP	GRN
11	NO CONNECTION	
12	BOOM DOWN	ORN

P2:12 PIN DEUTSCH DTM13-12PB

PIN#	DESCRIPTION	COLOR
1	HOIST DOWN OUTPUT	BLK
2	HOIST UP OUTPUT	BLU
3	EXTENSION OUT OUTPUT	GRN/BLK
4	EXTENSION IN OUTPUT	ORN/BLK
5	ROTATION CW OUTPUT	RED
6	ROTATION CCW OUTPUT	RED/BLK
7	CAN HIGH	WHT
8	CAN LOW	GRN
9	NO CONNECTION	
10	ATB SWITCH IN	YEL/BLK
11	PRESSURE SWITCH IN	BLU/BLK
12	NO CONNECTION	

LIFTMOORE
TRUCK CRANES

Houston TX
(713)-688-5533
www.liftmoore.com

DRN BY: JC
DATE: 04/27/09




OMNEX FM PROP DRA

DRAWING NO.

50673-A

P/N 20830 CONTROL, FM REC OMNX ENG/AUX

P/N 20933 EWH, DTCH ENGINE RCVR OMNEX FM



12P - A ENGINE CONTROL		
Pin Number	Wire Color	Function
3	Black	Ground
4	Red	Battery
6	Red/Black	E-Stop Input Power
7	Yellow/ Black	Compressor
8	Blue/Black	Engine High
9	Brown	Engine Start
10	Gray	Engine Stop
11	Green/Black	Output Power
12	—	E-Stop Output Power

SEE FORM 1214 FOR GENERAL INFORMATION ON INTERFACING WITH ECM AND CONTACT INFORMATION FOR VEHICLE AND ENGINE MANUFACTURES




Houston TX
(713)-688-5533
www.liftmoore.com

DRWN BY: KSP
DATE: 5/27/09

OMNEX FM ENGINE CONTROL
RECEIVER AND HARNESS

DRAWING NO.

50674-A




CAUTION:

NEVER USE A HOOK WHOSE THROAT OPENING HAS BEEN INCREASED, OR WHOSE TIP HAS BEEN BENT MORE THAN 10 DEGREES OUT OF PLANE FROM THE HOOK BODY, OR IS IN ANY WAY DISTORTED OR BENT.

	Houston TX (713)-688-5533 www.liftmoore.com	DRWN BY: JC DATE: 8/21/08	DRAWING NO. 22516-E
	BLOCK, TRAV ASSY 6.4K lbs/6.5D 6.58PD X 0.37 ROPE; 6400LBS		

NOTE: WIRE SHOULD BE SECURED TO SHEAVE BOLT TO ENSURE THAT IT DOES NOT INTERFERE WITH THE LEVER



30809 SCREW, HHC 0.25-20 X 0.50 GR5

22857 HOUSING, ATB STAMPING

33390 CONNECTOR, CGB 1/2-STRT 0.31

33405 LOCKNUT, CONNECTOR, CGB 0.50

33415 PIN, ROLL 0.25D X 0.75L - ZINC

20376 SWITCH, ATB LIMIT ASSY 2-WIRE NO

17164 SCREW, SOC HD 10-24 X 0.62 SS x 2

32639 WASHER, LOCK #10 GR2 PLATED x 2

33414 LEVER, ATB

33424 BUSHING 0.37ID X 0.50D X 0.50L

33374 WASHER, FLAT 0.37 SAE GR5 x 2

30834 NUT, HEX NYLOC 0.37-16 GR2

30833 NUT, HEX NYLOC 0.25-20 GR2

32481 WEIGHT ASSY, ATB
(INCLUDES CABLE AND EYE BOLT)

34216 PIN, CLEVIS 0.25 X 3.5
17974 PIN, COTTER 0.09 X 0.50 PLATED


NOT SHOWN:

22858 COVER, ATB

30989 SCREW, HWHSMS #8 X 0.50 (QTY 4)

22907 ATB BODY ASSY, 2 WIRE NO

Houston TX
(713)-688-5533
www.liftmoore.com




ATB ASSY, DEUTSCH CONN
TWO-WIRE NORMAL OPEN; LEFT SIDE

DRWN BY: JC
DATE: 07/02/09



DRAWING NO.

22908-A




ITEMS WITH * HAVE DETAIL DRAWINGS

	Houston TX (713)-688-5533 www.liftmoore.com	DRAWN BY: JC DATE: 3/17/09	BOOM-BODY ASSY 4064RZ ROTZLER TH1 WINCH	DRAWING NO. 23056-0
---	---	-------------------------------	--	-------------------------------



REPLACEMENT PARTS FOR CYLINDER	
DESCRIPTION	PART NUMBER
SEAL KIT	TM*SK-00271
COUNTER BALANCE VALVE	18577
P.O. CHECK VALVE PLUG	TM*PP00482
CYLINDER, 4.5 X 24.0 X 2.0 POC	18301




Houston TX
(713)-688-5533
www.liftmoore.com

DRWN BY: JC
DATE: 09/30/09

CYLINDER ASSY 4064XP ELEV DTCH
CYL 18301, 35.50" HOSE, DTCH LS

DRAWING NO.
21521-C



ITEMS WITH * HAVE DETAIL DRAWINGS


DRAWING NO.
23045-0

BODY ASSEMBLY 4064XP RZ
 W/ SLEWING RING (GEAR BEARING)

DRWN BY: JC
 DATE: 3/10/09

Houston TX
 (713)-688-5533
 www.liftmoore.com





DRAWING NO.
22245-A

MANIFOLD ASSY 4064 RZ
PRE-WIRE ASSY, EWH, FITTINGS

DRWN BY: JC
DATE: 10/14/08

Houston TX
(713)-688-5533
www.liftmoore.com



MANUAL OVERRIDES

PULL	FUNCTION	PUSH
DWN	HOIST	UP
OUT	EXTENSION	IN
UP	ELEVATION	DWN
CW	ROTATION	CCW

FUNCTIONS MANUAL OVERRIDES ARE SPRING LOADED TO CENTER. THE CRANE WILL STOP WHEN THE OVERRIDE IS RELEASED.

THE PROPORTIONAL VALVE SETTING IS NOT SPRING LOADED. THE MANUAL OVERRIDE MUST BE RETURNED TO THE CLOSED POSITION BEFORE RETURNING THE CRANE TO NORMAL OPERATION. IF THE VALVE IS LEFT OPEN, THE CRANE WILL OPERATE WITHOUT TRIGGER INPUT AND THE TRIGGER WILL HAVE NO AFFECT ON SPEED.

21189 MANIFOLD ASSY XP 4064 STERLING

COMPLETE MANIFOLD ASSY INCLUDING WIRING AND FITTINGS. INCLUDES TWO SUB-ASSEMBLIES:


21827 MANIFOLD ASSY XP 4064 PRE-WIRE MANIFOLD WITH 12P CONNECTORS

SUB-ASSEMBLY OF MANIFOLD (INCLUDING VALVES AND COILS) WITH 12 PIN CONNECTORS

21828 EWH, DTCH PWR & ATB SUB 4064 SUB HARNESS FOR MANIFOLD


SUB-ASSEMBLY INCLUDING POWER CONNECTOR, BUSS CONNECTOR, ATB AND LOAD SENSOR CONNECTOR

PROPORTIONAL VALVE MANUAL OVERRIDE
ADJUST TO DESIRED SPEED
CCW INCREASES SPEED



TO OPERATE MANUAL OVERRIDES:
FIRST PULL LOCKING COLLAR BACK TO UNLOCK
THEN OPERATE IN DESIRED DIRECTION

VALVES DO NOT INCLUDE COILS



SH*JP04C3150N VALVE, PROP CARTRIDGE 12V

SH*1001 VALVE, RELIEF 3000 PSI

SH*GS045850ND VALVE, SOLENOID 4W/3P OC 12V (x3)

SH*CAP012L COIL, 12V STERLING DIR & PROP (x9)

SH*GS045750ND VALVE, SOLENOID 4W/3P TC 12V (HOIST ONLY)






Houston TX
(713)-688-5533
www.liftmoore.com

DRWN BY: TV
DATE: 08/22/06

MANIFOLD ASSY 4064XP RZ
ROTZLER WINCH TH2

DRAWING NO.

50667-0



P/N 30867
SCREW, SOC HD 0.62-11 X 2.25
4 PLCS

P/N 31054
WASHER, FLAT 0.62 SAE GR8
12 PLCS

P/N 31100
SCREW, HHC 0.62-11 X 2.25 GR8
12 PLCS

P/N 19824
ZERK, 0.12 NPT STRAIGHT X 2.62

P/N 20046
ZERK, 0.25-28 90°

P/N 31224
COVER, ZERK 1/4

P/N 23037
ADAPTER, ELBOW MALE X FEMALE

*P/N 23192
SWIVEL, HYD/ELEC ASSY

P/N 21112
PLATE, BASE 4064 MACH

P/N 31505
SCREW, HHC 0.62-11 X 3.00 GR8
18 PLCS

P/N 31054
WASHER, FLAT 0.62 SAE GR8
18 PLCS

P/N 18266
PLATE, SWIVEL MOUNT SLIDE MACH

P/N 30890
WASHER, LOCK 0.31 GR5 PLATED
2 PLCS

P/N 32955
SCREW, SOC HD 0.31-18 X 1.75
2 PLCS

*P/N 21605
REDUCER, SPEED TULSA 14 TOOTH

P/N 31288
RING, ECCENTRIC

P/N 17473
O-RING, 155 Buna 70 DUROMETER

P/N 17472
O-RING, 158 Buna 70 DUROMETER

P/N 23038
HOUSING WELDMNT 4064 DTCH
BEARING, GEAR 4064

P/N GP*535-10117-1
ZERK, 0.12 NPT STRAIGHT

P/N 31224
COVER, ZERK 1/4

P/N 18714
CONNECTOR, CGB 0.25NPT 0.20

P/N 31713
SPACER, HYD SWIVEL SUPPORT
2 PLCS

P/N 32132
SCREW, HHC 0.37-16 X 6.00 GR8
2 PLCS

P/N 30473
WASHER, LOCK 0.37 GR5 PLATED
2 PLCS

P/N 30467
NUT, HEX 0.37 - 16 GR2 PLATED
4 PLCS

P/N 18263
PROTECTOR, SWIVEL SLOTTED WELD

P/N 30458
SCREW, HHC 0.31-18 X 0.75 GR5
3 PLCS

P/N 30890
WASHER, LOCK 0.31 GR5 PLATED
3 PLCS

P/N 21184
SPACER, SPEED REDUCER 4064
2 PLCS

P/N 19994
SCREW, HHC 0.43-14 X 2.25 GR8
4 PLCS

P/N 30872
WASHER, LOCK 0.43 GR5 PL
4 PLCS

P/N 31062
WASHER, FLAT 0.43 SAE GRADE 8
4 PLCS

P/N 19720
CONNECTOR
COVER, GEAR PINION 72100

P/N 30457
SCREW, HHC 0.25-20 X 0.75 GR5
3 PLCS

P/N 21185
COVER, GEAR 4064

P/N 30809
SCREW, HHC 0.25-20 X 0.50 GR5
7 PLCS

P/N 30889
WASHER, LOCK 0.25 GR5 PLATED
10 PLCS

ITEMS WITH * HAVE DETAIL DRAWINGS


LIFTMOORE
TRUCK GRANES

Houston TX
(713)-688-5533
www.liftmoore.com

DRWN BY: JC
DATE: 06/29/09

BASE-HOUSING ASSY 4064 RZ
W/ SLEWING RING (GEAR BEARING)

DRAWING NO.
23044-0



1. APPLY LOC-TITE TO THREADS OF SHAFT (ITEM 1) THEN TORQUE BEARING LOCKNUT (ITEM 8) TO 50 FT.-LBS. LOOSEN AND RETORQUE TO 20-30 FT.-LBS.
2. PAINT ALL EXTERIOR SURFACES EXCEPT GEAR, GEAR SHAFT, ECCENTRIC RING, AND HOUSING PILOT WITH TMI PRIME SPEC 709169 (WHITE PAINT).
3. SHIM AS NECESSARY TO ACHIEVE -.002 TO .000 WORM MOVEMENT AXIALLY. (USE SHIMS 42366, 42367, & 42368 TO ACHIEVE PROPER MOVEMENT).
4. FILL WITH E.P. 0 GREASE.

ITEMS WITH * HAVE DETAIL DRAWINGS

#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY
1	TW*43469	SHAFT, OUTPUT, HFG938D	1	8	TW*26528	LOCKNUT	1	15	TW*43745	WORM, SR, HFG945D	1
2	TW*41979	SEAL, OIL, HFG938D	1	9	TW*40518	KEY	2	16	TW*42366	SHIM, G1600D	2
3	TW*41983	CUP, BEARING, HFG93	2	10	TW*43492	HOUSING, HFG938D	1	17	TW*42367	SHIM, G1600D	2
4	TW*41982	CONE, BEARING, HFG9	2	11	19978	MOTOR, HYD 4.50 CID CHAR-LYNN	1	18	TW*42368	SHIM, G1600D	2
5	TW*40510	WASHER, THRUST	2	12	TW*33155	SEAL, OIL	1	19	TW*24180	SEAL, OIL	1
6	TW*42578	GEAR, SR, HFG945D	1	13	TW*996515	CONE, BEARING	2				
7	TW*41299	WASHER, LOCK	1	14	TW*996516	CUP, BEARING	2				




Houston, TX
(713)-688-5533
www.liftmoore.com

DRAWN BY: TV
DATE: 04/22/05

REDUCER, SPEED TULSA 14 TOOTH
15K IN-LBS, 14T PINON, BEARING

DRAWING NO.
21605-0



#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY
1	34256	NUT, HEX NYLOC 0.31-18 SS 304	1	10	23207	SWIVEL, HYDRAULIC ASSY .50 NPT	1	19	31451	INSULATOR, BOLT ELECTRIC	1
2	32278	WIRE, SWIVEL SUPPLY W/TERMINAL	1	11	31382	SPACER, SWIVEL STUD INSULATOR	1	20	31995	ADAPTER, 8FP-8MJ	3
3	34255	NUT, HEX 0.31-18 SS 304	1	12	31381	SPACER, SWIVEL UPPER - BRONZE	1	21	23063	SCREW, HHC 0.37-16 X 1.25 GR8	1
4	33353	WASHER, FLAT 0.31 SAE SS304	1	13	30674	BOOT, RUBBER 1 & 1/0	1	22	32368	WASHER, FLAT 0.37 SAE SS GR304	1
5	32277	STUD, 5/16-18 X 6 DOUBLE END	1	14	22238	ADAPTER, NIPPLE 4.50" LG #8	1	23	34256	NUT, HEX NYLOC 0.31-18 SS 304	1
6	32468	ADAPTER, 8FP-10MJ	1	15	32112	ADAPTER, NIPPLE 6.00" LG #8	1	24	32279	SLEEVE, SWIVEL SCREW INSULATOR	1
7	31383	SPACER, SWIVEL STUD INSULATOR	1	16	20500	WIRE, SWIVEL HOT PLATE ASSY D	1				
8	31996	ADAPTER, NIPPLE 2.50" LG #8	1	17	32562	WASHER, FLAT 0.50 SS GRADE 304	1				
9	32321	ADAPTER, NIPPLE 4.00" LG #8	1	18	31452	SPRING, SWIVEL	1				

LIFTMOORE
TRUCK CRANES

Houston, TX
(713)-688-5533
www.liftmoore.com


DRWN BY: JC

DATE: 07/13/09

SWIVEL, HYD/ELEC 4064 ASSY

MANUFACTURED @ LIFTMOORE

DRAWING NO.
23192-0



ITEMS WITH * HAVE DETAIL DRAWINGS


Houston TX
(713)-688-5533
www.liftmoore.com



DRWN BY: JC
DATE: 03/16/09

BOOM ASSEMBLY 4064 RZ
ROTZLER TH1 WINCH

DRAWING NO.
23055-0



DRAWING NO.

23052-0


BOOM, OUTER ASSY 4064 RZ
 ROTZLER WINCH TH1

DRWN BY: JC

DATE: 03/16/09

Houston TX
 (713)-688-5533
 www.liftmoore.com






REPLACEMENT PARTS FOR CYLINDER

DESCRIPTION	PART NUMBER
CHECK VALVE	31591
COUNTERBALANCE VALVE	30851
HOSE, HYD #6 21.00"	32961
ADAPTER, 45° 6MJ-6MO	31706
CYLINDER, 2.75 X 144.0 - 2CYLS	21556


LIFTMOORE TRUCK CRANES
 Houston TX
 (713)-688-5533
 www.liftmoore.com
 DRAWN BY: JC
 DATE: 3/16/09
 BOOM, INNER ASSY 4064X-22
 ROTZLER TH1 WINCH
 DRAWING NO.
 23054-0



ITEMS WITH * HAVE DETAIL DRAWINGS


#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY
1	RZ*M.TH2.CW.31	ASSEMBLY MOTOR TH1 CW	1	5	RZ*220-077	LABEL, NUMBER	1	9	RZ*220-067C	CABLE WEDGE, .44"	1
2	RZ*220-044	SEAL, O-RING, #2-163	1	6	RZ*220-065	LABEL, IDENTIFICATION	1	10	RZ*220-032	SCREW HEX HEAD CAP, M10-1.50x25	1
3	RZ*P.TH1.CW	ASSEMBLY, PRIMARY TH1.CW	1	7	RZ*210-062	SCREW, HEX HEAD CAP, M10-1.50x30	1	11	RZ*220-068	WASHER, M10, DIN 433, PLATED	1
4	RZ*220-079	LABEL, ROTATION, CW	1	8	RZ*220-068	WASHER, M10, DIN 433, PLATED	1	12	RZ*F.TH1	ASSEMBLY, FINAL, TH1	1

		Houston TX (713)-688-5533 www.liftmoore.com	DRAWN BY: PDS DATE: 12/19/08	WINCH, HYD. RZ TH1 .31.0.116 CCW DRUM ROTATION	DRAWING NO. 22913-A
--	--	---	---------------------------------	---	-------------------------------



ITEMS WITH * HAVE DETAIL DRAWINGS

#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY
1	C.TH1.CW	ASSEMBLY, CLUTCH, TH1-CW	1	7	RZ*220-015	BRAKE LOCATOR, TH2	1	13	RZ*220-016	SPRING, TH2	8
2	RZ*220-081	RETAINER, SPIROLOX #UR-162	1	8	RZ*220-038	BRAKE SEPARATOR, TH2	3	14	RZ*220-043	SEAL, O-RING, #2-357	1
3	RZ*220-035	SEAL, BRAKE SHAFT, TH2	1	9	RZ*220-039	BRAKE DISC, TH2	2	15	RZ*220-042	SEAL, BACKUP RING, #8-357	1
4	RZ*220-002	BASE, PRIMARY, TH2	1	10	RZ*220-040	SEAL, BACKUP RING, #8-356	1	16	RZ*220-047	SEAL, O-RING, #2-008	2
5	RZ*220-066	BEARING, SLEEVE, TH2	1	11	RZ*220-041	SEAL, O-RING, #2-356	1	17	RZ*220-048	SEAL, BACKUP RING, #8-008	2
6	RZ*220-058	SLEEVE, ROTARY SHAFT SEAL, TH2	1	12	RZ*220-011	BRAKE PISTON, TH2	1	18	RZ*220-045	BRAKE CONDUIT, TH2	1



Houston TX
(713)-688-5533
www.liftmoor.com

DRWN BY: TV
DATE: 02-14-05

DWG, WINCH BRAKE PARTS TH1
ROTZLER

DRAWING NO.
50594-A




BY: JC
DATE: 10/02/08

SCHEM, ELEC 4064XP OMNEX FM
DTCH


DOCUMENT NO.

50672-A

THIS SCHEMATIC IS USED FOR EWH 20740.



NOTE: PINS 1 - 9
CORRESPOND TO
VALVE COILS 1 - 9




Houston TX
 (713)-688-5533
 www.iftmoore.com

DRAWN BY: BLF
 DATE: 1/10/04

SCHEM, HYD 4064 WITH DP HOIST

DRAWING NO.

50613-0



#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY
1	15581	DECAL, LOGO LARGE	1	6	15579	DECAL, DANGER CABLES	1	11	32085	DECAL, LIFTING PERSONNEL	1
2	16102	DECAL, CAUTION READ MANUAL	1	7	15580	DECAL, LIFTMOORE - 3.00"	2	12	22375	DECAL, ANGLE PENDULUM LEFT	1
3	19756	DECAL, ATTENTION GREASE GEAR	1	8	15618	DECAL, DANGER ELECTRIC INJURY	1	13	22377	DECAL, LOAD CAPACITY 40K 10-22	1
4	22376	DECAL, ANGLE PENDULUM RIGHT	1	9	22817	DECAL, BLOCK & HOOK WT. 60 lbs.	1	14	21198	PLATE, SERIAL 4064	1
5	21203	DECAL, 4064 HORIZONTAL	2	10	21550	DECAL, TRAVEL BLOCK 6400 LBS	2	15	15615	DECAL, WARNING TRAVELING BLOCK	1



Houston TX
 (713)-688-5533
 www.liftmoore.com

DRWN BY: JC
 DATE: 3/17/09

DECAL DIAGRAM FOR THE 4064XP
 WITH ATB ON LEFT SIDE; RZ TH1

DRAWING NO.
58334-0

LIFTMOORE LIMITED WARRANTY

Parts and Structural

Liftmoore, Inc. warrants each LIFTMOORE crane to be free from defects in materials and workmanship for twelve (12) months from the date of delivery to the original customer. Under the terms of this warranty the crane structural components manufactured by LIFTMOORE, Inc. are warranted for thirty-six (36) months from the date of delivery to the original customer. LIFTMOORE, Inc. will repair or replace, as its sole discretion, any equipment or part that is returned f.o.b. to LIFTMOORE, Inc.'s plant at 7810 Pinemont Drive, Houston, Texas 77040, or to one of its authorized dealers, and is found by LIFTMOORE, Inc. or its authorized dealer to have been defective at the time of original delivery.

The foregoing warranty is the exclusive warranty made by LIFTMOORE, Inc. with respect to its cranes and is in lieu of all other warranties. ANY AND ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS OF ANY CRANE FOR A PARTICULAR PURPOSE OR OPERATION, ARE HERBY EXPRESSLY DISCLAIMED.

The foregoing warranty applies only to LIFTMOORE cranes under normal use and service and does not apply in the event of damage caused by repair or alteration or damage during shipment, accident, negligence, overloading, or misuse, including operator's failure to follow any of the instructions issued with the crane.

This warranty is limited to the original purchaser and is not assignable. In order to submit a claim, the original purchaser must provide a copy of the original invoice for the crane in question within twelve (12) months following the delivery date and within 30 days from the date of repair.

The warranty applies only when the LIFTMOORE crane is used for commercial purposes and does not cover any purchase for use for personal, family or household purposes.

LIMITATION OF LIABILITY: LIFTMOORE, Inc.'s liability for any losses or damages resulting from any cause whatsoever, including LIFTMOORE, Inc.'s NEGLIGENCE or from a defective crane irrespective of whether such defects are discoverable or latent, shall in no event exceed the purchase price of the crane to which losses or damages are claimed, or at the election of LIFTMOORE, Inc., the repair or replacement of the defective crane.

In no event shall LIFTMOORE, Inc. be liable for any special, incidental, or consequential damages, including commercial losses or costs of any kind sustained by purchaser or any other person or for any damages for which purchaser may be liable to other persons by reason of any defect in any LIFTMOORE crane or any part thereof.

LIFTMOORE, Inc. reserves the right to make changes in design or construction of its cranes at any time without obligating itself to make such changes on cranes previously manufactured.

No agent, employee, or representative of LIFTMOORE, Inc. has authority to amend or modify the foregoing warranty or to bind LIFTMOORE, Inc. by any other warranty, guaranty, or assumption of liability.

In the event any provision of this warranty is for any reason held ineffective, the remaining provisions shall remain in full force and effect.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other legal rights that vary from state to state.

