

TABLE OF CONTENTS

USERS MANUAL P/N 29705
72100DX-30 WP DTCH.
30 FT BOOMS

SECTION I

CRANE INSTALLATION INSTRUCTIONS

CRANE INSTALLATION INSTRUCTIONS	F1541-D	1-1
MOUNTING PATTERN.....	DWG.50542-D.....	1-3
ELECTRICAL INSTALLATION	DWG.50378-B	1-4
HYDRAULIC INSTALLATION.....	DWG.50026-B	1-5
ENGINE CONTROL RECEIVER INSTALLATION.....	F1214-D	1-6
STABILITY PROCEDURE.....	F691-I.....	1-7
STABILITY TEST RESULTS	F691-I.....	1-8

SECTION II

GENERAL OPERATION, INSPECTION, AND MAINTENANCE

CRANE SAFETY RULES.....	F1122-B.....	2-1
INTRODUCTION	F1111-D.....	2-3
OPERATING RESTRICTIONS	F1112-F	2-4
OPERATING PRACTICES	F1112-F	2-4
INSPECTION AND MAINTENANCE.....	F1113-E	2-7
MONTHLY INSPECTION REPORT	F1123-B.....	2-9
ANNUAL INSPECTION REPORT.....	F1507-0	2-10
STANDARD HAND SIGNALS FOR CRANE OPERATIONS ..	F2409-0	2-13

SECTION III

WIRELESS REMOTE-CONTROL SYSTEM

OPERATION MANUAL RADIO/CAN REMOTE WIFI	F2724-0	3-1
--	---------------	-----

SECTION IV

CRANE SYSTEMS AND TROUBLESHOOTING

SAFTEY SYSTEM.....	F1769-0	4-1
PROPORTIONAL HYDRAULIC SYSTEM.....	F1299-C	4-2
TROUBLESHOOTING PROPORTIONAL SYSTEMS	F1447-C	4-4
DEUSTCH CONNECTORS AND PINS.....	F2435-A	4-5

SECTION V

CRANE SPECIFICATIONS

LIFTING CAPACITIES	F1285-D	5-1
POWER FUNCTIONS AND SPEEDS.....	F1285-D	5-1
BOLT AND LUBRICATION SPECS	F1285-D	5-2
CRANE LUBRICATION POINTS.....	F1285-D	5-3



F2722-A
07/08/21

HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmoore.com

TABLE OF CONTENTS

USERS MANUAL P/N 29705
72100DX-30 WP DTCH.
30 FT BOOMS

SECTION VI PARTS

BOX PARTS LIST	F2723-0	6-1
CRANE ASSEMBLY & ELEC SCHEMATIC	DWG.29703-B	6-2
BOOM-BODY ASSEMBLY.....	DWG.29702-B.....	6-10
ELEVATION CYLINDER ASSEMBLY	DWG.19802-D.....	6-12
BODY ASSEMBLY	DWG.29701-B	6-13
MANIFOLD ASSEMBLY	DWG.29725-A	6-15
MANIFOLD PRE-ASSEMBLY	DWG.24993-C	6-16
BASE HOUSING ASSEMBLY	DWG.29700-B	6-17
HYDRAULIC SWIVEL	DWG.28145-0.....	6-21
BOOM ASSEMBLY – 30 FT.....	DWG.29699-A.....	6-22
BOOM OUTER ASSEMBLY – 30 FT	DWG.29698-B	6-24
BOOM INNER ASSEMBLY – 30 FT	DWG.29737-A.....	6-25
WINCH.....	DWG.29472-0.....	6-27
ROTATION SPEED REDUCER	DWG.29116-B	6-30
ELECTRICAL WIRING HARNESS.....	DWG.29515-0.....	6-32
HYDRAULIC SCHEMATIC	DWG.50940-0.....	6-35
TRAVEL BLOCK ASSY	DWG.29145-A.....	6-36
WARRANTY	F1442-A.....	



F2722-A
07/08/21

HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmoore.com

MODEL 72100/60100 INSTALLATION INSTRUCTIONS

Read and understand these instructions completely before starting the work.

Before installing make sure you have all necessary parts. Please refer to the Owner's manual Section 4-1 for the list of parts required for installation. Report any shortages to Liftmoore, Inc. immediately.

1. The mounting surface for the crane must be capable of supporting the rated moment and the maximum load of the crane listed below:

72100:	72,000 Ft.-Lbs.	10,000 Lbs.	10,000 Lbs. @ 7.2 Ft.
60100:	60,000 Ft.-Lbs.	10,000 Lbs.	10,000 Lbs. @ 6.0 Ft.

2. Layout the mounting holes for the crane as shown in the drawing No. 50542. Cut the center hole for the crane swivel as shown on this drawing. Mount the crane with four 1 1/4" bolts of at least Grade 8 quality.

3. A manual disconnect switch with mounting bracket and terminals is provided with the crane. This switch will act as the main power disconnect for the crane. Removing power from the crane during periods of non-use will help to increase the life of the crane's electrical components. The switch should be mounted as near as possible to the crane and in a position which will facilitate its use. Determine the appropriate mounting position for the switch and use the supplied terminals to splice in to the crane's main power cable. Drawing No. 50378 illustrates how to install the disconnect switch and fuse.

4. Install the 30 Amp fuse, which is supplied with the crane, near the battery on the positive line. This fuse is to protect the wiring in event of an accidental grounding. Use a section of the wire and the terminals supplied to connect between the battery and the circuit breaker. See drawing No. 50378.

5. Run the 10 Ga. battery cable along the inside of the chassis frame to the positive battery terminal and connect it to the battery through the in-line fuse. See that the cable is protected. Avoid sharp edges and heat sources such as the muffler or catalytic converter. Use loom for protection whenever the cable passes through the body. On continuous rotation models, use the terminal supplied and connect the cable to the bolt located between the pipe nipples in the center of the swivel under the crane. On limited rotation models connect the battery wire to the 10 gage black wire under the crane.

6. Be certain that the crane and the battery are grounded to the truck chassis. A good ground must exist for the crane to work. Ground wire supplied.

7. Hydraulic Component Installation: The following description applies to Liftmoore's Hydraulic Installation Drawing No. 50026.

These cranes require a pump driven by the vehicle's engine. Pumps can be either Power Take Off or Fan Belt drive. For best, smoothest operation the pump needs to supply 8 GPM at 3,000 PSI with the engine at 1,000 RPM.

Do not use pumps that will deliver more than 8 GPM at engine speed. 10 GPM is the maximum flow acceptable to the valves in the crane. If a larger pump is installed on the vehicle for other functions, use a pressure compensated flow control valve to restrict the flow to the crane as required above.

A wire control or solenoid throttle advance can be used to increase the engine speed. Liftmoore can supply a solenoid throttle advance kit (Part No. 32592) that includes a control switch to be mounted near the crane. On engines with electronic throttles, the solenoid throttle advance cannot be used, check with the dealer for throttle advance information. Engine speed, start and stop control can be included in the pendant control box if ordered.

A reservoir of at least 25 gallon capacity is recommended. Reservoir capacity will need to be enlarged for increased running time. For run times of 15 minutes or less the 25 gallon capacity is adequate. For longer duty cycles the reservoir size should be increased.



MODEL 72100/60100 INSTALLATION INSTRUCTIONS, Cont.

The reservoir should be equipped with a suction line strainer, return line diffuser, and filler/breather cap. A sight gage for displaying fluid level is also advisable. Locate the reservoir as close to the pump as possible and as high as possible above the pump.

A adjustable relief valve set @ 3,000 PSI should be installed at the pump's output to protect the pump from pressure surges. The crane incorporates a relief valve to protect its valves and hoses.

For up to 9.5 GPM flow the minimum suction line hose size is 1" ID. For the pressure line a 5/8" ID hose is needed. For the return line between the crane and reservoir a 3/4" ID is advised. Hose sizes can be reduced for lower flows.

A 10 Micron return line filter should be installed in a location that allows convenient access to the replaceable cartridge.

8. DO NOT RUN OIL THROUGH THE CRANE UNTIL THE OIL HAS BEEN FILTERED. An adapter union matching the crane fittings is included. Connect the supply and return lines together using this adapter, circulate the oil through the filter to insure a clean supply. After the pump has filtered 1.5 times the reservoir capacity, hook the hoses to the crane. It is now ready to run.

9. Connect the hydraulic hoses to the fittings projecting below the crane. The pressure hose must be connected to the port marked "P" (No. 8 size fitting). This is the smaller of the two fittings. The return line to the tank must be connected to the port marked "T" (No. 10 fitting). This is the larger of the two fittings. The port letters are stamped on the bottom of the swivel.

10. Verify that the anti two-block will stop extension out and winch up when the Bail arms device is lifted by either function. The Crane Assembly drawing in the owner's manual illustrates how the Bail arms should be installed on the crane.

11. READ AND UNDERSTAND OPERATORS MANUAL BEFORE OPERATING CRANE. Operate the crane through all its functions. Check that each switch operates the correct function. Verify speed of the unit.

12. A boom support is required for this crane. For bodies shorter than 132", place the support so that the traveling block hook is secured and does not block the truck cab door.


13. An outrigger rated at least that of the crane must be installed to keep the crane as level as possible under all expected working conditions. Keeping the crane level reduces the loads on the rotation gear. This will also protect the truck's springs, axle, and wheels when heavy loads are suspended from the crane. OSHA requirements require a stability test be performed on this installation.

14. Extra rear spring leaves or heavy coil springs may be needed to keep the truck level when the crane is mounted on corner or off center locations.

15. Place these instructions with the Operators Manual.


16. Load Chart and stability test decals are to be placed on the truck body for easy visibility by the user.





	Houston TX (713)-688-5533 www.liftmoore.com	DRWN BY: KSP DATE: 6/2/21	DRAWING NO. 50542-D
	PLATE, MOUNTING 60100/72100		

SUGGESTED WIRING SCHEMATIC FOR LIFTMOORE HYDRAULIC CRANE INSTALLATION



Houston TX
(713)-688-5533
www.liftmoore.com

DRWN BY: TV
DATE: 03/02/06


SCHEM, CRANE ELEC. INSTAL-HYDR

DRAWING NO.

50378-B



SUGGESTED HYDRAULIC SCHEMATIC FOR LIFTMOORE HYDRAULIC CRANE INSTALLATION



Houston TX
 (713)-688-5533
 www.liftmoore.com

DRWN BY: TV
 DATE: 03/02/06

SCHEM, CRANE HYD. INSTAL-HYD

DRAWING NO.

50026-B



OPTIONAL ENGINE CONTROL RECEIVER INSTALLATION

The engine control functions allow the user to start and stop the engine and also advance the idle, all from the crane remote pendant control.

The following instructions provide a general guideline for installing and wiring the receiver. Since engine controls vary from manufacture to manufacturer and even from year to year, it is impossible for Liftmoore to maintain specific information on your vehicle. You will have to contact the vehicle and/or engine manufacturer (contact information is provided below). Also, many new vehicles have a provisions for remote engine control built into the ECU, but these functions must be activated and/or programmed by a dealer or authorized service center.

MOUNTING THE RECEIVER

The receiver should be mounted vertically with the antenna up. For best reception, it should be mounted in cab in line of site of operator. Since interfacing connections will generally be inside the cab, a good mounting place is the inside, back the cab with the antenna visible through the back glass. The receiver can be mounted outside of the cab, however it should NOT be mounted inside the engine compartment because of interference generated by the engine.

ENGINE START

Engine start is accomplished by splicing the brown wire on the engine receiver control harness with the ECU start circuit.

WARNING!

Engine start may bypass some manufactures safety functions such as clutch or neutral interlock. It is the installer's responsibility to ensure safe and proper installation.

ENGINE STOP

If the ECU is not equipped with a remote engine kill circuit then a normally closed relay must be installed in the ECU power or engine run circuit. The gray wire on the engine control receiver harness is then connected to the solenoid coil. Activating the circuit will open the solenoid, killing the engine.

NOTE!

It is advisable to include a small jumper wire that can be installed to bypass the solenoid should it fail, otherwise the engine would not run.

ADVANCED IDLE

Many new diesel engines have an advanced idle control circuit built into to the ECU. Some automatically advance the idle when the PTO is activated. This feature may have to be activated and/or programmed by the dealer.

NOTE!

Some engines also require activating a PTO circuit to prevent "Service Engine Soon" or other erroneous errors during PTO operation.

For gas engines or engines without this feature, an after-market throttle advance will have to be purchased separately.

CONTACT INFORMATION

Your truck or engine dealer should be able to provide you with further assistance. Also check the manufacturer's body builder manual (some provided online). Before calling, please have your vehicles make, model, year, engine and transmission size and manufacturer, and VIN if available.

Ford Body Builders Advisory Service	1.877.840.4338
GM Upfitter Integration	1.800.875.4742
Peterbilt	1.940.591.4000
Caterpillar	1.800.847.4986
Cummins	1.800.343.7357
Dodge	
Navistar	1.800.336.4500

www.fleet.ford.com/truckbbas
www.gmupfitter.com

Rammbg@chrysler.com

HOUSTON, TEXAS
 FAX: (800) 824-5559 (USA & Canada)
 FAX: (713) 688-6324
 PHONE: (713) 688-5533
www.liftmoore.com

VEHICLE STABILITY TEST

OSHA (29CFR 1910.180c) requires a stability test be completed by the installer. A qualified person shall perform this test. Please call Liftmoore for any assistance required in completing this test.

TEST PREPARATIONS:

- Use as level of a test site as possible.
- Engage parking brake on vehicle.
- Set outriggers, jackstands, or other stability device in place.
 - Vehicle tires should remain in contact with the ground.
 - The vehicle should be level.

FILL OUT TEST FORM:

- Complete the Vehicle Information and Crane Information data at the top of Page 2 of this form.
- Use a known weight to determine the *Initial Testing Load Radius*. Write this number on all 3 locations on Page 2 of this form.

TEST PROCEDURE:**Determine Area Y Angle**

1. With the crane extended to the *Initial Testing Load Radius* over the rear of the truck, lift the load. Keep the load less than 4" off of the ground.
2. Rotate the load counterclockwise. Monitor all vehicle tires to ensure they remain in contact with the test surface.
3. When one of the vehicle's tires breaks contact with the ground, stop the rotation.
4. Use a protractor to determine this angle. Write this angle on the **Stability Test Results** as *Area Y*.

Determine Area W1 Length

5. Keeping the load off of the ground, retract or elevate the boom until all tires are in contact with the test surface.
6. Continue rotating the load counterclockwise while monitoring all vehicle tires.
7. When one of the vehicle's tires breaks contact with the ground, stop the rotation.
8. Keeping the load off of the ground, retract or elevate the boom until all tires are in contact with the test surface.
9. Repeat this procedure until either the vehicle prevents further rotation or a 180 degree rotation of the load is reached.
10. Record the load radius in feet at this point on page 2 of this form as *Area W1 Length*.
11. Calculate the *W1 % Rated Capacity*.
12. Write the *W1 % Rated Capacity* in the **Stability Test Results** on Page 2 of this form.

Determine Area Z Angle

13. Return the load to the rear of the vehicle and extend the load to the *Initial Testing Load Radius*. Keep the load less than 4" off of the ground.
14. Rotate the load clockwise. Monitor all vehicle tires to ensure they remain in contact with the test surface.
15. When one of the vehicle's tires breaks contact with the ground, stop the rotation.
16. Use a protractor to determine this angle and write this angle on the **Stability Test Results** as *Area Z*.

Determine Area W2 Length

17. Keeping the load off of the ground, retract or elevate the boom until all tires are in contact with the test surface.
18. Continue rotating the load clockwise while monitoring all vehicle tires.
19. When one of the vehicle's tires breaks contact with the ground, stop the rotation.
20. Keeping the load off of the ground, retract or elevate the boom until all tires are in contact with the test surface.
21. Repeat this procedure until either the vehicle prevents further rotation or a 180 degree rotation of the load is reached.
22. Record the load radius in feet at this point on page 2 of this form as *Area W2 Length*.
23. Calculate the *W2 % Rated Capacity*.
24. Write the *W2 % Rated Capacity* in the **Stability Test Results** on Page 2 of this form.

Record Stability Test Results on Placard

25. Record the information from the **Stability Test Results** on the **CRANE TRUCK STABILITY** plate (P.N. 18600) and install the plate in a visible position on the vehicle, preferably near the crane.

THIS TEST IS NOW COMPLETE


STABILITY TEST FORM

Operational limits of this vehicle

VEHICLE INFORMATION	CRANE INFORMATION
Year _____	Model _____
Make _____	Serial Number _____
Model _____	Moment Rating (ft-lbs.) _____
VIN _____	

Determine the **Testing Load Radius** by using the following:

Moment Rating (ft-lbs.)	_____
Multiply by 1.18	x _____
Divide by known weight	÷ _____
Testing Load Radius (ft.)	= _____



Area W1 Length	_____
Testing Load Radius (ft.)	_____
Multiply by 100	_____
W1 % Rated Capacity	_____
Area W2 Length	_____
Testing Load Radius (ft.)	_____
Multiply by 100	_____
W2 % Rated Capacity	_____

STABILITY TEST RESULTS

Area Y:	_____	Degrees
Area Z:	_____	Degrees
Area W1 Rated Capacity:	_____	%
Area W2 Rated Capacity:	_____	%

Test Performed By: _____

Date: _____

CRANE SAFETY RULES

CAUTION!

1. READ AND UNDERSTAND OPERATOR'S MANUAL.
2. INSPECT VEHICLE AND CRANE, INCLUDING ITS OPERATION BEFORE DAILY USE.
3. USE THIS EQUIPMENT ONLY ON SOLID LEVEL GROUND WITH OUTRIGGERS OR JACKSTANDS PROPERLY SET.
4. BEFORE OPERATING THE CRANE REFER TO MAXIMUM LOAD CHART ON CRANE FOR OPERATING LOAD LIMITS.
5. BE SURE LOAD BEING LIFTED IS WITHIN SAFE WINCH CAPACITY AS WELL AS SAFE CRANE CAPACITY. MULTI-PART LINE OPERATION IS REQUIRED WHEN SINGLE LINE LOAD CAPACITY OF WINCH IS EXCEEDED.
6. DO NOT OPERATE, WALK, OR STAND UNDER THE BOOM OR ANY SUSPENDED LOAD.
7. ALWAYS PAY OUT LOAD LINE BEFORE EXTENDING BOOM. WIRE ROPE DAMAGE AND / OR BREAKAGE MAY OCCUR.
8. BOOM MUST BE IN ITS REST BEFORE MOVING VEHICLE.
9. BOOM TIP MUST BE DIRECTLY OVER THE LOAD BEFORE ANY LIFTING IS STARTED. DO NOT DRAG LOADS WITH THIS CRANE.
10. MAINTAIN THIS CRANE AS REQUIRED IN THE OWNER'S MANUAL.
11. DO NOT ALLOW PERSONNEL TO RIDE ON THE LOAD LINE, LOAD, OR BOOM OF THIS CRANE.
12. IT IS UNLAWFUL TO OPERATE THIS EQUIPMENT WITHIN TEN FEET OF HIGH VOLTAGE LINE



THIS PAGE INTENTIONALLY LEFT BLANK



F1122-B
05/12/08

HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmore.com

INTRODUCTION

This crane is a powerful machine designed to lift and move heavy loads. There are many hazards associated with these operations. Liftmoore has designed this crane to be as safe as possible but -

IT IS THE OPERATOR'S RESPONSIBILITY TO PREVENT ACCIDENTS!

This takes pre-planning, attention, and knowledge of basic principles and rules. Even if you have used similar cranes, reading this manual in its entirety will help prevent damage, injury, or even loss of life; benefits well worth the short amount of time it takes to read these pages.

REGULATORY AUTHORITY

Use of this crane is governed by OSHA 29 CFR 1910.180 and may be governed by other federal, state, or local regulations.

IT IS THE OPERATOR'S RESPONSIBILITY TO UNDERSTAND AND COMPLY WITH ALL APPLICABLE REGULATIONS GOVERNING THE OPERATION, INSPECTION, AND MAINTENANCE OF THIS CRANE.

Personnel should be trained, tested, and certified, as recommended by OSHA and ANSI standards, before operating this crane.

USING THIS MANUAL

This manual assumes that the crane is mounted on a typical service body type or similar truck, which is powered by the vehicle electrical or hydraulic system, and is controlled by either the standard pendant control or FM radio control sold by Liftmoore, Inc.

This manual is supplied to provide basic guidelines for the safe use, routine maintenance, and general inspections of this crane.

This manual is supplied to provide basic guidelines for the safe use, routine maintenance, and general inspections of this crane.

Laws, regulations, standards, or policies may be more restrictive than this manual. If a conflict exists for any limit or condition, the safest or most prohibitive shall be used. Under no circumstances shall the load, moment, or stability ratings be exceeded.

Pay particular attention to the following:

WARNING! – Draws attention to hazards, conditions, or procedures that if not observed could result in injury or death.

CAUTION! – Draws attention to hazards, conditions, or procedures that if not observed could result in damage to the crane, load, or other equipment. Equipment failure could in turn lead to injury or death.

NOTE! – Draws attention to conditions or procedures that are essential to emphasize.

For questions, interpretations, or to report errors, please contact Liftmoore, Inc, Engineering Dept.



OPERATING PRACTICES

OPERATING RESTRICTIONS

DUTY CYCLE

For Electric Cranes the duty cycle time should be limited to 10%. This is limited by heat buildup in the motors and declining charge in the batteries. (Installing extra batteries near the crane helps keep the voltage at maximum.)

PERSONNEL

LIFTING OR MOVING OF PERSONNEL IS STRICTLY PROHIBITED! This crane was neither designed nor intended to lift personnel. Under no circumstances should anyone be allowed to ride on the crane, line, or load. All non-essential personnel must be kept away when using the crane. The load must never be moved over people, nor must anyone be allowed to pass or stand under a suspended load.

ELECTRICAL LINES

Consult ASME B30.5 for operating procedures, minimum safe distances, and prohibited zones when working around electrical lines or poles.

When operating near electrical power lines, the crane must be positioned so that the distance from the crane to the lines or poles is equal to or greater than the length of the fully extended boom plus the minimum safe distance required.

All parts of the crane, line, and load must be kept a minimum safe distance from electrical power lines and poles. This distance is 10 feet for electrical lines carrying 50kV or less.

UNDER NO CIRCUMSTANCES SHOULD A CRANE BE OPERATED UNDER ELECTRICAL POWER LINES.

SETUP

POSITION The vehicle must be positioned so that the load is kept as close to the crane base as possible to reduce the moment on the crane. Consideration must be given to starting and ending position as well as firmness and slope of the ground and any obstructions.

OUTRIGGERS The outriggers or jackstands must be firmly set and the vehicle as level as possible. This will reduce the stresses on the rotation drive and keep the load off the vehicle's suspension. Keep in mind that the weight on the vehicle will shift as the crane and load is rotated.

MANUAL BOOM EXTENSION If the manual extension part of the boom is needed, it must be extended and the boom pin placed in the required position. Insert the pin and replace the pin's hairpin keeper before attempting to lift any load.

LOAD LIMIT The operator must understand the crane load chart. The operator must ensure that the load is within the load limits over the entire range which it will be moved. Be sure to include the weight of any lifting devices including the travel block.

The load limit chart is attached to the side of the crane to aid the operator.

The boom angle indicator and chart aids the operator in determining the load capacity at various boom angles and extensions. It also gives the load limit at that configuration.

STABILITY A stability chart must be posted near the crane. The operator must understand the stability chart. The crane may be de-rated over some areas of its operating radius.



TRAVEL BLOCK The operator must determine if the load is within the single line compatibility of the winch or if a multi-part line configuration is needed.

REEVING Ensure the proper routing of the rope through the sheaves and travel block. The rope must lie in the sheave groove and must not rub against any metal objects.

Ensure the rope is correctly wound on the winch drum. The crane assembly drawing will indicate if the rope must be wound over the top or bottom of the drum. The rope must never contact any part of the winch mounting.

WARNING!

If the winch winding direction is reversed the brake will not work and the load will fall.

ATTACHING THE LOAD

POSITION The boom tip must be moved over the load before lifting so that it will be lifted straight up.

CAUTION!

Never drag a load with the crane. Dragging a load puts very high stresses on the crane for which it was not designed.

ROPE Check the rope condition to ensure it is not frayed or damaged. Ensure that the rope is not kinked and that it does not contact any sharp edges or make any sharp bends.

If using double line configuration, ensure that the lines are not twisted.

CAUTION!

Never wrap the hoist rope around the load! Serious damage to the rope WILL occur.

HOOK Always make sure the load is applied to the throat of the hook. Never use a bent hook.

CAUTION!

Always lift with the throat of the hook. Never lift with the load applied to the tip of the hook. Doing so will bend the hook.

SLINGS If the load does not have a lifting eye, use a nylon, chain, or other type of sling designed for lifting and rated for loads greater than that being lifted.

BALANCE Ensure the load will be secure and balanced when lifted. Ensure that the load cannot shift in the sling and that the sling cannot slide across the hook should the load become unbalanced.

LIFTING THE LOAD

Before lifting, ensure that the load is free from all mountings and is no way attached or stuck to anything.

Ensure that at least five full wraps remain on the winch drum at all times.

Test the winch brake by lifting the load a few inches and ensuring that it does not slip.



HOLDING THE LOAD

The operator must keep the load in sight at all times once it is lifted.

The operator must never leave the controls once the load is lifted.

The operator must ensure that no one is allowed to pass or stand under a suspended load.

CAUTION!

Never move the vehicle with a suspended load. Doing so will put dynamic loads on the crane for which it was not designed.

MOVING THE LOAD

Before moving the load, make sure the path is free of any obstructions or people.

Avoid sudden accelerations or stops. Speeds must be kept to a minimum, especially rotation, to keep the load from swinging.

Avoid sudden reversing of direction. Do not reverse direction while the load is still moving.

Make sure that no part of the crane, boom, or load makes contact with any obstruction or comes within a minimum of ten feet from any electrical line.

TRANSIT

While in transit, the crane must be stowed, preferably in a boom rest. The crane must be prevented from rotating and the hook prevented from swinging.



INSPECTION AND MAINTENANCE

OSHA and ASME require frequent and periodic inspections. Records of these inspections must be kept readily available. Liftmoore requires periodic maintenance to ensure proper operation and prolonged life of the crane.

INSPECTION

DAILY INSPECTION

OSHA 29CFR 1910.180 (d)(2)(i) requires the following be checked daily prior to use:

- All control mechanisms for maladjustment interfering with proper operation as well as for excessive wear of components and contamination by lubricants or other foreign matter.
- All safety devices for malfunction. This should include the anti-two block and pressure switch.
- Deterioration or leakage in air or hydraulic systems.
- Crane hooks with deformations or cracks. For hooks with cracks or having more than 15 percent in excess of normal throat opening or more than 10 deg. twist from the plane of the unbent hook.
- Electrical apparatus for malfunctioning, signs of excessive deterioration, dirt, and moisture accumulation. This should include the battery terminals, master disconnect switch, electrical swivel
- The wire rope shall be replaced if any of the following conditions are noted:
 - Kinking, crushing, bird-caging, or other damage
 - Reductions from nominal diameter of more than one-sixty-fourth inch for diameters up to and including five-sixteenths inch, one-thirty-second inch for diameters three-eighths inch to and including one-half inch.
 - Thimble is not in place or is damaged
 - Any evidence of heat damage
 - Six or more randomly distributed broken wires in 1 lay
 - Three or more broken wires in 1 strand in 1 lay

MONTHLY INSPECTION

A thorough inspection of all ropes in use shall be made at least once a month and a certification record which includes the date of inspection, the signature of the person who performed the inspection and an identifier for the ropes shall be prepared and kept on file where readily available. All inspections shall be performed by an appointed or authorized person. Any deterioration, resulting in appreciable loss of original strength shall be carefully observed and determination made as to whether further use of the rope would constitute a safety hazard. Some of the conditions that could result in an appreciable loss of strength are the following:

- Reduction of rope diameter below nominal diameter due to loss of core support, internal or external corrosion, or wear of outside wires.
- A number of broken outside wires and the degree of distribution of concentration of such broken wires.
- Worn outside wires.



- Corroded or broken wires at end connections.
- Corroded, cracked, bent, worn, or improperly applied end connections.
- Severe kinking, crushing, cutting, or unstranding.

PERIODIC INSPECTION

An Annual Inspection Form is included in this manual. OSHA 29CFR 1910.180 (d)(2)ii requires periodic inspections of this crane. Liftmoore recommends an annual inspection using the included form.

MAINTENANCE PRECAUTIONS

The crane should be maintained monthly for safety reasons and to reduce stress on the crane.

WARNING!

Never perform any maintenance while the crane has any type of load on it. Use the manual operation procedure to lower the load if necessary.

WARNING!

Hydraulic cylinders may have high pressure stored in them even after hydraulic power is removed.

The counterbalance and pilot operated check valve in the cylinder will always hold some pressure in the cylinder. Slightly extending the cylinder then retracting a small amount will relieve most of the pressure in the cylinder. **DO NOT DEADHEAD THE CYLINDER!** This will store the maximum amount of pressure in the cylinder. Care should be taken when either valve is removed from the cylinder as some pressure will still remain.

After any maintenance has been performed the crane shall not be operated until all guards have been reinstalled, all safety devices reactivated, and maintenance equipment removed.

LUBRICATION Refer to the crane specification section for the periodic maintenance schedule and type of lubrication required.

BOLTS Bolts may loosen over time due to vibration; therefore, they should be checked periodically. If bolts need to be replaced, make sure they are replaced with bolts of equal or greater strength. Check the periodic maintenance schedule (Crane Specification Section) for bolt specification and torque.

NOTE!

Sheave and boom and cylinder pivot bolts are not standard bolts. The shank and thread length of these bolts have been modified so that they do not pivot on the threads. Consult the parts section of this manual for part numbers of these bolts.

OTHER MAINTENANCE

Refer to parts drawings for any specific maintenance or adjustment procedures such as hydraulic winch brake, rotation drive gear set adjustment, Etc.



MONTHLY INSPECTION REPORT

Crane Model No. _____ Serial Number _____

Are Boom Hitch Pins and Keepers in place?	Yes _____	No _____
Wire Line Hook with Safety Latch Working?	Yes _____	No _____
Is Hook OK, (Not bent)?	Yes _____	No _____
Is Thimble on Wire Rope OK?	Yes _____	No _____
Is Traveling Block in use?	Yes _____	No _____
Is Wire Rope OK, not kinked or frayed?	Yes _____	No _____
Are all Boom Sections straight?	Yes _____	No _____
Are Sheave Bolts in place and tight?	Yes _____	No _____
Do all Sheaves rotate easily?	Yes _____	No _____
Are Mounting Bolts tight?	Yes _____	No _____
Is Anti Two-Block functioning properly?	Yes _____	No _____
Is Boom Angle Indicator in place and functioning and is Chart legible?	Yes _____	No _____
Are Cylinder Mounting Bolts secure?	Yes _____	No _____
Are Winch Mounting Bolts tight?	Yes _____	No _____
When stopped does winch drift less than 1.0 Inches?	Yes _____	No _____
Is Load Chart in place and easily read?	Yes _____	No _____
Are functions on Pendant operating correctly?	Yes _____	No _____
Is Hydraulic Reservoir full?	Yes _____	No _____
Is Outrigger straight and functioning?	Yes _____	No _____

Any items checked 'No' must be repaired before using this crane.



ANNUAL CRANE CERTIFICATION (29CFR1910.180)

OWNER _____

MODEL NUMBER _____ SERIAL NUMBER _____

DATE _____

Check the following:

___ Crane Mounting Bolts (Torque)

___ Winch mounting Bolts (Torque)

___ Boom mounting bolts

___ Cylinder mounting bolts

___ Cracks on boom (Check when extended)

___ Extension Pads not worn excessively

___ Cracks on housing

___ Weld cracks on boom

___ Weld cracks on housing

___ Boom swing approximately one inch or less at boom tip when retracted

___ Hydraulic leaks

___ Hoses not chafed or cracked

Sheaves not cracked

___ Boom Tip

___ Traveling Block

___ Sheaves not worn excessively

___ Boom Tip

___ Traveling Block

___ Sheaves rotate freely

___ Boom Tip

___ Traveling Block

___ *Load Chart in place and legible*

___ *Boom angle chart in place and legible*

___ *Labels in place (See manufacturer's chart)*

___ *Crane Hook Throat Opening within 15% of standard*

___ *Crane Hook not bent more than 10 degrees from plane*

___ *Hook safety latch operating properly*

___ *Booms pin(s) and Keeper(s) in place (Manual Extension Section)*

___ *Wire Rope removed if the following occurs:*

Six randomly distributed broken wires in one lay or three broken wires in one strand in one lay.

Wear of one-third the original diameter of outside individual wires.

Kinking, crushing, bird-caging or any other damage.

Evidence of heat damage.

Reduction from nominal diameter of more than one sixty-fourth inch for diameters to five-sixteenths diameter and one-thirty-second inch for diameters three-eighths to one-half inch.

___ *Wire Line installed as manufacturer requires.*

___ *Protective covers in place*

___ *Grease crane as required*

Check fluid level

___ *Winch*

___ *Gearbox*

___ *Reservoir*

2-12

Control system for proper operation

___ *Winch Up and Down*

___ *Boom Up and Down*

___ *Boom In and Out*

___ *Rotation CW and CCW*

Anti Two-Block (Required on Power Extendible Cranes) interrupts:

___ *Boom Down*

___ *Boom Out*

___ *Winch Up*

___ *Boom Up stopped by Up Limit Switch*

___ *Outrigger or jackstand operable*

___ *Outrigger crushing decal in place*

___ *Outrigger and Jackstand operates properly*

___ *Boom rest in place and used*

___ *Load Sensor trips when overloaded*

___ *Winch Down does not overrun when stopped*

___ *Crane stability chart in place and visible.*

I certify that I have performed the above tests and that any deficiencies were corrected and now comply as above.

Signed _____







Print Name _____







Company _____


Address _____

City _____ *State* _____

STANDARD HAND SIGNALS FOR CONTROLLING CRANE OPERATIONS

 <p>HOIST. With forearm vertical, forefinger pointing up, move hand in small horizontal circle.</p>	 <p>LOWER. With arm extended downward, forefinger pointing down, move hand in small horizontal circle.</p>	 <p>USE MAIN HOIST. Tap fist on head; then use regular signals.</p>
 <p>USE WHIPLINE (Auxiliary Hoist). Tap elbow with one hand; then use regular signals.</p>	 <p>RAISE BOOM. Arm extended, fingers closed, thumb pointing upward.</p>	 <p>LOWER BOOM. Arm extended, fingers closed, thumb pointing downward.</p>

 <p data-bbox="256 751 594 926">MOVE SLOWLY. Use one hand to give any motion signal and place other hand motionless in front of hand giving the motion signal. (Hoist slowly shown as example.)</p>	 <p data-bbox="630 751 963 894">RAISE THE BOOM AND LOWER THE LOAD. With arm extended, thumb pointing up, flex fingers in and out as long as load movement is desired.</p>	 <p data-bbox="1003 751 1336 926">LOWER THE BOOM AND RAISE THE LOAD. With arm extended, thumb pointing down, flex fingers in and out as long as load movement is desired.</p>
 <p data-bbox="266 1497 599 1566">SWING. Arm extended, point with finger in direction of swing of boom.</p>	 <p data-bbox="638 1497 954 1602">STOP. Arm extended, palm down, move arm back and forth horizontally.</p>	 <p data-bbox="997 1497 1330 1602">EMERGENCY STOP. Both arms extended, palms down, move arms back and forth horizontally.</p>



THIS PAGE INTENTIONALLY LEFT BLANK



F2409-0
4/11/16

HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmoore.com



GUIDER

RADIO/CAN REMOTE CONTROL SYSTEM

INSTALLATION AND OPERATION MANUAL

LIFTMOORE
3B278DAJ.doc
December 12, 2019
BK

GUIDER REMOTE

INDEX

DESCRIPTION	3
OPERATION	4
INDICATOR LEDs	6
TRANSMITTER AND RECEIVER SYNCHRONIZATION.....	6
TEACH BY CAN CABLE	7
TEACH BY RF.....	7
CLONING	7
BATTERY CHARGING.....	8
OUTPUTS	9
INPUTS.....	10
INSTALLATION	10
BEFORE APPLYING POWER!.....	11
SYSTEM TROUBLESHOOTING USING ON BOARD GATE:.....	12
ACCESSING THE CONTROL PANEL	12
DIAGNOSTICS	13
CALIBRATION	14
HISTOGRAM	17
RECEIVER SOFTWARE UPDATE.....	18
GATE CONFIGURATION	19
GATE SOFTWARE UPDATE	20
WIRING CRANE RECEIVER.....	22
WIRING ENGINE RECEIVER	23
ROUTINE MAINTENANCE	24
MAINTENANCE PRECAUTIONS	24
TROUBLESHOOTING	25
TROUBLESHOOTING CHART	26
ERROR CODES CRANE RECEIVER	28
TRANSMITTER PICTORIAL.....	32
CRANE RECEIVER PICTORIAL	33

GUIDER REMOTE

TILT, CHASSIS SENSOR PICTORIAL..... 35
ROTATIONAL, BOOM SENSOR PICTORIAL..... 36
PRESSURE SENSOR PICTORIAL 37
SPECIFICATIONS..... 38
INSTRUCTION TO THE USER..... 39

GUIDER REMOTE

DESCRIPTION

The GUIDER REMOTE is a state of the art microprocessor based Radio Frequency (RF) control system. It will provide the operator the ability to wirelessly operate equipment. The operator is required to follow all OSHA www.osha.gov and other applicable safety standards when operating the equipment. Do not use high power radio devices in close proximity of this product.

The remote control system consists of: the radio transmitter, main receiver module, engine receiver module, and associated optional equipment such as wiring harnesses.

The transmitter is equipped with a trigger, twist to release E-stop

switch, and toggle switches for the various functions. It includes a port for wired control via the built-in Controller Area Network (CAN) system¹. This unit runs on a 3.7V rechargeable Li-Ion battery when in wireless mode. When in wired mode, the transmitter runs with power supplied by the CAN cable. This is useful if the battery power gets too low to operate the transmitter but continued operation is needed. The port is also used to charge the internal battery.

The system's radio receiver has both a proportional output and ON/OFF outputs to accommodate the functions available on the transmitter. All outputs are current-sourcing. It also includes a port for wired

¹ The CAN control will only work with the CRANE module. The ENGINE module only works on RF

GUIDER REMOTE

(CAN) and RS-232 communication for system diagnostics.

OPERATION

Power must be applied to the receiver module for the system to work.

Releasing the E-STOP will turn on the transmitter. Pressing the E-STOP button will turn off the transmitter. Pressing the E-STOP will turn off all outputs as a safety feature. If the transmitter goes out of range for more than 2 seconds, all the momentary outputs will turn off as a safety feature, the e-stop output will turn off after 10 seconds.

To operate a proportional output, toggle the switch of the desired function and pull the trigger to the level desired.

***Please note that if the trigger is pulled before the function is selected, the proportional output will not work as a safety feature.** Release the trigger and begin again in the proper sequence.

Once the Guider transmitter is on, the operating screen will be displayed. On the top left corner of the screen is transmitter battery display. Plug in the transmitter as soon as possible after seeing the battery symbol turn red. See BATTERY CHARGING below. The top middle of the screen shows the LINK status with the receiver (CAN, RF, or NO LINK), and the top right of the screen shows the system voltage. Load capacity and any errors (if present) are then shown below this when connected to the CRANE receiver. When connected to

GUIDER REMOTE

the ENGINE receiver, the display will show RUNNING ENGINE FUNCTIONS.

CONFIGURATION MENU

To navigate to the configuration menu turn the transmitter and receiver off. Press and hold the HORN button then turn on the transmitter. Keep holding the button for greater than 10 seconds until the menu is shown. There are the following options under the configuration menu: TEACH MODE, CLONE TX, SLEEP TIME, RESET TX, and EXIT. To select an option press the HORN button. To scroll down, use the AUX switch and to scroll up, use the RPM switch. To EXIT the configuration menu and go to the operating screen select EXIT.

TEACH MODE

Select this option to put the transmitter into teach mode and synchronize the receiver and transmitter. See transmitter and receiver synchronization below for more information.

SLEEP TIME

To save battery life, the transmitter will turn off after 60 minutes no buttons are pressed. The user must press and release the E-STOP at this point to restore transmitter operation. To change the sleep time, select this option and use the RPM and AUX switch to change the number of minutes the transmitter waits to go to sleep. Press the HORN button to save the selected sleep time and exit.

GUIDER REMOTE

RESET TX

Warning! If the transmitter is reset, the receiver will have to be re-synchronized to the transmitter for operation! To reset the transmitter select RESET TX then press any button.

CLONE TX

Warning! This feature can pose a safety hazard for operators if both transmitters are used simultaneously! Use with caution! Occasionally, it is desirable to have more than one transmitter work with a single receiver. This is accomplished by a process called cloning. See CLONING below for more information.

INDICATOR LEDs

The receiver module can identify problems with the system in the form of an error code (red LED will be blinking). Check the decal on the receiver to diagnose system problems. Then, refer to the ERROR CODE CHART in this manual for explanation of the error codes. The green LED indicator will blink on the receiver during active operation. It will turn on solid when the Gate is connected to Wi-Fi.

TRANSMITTER AND RECEIVER SYNCHRONIZATION

Each radio remote system is designed to operate with a unique radio ID code and RF channel sequence. Each receiver is programmed to respond *only* to the transmitter with the correct ID code/RF channel

GUIDER REMOTE

sequence for which it is set. This feature allows multiple systems to work in close proximity to one another without interference.

In the event that a transmitter becomes damaged and a new one is needed, the receiver can be reprogrammed to respond to the new transmitter. To teach the ID code to the receiver, use the following procedure. ***Please note that if this procedure is interrupted before it has completed, the system may have intermittent operation:**

For 3B2783A, Crane Receiver:

TEACH BY CAN CABLE

1. Plug the CAN cable into the CAN port on both the receiver and transmitter and operate a function on the transmitter until the LEDs on the front panel go from steady to flashing for at least 5 seconds. The

units will be synchronized at this point

TEACH BY RF

1. Turn the transmitter and both receivers off
2. On the transmitter, go to the configuration menu above then select TEACH MODE
3. Apply power to the receiver (engine or crane). The transmitter will display SUCCESFUL and go to operating screen
4. Teach complete

CLONING

Warning! This feature can pose a safety hazard for operators if both transmitters are used simultaneously! Use with caution! Occasionally, it is desirable to have more than one

GUIDER REMOTE

transmitter work with a single receiver. This is accomplished by a process called cloning. Cloning allows an additional transmitter (B) to have the same ID code as the original transmitter (A). If this feature is desired, use the following procedure:

1. Make sure transmitters and receivers are off
5. On transmitter A, go to the configuration menu above then select TEACH MODE
6. On transmitter B, go to the configuration menu above then select CLONE TX
2. Wait for a few seconds until the screen displays SUCCESFUL
3. Turn off both transmitters
4. Synchronize one of the transmitters to the receivers

If cloning feature has been

invoked and is no longer desired, the ID code of one of the transmitters needs to be changed. This will unclone the transmitters. If this is desired, use the following procedure:

1. Make sure the receiver and transmitters are OFF
2. On the transmitter, go to the configuration menu above then select RESET TX
3. Press any switch again to select a new ID
4. Uncloning complete
5. Use transmitter and receiver synchronization procedure above to link the uncloned transmitter to new receivers

BATTERY CHARGING

The transmitter is designed with a smart battery charger. The battery can be charged by

GUIDER REMOTE

connecting the CAN cable from the receiver module (powered on) to the port on the transmitter, or by plugging the AC wall charger or DC cigarette charger (minimum 2A @ 12.6VDC) into the port. Red and green LED indicators on the underside of the transmitter indicate the status of the charger: A red LED indicates that the battery is charging and a green LED indicates that the battery is fully charged.

IMPORTANT BATTERY INFO

When the battery is new, the run-time of the transmitter will be shorter until it has gone through the drain/charge cycle several times. After this point, the unit's current drain should allow at least 20 hours of run-time before a recharge is needed.

The temperature that the transmitter battery is exposed to affects performance and useful life. It is strongly recommended you keep within the following limits:

- A. Charging: -4 to +86°F
- B. Operating: -20 to +122°F
- C. Storing: -4 to +86°F
(lower is better)

OUTPUTS

Each of the outputs from the receiver module is designed with built-in short circuit and overload protection. The outputs can also detect a no-load or broken wire condition.

These error conditions are evident by the alphanumeric display on the receiver module *or* the HISTOGRAM page on the optional Gate.

GUIDER REMOTE

The ON/OFF outputs will indicate an error under no load or broken wire status if NOT activated, and will detect a short IF activated. The proportional outputs will detect a no-load or short condition WHEN activated.

INPUTS

Digital inputs are available for ATB, BOOM LIMIT, and PRESSURE signals. They will function up to battery voltage levels. One analog input is available for a PRESSURE TRANSDUCER. This expects a signal from 4-20mA.

INSTALLATION

Refer to the WIRING CHART in this manual for hookup of the harness.

To install the receiver module, use the two mounting holes

provided on the enclosure to attach it in a vertical manner with the connectors facing down. Please take extra caution not to damage internal components while installing. For high vibration applications, use shock absorbing mounts. It is advised to mount the unit as high as possible, keeping clear of metal obstructions around the antenna which might affect RF performance. Antenna extension cables are available from Kar-Tech to aid in this, if needed.

The main power to the receiver should be connected through a switched, fused line capable of a minimum of 20 amps. For best results, connect power (+) to the receiver via an auxiliary terminal of the ignition switch, PTO switch, or ignition relay. Be sure that the ground (-) is connected securely to the

GUIDER REMOTE

chassis or battery with a star washer which digs into the base metal to insure good contact.

- Read the rest of this manual.

All connections must be properly insulated to protect against shorts.

Seal all connections with a non-conductive silicone grease to prevent corrosion.

BEFORE APPLYING POWER!

- Check power and ground for proper polarity.
- Check the wiring harness for possible shorts before connecting to output devices (i.e., valves and relays) by checking each mating pin terminal.
- Verify that the transmitter battery is fully charged.

GUIDER REMOTE

SYSTEM TROUBLESHOOTING USING ON BOARD GATE:


The GATE creates a Wi-Fi access point which allows you to connect to any device with Wi-Fi and web browser such as smart phones, pads or personal computers. It supports Google Chrome, Internet Explorer, Firefox and IOS Safari and allows user to configure, diagnose and troubleshoot the system.

ACCESSING THE CONTROL PANEL

1. Turn on the power to the receiver.
2. Use your device and look for the available WiFi networks. A network under the name of "LIFTMOOREXXXXXXXXXX" should be available at

this point. The "XXXXXXXXXX" should be the 10 digit numeric serial # on the crane WIFI receiver. Connect to the network, if required password is 3B2785A1.


3. Once the connection is established, open a web browser on your device. The Chrome browser is recommended.
4. Enter the address `http://192.168.1.1` in the address bar



Address Bar

5. If the Gate is not used for 5 minutes after power up it will automatically turn off. Recycle power to the receiver to turn it back on.
6. The following options are available from the main screen.

GUIDER REMOTE




Main Screen

DIAGNOSTICS

Tap the `Diagnostics` button to see the diagnostic screens, which shows the present state of remote communications, and system I/O.

When the round circle next to a label is dark, the corresponding ON/OFF input or output is sensed to be active or ON.




Diagnostics

GUIDER REMOTE

CALIBRATION

To change the configuration of the unit, tap the Calibration icon.



*End user Calibration
Page Password = 1713*

GUIDER REMOTE

Help

LIFTMOORE
TRUCK CRANES

Wi-Fi Configuration

Home

Wi-Fi Name(SSID) ▼

Current Value: LIFTMOORE3B2785
New Value:

Broadcast SSID
 Not broadcast SSID

Enable Multiple Connections
 Disable Multiple Connections

NOTE: 1. Wi-Fi Name limited to 20 characters
2. Wi-Fi Name can only use numbers and letters
3. Channel can be set from 1 to 11

Save Factory Settings

Refresh

Gate Configuration Page

GATE CONFIGURATION

The password to gain access to the gate configuration page is (*Contact Liftmoore Inc.*).

This page allows you to change the name (SSID) of the Wi-Fi network you are connecting to. Factory settings will rename the Wi-Fi to its original name.

If Broadcast SSID option is

selected, the Wi-Fi name (SSID) is public and it will be visible to any other Wi-Fi devices. Otherwise, the Wi-Fi name (SSID) is hidden and it would require manual connection to the network.

If Enable Multiple Connections is selected, multiple connections up to 4 devices could be connected to the GATE. However, only one of the connected devices can use the GATE. If Single connection is enabled, only one device can be connected to the GATE.

NOTE: A reconnect to the new Wi-Fi connection is needed after each change. It is advised to keep a note of the Wi-Fi name in case if Not Broadcast SSID option is selected. Forgetting the Wi-Fi name after selecting this to be sent to KAR-TECH for RESET .

GUIDER REMOTE

WIRING CRANE RECEIVER

P1 - DEUTSCH DTM13-12PA, GRAY

PIN	DESCRIPTION
1	GROUND
2	CANH
3	CANL
4	N/C
5	N/C
6	BOOM PRESSURE 4-20mA INPUT
7	ANTI-TWO-BLOCK SWITCH INPUT
8	N/C
9	N/C
10	PROPORTIONAL SPEED CONTROL OUTPUT
11	HORN OUTPUT
12	POWER (9-30V)

P2 - DEUTSCH DTM13-12PB, BLACK

PIN	DESCRIPTION
1	ROTATION CW OUTPUT
2	ROTATION CCW OUTPUT
3	EXTEND OUT OUTPUT
4	EXTEND IN OUTPUT
5	BOOM UP OUTPUT
6	BOOM DOWN OUTPUT
7	HOIST UP OUTPUT
8	HOIST DOWN OUTPUT
9	N/C
10	E-STOP OUTPUT
11	N/C
12	BOOM UP LIMIT SWITCH INPUT

GUIDER REMOTE

WIRING ENGINE RECEIVER

DEUTSCH DTM13-12PA

PIN	DESCRIPTION
1	GROUND
2	N/C
3	N/C
4	N/C
5	ENGINE SPEED SELECT DIGITAL INPUT
6	N/C
7	N/C
8	AUXILIARY OUTPUT
9	ENGINE START OUTPUT
10	ENGINE STOP OUTPUT
11	ENGINE SPEED OUTPUT
12	POWER (9-30V)

TRANSMITTER PORT

- A POWER
- B GROUND
- C CAN HIGH
- D CAN LOW
- E NO CONNECTION

WIRING TILT AND ROTATIONAL SENSOR

DT04-4P-E008 CON/ KT PN: 055-157-0402	
PIN	DESCRIPTION
1	POWER 9-30V
2	GROUND
3	CAN HIGH
4	CAN LOW

GUIDER REMOTE

ROUTINE MAINTENANCE

Clean transmitter regularly with a damp cloth and mild detergent.

Inspect electrical wiring for wear points or other damage. Repair as required.

Inspect all connections for looseness or corrosion. Tighten and/or "seal" as necessary.

Guider pendants that include a trigger control should be cleaned periodically by blowing air around the trigger area to remove any debris that would prevent proper operation. Apply a light machine oil to the point of rotation when clean.

MAINTENANCE PRECAUTIONS

When performing any inspection

or maintenance work on the remote system, always exercise care to prevent injury to yourself and others or damage to the equipment. The following are general precautions, which should be closely followed in carrying out any maintenance work.

Do not have hydraulic power available to the valves when performing electrical tests.

Never operate or test any function if any person is in an area where they could be hurt by being hit or squeezed by the hydraulic equipment.

Turn power off before connecting or disconnecting valve coils or other electrical loads.

GUIDER REMOTE

TROUBLESHOOTING

This next section provides basic operator level troubleshooting for the GUIDER REMOTE system. If, after following these instructions, the system still does not function, contact your sales representative for further instructions or servicing.

GUIDER REMOTE

TROUBLESHOOTING CHART

<i>PROBLEM</i>	<i>SOLUTION</i>
No functions work	<ol style="list-style-type: none">1. Verify transmitter power source – battery, CAN cable, external supply, etc2. Verify that receiver control module power source is present at its input connector3. Check for proper system ground4. Check the receiver or control module LED status display for functionality or errors3. Check the hydraulic system4. Check to see if the crane receiver has sufficient cooling.
Certain functions do not work	<ol style="list-style-type: none">1. Check the wiring and connections from the receiver control module to the control module to the valve coil for the particular function that does not work2. Check the receiver control module LED status display for possible fault or error indication3. Check the hydraulic system4. Check the electrical system5. Check to see if the crane receiver has sufficient cooling.
Functions operate intermittently	<ol style="list-style-type: none">1. Check for loose connections at the valve coil2. Check the receiver control module LED status display for functionality or errors3. Check the receiver antenna for damage

GUIDER REMOTE

	<p>and possible obstructions</p> <ol style="list-style-type: none">1. Check the hydraulic system2. Check to see if the crane receiver has sufficient cooling.
--	--

GUIDER REMOTE

ERROR CODES CRANE RECEIVER

Receiver Display	Error Code	Transmitter Display
NOLK	RF Communication Error	RF signal will show red x
WiFi	WiFi Linked to Device	N/A
RLV	Low Truck Battery Error	Truck low batt err
ESTP	E-STOP Condition	E-STOP mode err
XDCR	Transducer Error	Transducer err
OVLD	Overload Condition	Overload err
ATB	ANTI-TWO-BLOCK Condition	ANTI-TWO-BLOCK
BLMT	BOOM UP LIMIT Condition	Boom limit err
BSNS	BOOM (Rotate) Sensor Error	Boom angle sens err
CSNS	CHASSIS (Tilt) Sensor Error	Tilt sensor err
EC01	ROTATE CW Output Error	Rotate CW err
EC02	ROTATE CCW Output Error	Rotate CCW err
EC03	EXTEND OUT Output Error	Extend out err
EC04	EXTEND IN Output Error	Extend in err
EC05	BOOM UP Output Error	Boom up err
EC06	BOOM DOWN Output Error	Boom down err
EC07	HOIST UP Output Error	Hoist up err
EC08	HOIST DOWN Output Error	Hoist down err
EC09	E-STOP Output Error	E-STOP out err
EC10	HORN Output Error	Horn err
EC11	SPEED Output Error	Speed out err
EC12	TRIGGER Input Error	Trigger err
EC13	TRIGGER before Switch Error	Trigger start err
N/A	N/A	Chassis tilted

Error code explanations:

NOLK Transmitter is off
 Transmitter went to sleep mode
 Interference in RF communication link

RLV System voltage is below 11V (12V system)

ESTP E-STOP button is pressed on the transmitter

GUIDER REMOTE

- XDCR** No voltage present at pressure input or voltage is out of specified range (4-20mA)
- OVLD** Overload condition based on Gate setting is present
- ATB** Anti-Two Block condition present, ATB input is low
- BLMT** Boom Limit input active, BOOM LIMIT input is low
- CSNS** No CAN messages are being received from Tilt sensor. Check wiring
- BSNS** No CAN messages are being received from Rotational sensor. Check wiring
- EC1-10** Short or open load/coil on output
- EC11** Current at SPEED output is above rated current, output will turn off
- EC12** No voltage present on trigger in transmitter
- EC13** Trigger was pulled on transmitter before switch was activated

Chassis tilted - If the chassis is tilted over five degrees, all functions are reduced to slow speed. The following outputs will also be disabled: Boom Down, Hoist Up, and Extend Out.

GUIDER REMOTE

ERROR CODES ENGINE RECEIVER

EC	POSSIBLE CAUSE
1	RF COMMUNICATION ERROR
2	ENGINE SPEED OUTPUT ERROR

Error code explanations:

- 1** Transmitter is off
 - Transmitter went to sleep mode
 - Interference in RF communication link
- 2** Short or open load/coil on output

GUIDER REMOTE

PARTS LIST

PART NUMBER	DESCRIPTION
28790	RADIO TRANSMITTER
28792	CRANE RADIO RECEIVER
28793	ENGINE RADIO RECEIVER
28796	CAN ADAPTOR CABLE 25'
28794	SENSOR, PRESSURE, 5K PSI, 4-20, 1/4-18 NPT, DT04-3P
20186	CHARGER, 12 VDC CIGARETTE LIGHTER PLUG
24510	FAST CHARGER SUPPLY, 110V AC WALL
28795	TILT SENSOR
28853	ROTATIONAL SENSOR

There are no user-serviceable parts inside the transmitter or the receiver. Return the units for service.

Note: For operation with negative ground systems only.



WARNING:

The GUIDER REMOTE must be operated in compliance with all applicable safety regulations, rules, and practices. Failure to follow required safety practices may result in death or serious injury.

The information, specifications, and illustrations in this manual are those in effect at the time of printing. We reserve the right to change specifications or design at any time without notice.




GUIDER REMOTE

TRANSMITTER PICTORIAL




GUIDER REMOTE

CRANE RECEIVER PICTORIAL




GUIDER REMOTE

ENGINE RECEIVER PICTORIAL




GUIDER REMOTE

TILT, CHASSIS SENSOR PICTORIAL





GUIDER REMOTE

ROTATIONAL, BOOM SENSOR PICTORIAL



GUIDER REMOTE

PRESSURE SENSOR PICTORIAL



Parameter	
Pressure Range	0~5000psi
Pressure Connection Type	NPT1/4
Electrical Connection	DT04-3P
Supply Voltage	10~36VDC
Output Signal	4~20mA
Accuracy	±0.5%F.S
Pressure cycle	>10 ⁸
Overload Pressure	2X
Burst Pressure	10X
Long-term stability	±0.25F.S/Year
Working Temperature	-40~125?
Ingress protection	IP65

GUIDER REMOTE

SPECIFICATIONS

FCC ID: P4U-MOD164

Industry Canada Certification Number: 4534A-MOD164

EQUIPMENT CLASS: PART 15 SPREAD SPECTRUM TRANSMITTER

TRANSMITTER

Power supply	3.7V Li-Ion Rechargeable Battery
Fast charger temperature range	+5°C to +60°C
Operating temperature - Radio	-40°C to +85°C
Storage temperature.....	-40°C to +100°C
RF Frequency	902-928 MHz
RF Transmit power (EIRP).....	100 mW
LCD display operating range (if equipped)	-20°C to +70°C
Vibration	3G to 200Hz
Shock.....	50G
NEMA	12

RECEIVER

Power supply voltage	9-30VDC
Operating temperature	-40°C to +85°C
Storage temperature.....	-40°C to +100°C
Outputs.....	5.0A max each, sourcing, 20A system max
Digital Inputs (when equipped)	supply voltage
Analog Inputs (when equipped)	0-5VDC/4-20mA
RF Frequency	902-928 MHz
Vibration	3G to 200Hz
Shock.....	100G
NEMA	4X

GUIDER REMOTE

INSTRUCTION TO THE USER

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- * Reorient or relocate the receiving antenna.
- * Increase the separation between the equipment and receiver.
- * Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- * Consult the dealer or an experienced radio/TV technician for help.

This equipment has been certified to comply with the limits for a class B computing device, pursuant to FCC Rules. In order to maintain compliance with FCC regulations, shielded cables must be used with this equipment. Operation with non-approved equipment or unshielded cables is likely to result in interference to radio and TV reception. The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.

THIS PAGE INTENTIONALLY LEFT BLANK



HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmoore.com

SAFETY SYSTEM

The safety system is designed to help prevent damage to the crane that would be caused by overload or two-blocking. The system consists of a load sensor, anti-two block device (optional on smaller, electric cranes), and limiting system control board.

When the applicable switch detects an overloading or two-block condition, the limiting system will prevent activation of winch up, and extend out since these directions would cause damage. Winch down, boom down, boom up, extend in, and power rotation will still function so that the crane can be moved to a safe configuration.

CAUTION!

Never de-activate or override safety functions. Doing so can result in serious damage to the crane and possibly injury or death.

LOAD SENSOR

A pressure activated switch in the elevation cylinder acts as a load sensor. This switch is normally closed and opens at the preset pressure corresponding to the load rating of the crane.

CAUTION!

The load sensor will not function when the elevation cylinder is fully retracted and is inaccurate when the boom is below horizontal.

CAUTION!

The operator must never rely strictly on the load sensor to determine overload conditions. The load and load limits must always be known and adhered to.

ANTI-TWO BLOCK

The anti-two block device (optional on smaller electric cranes), mounted on the boom crown plate, consists of a normally open switch actuated by a lever. A weight is attached to the lever and holds the switch

closed. If the weight is lifted by the hook or travel block the switch opens.

The power and signal wires are wired through the cord reel, which is in turn wired to the ATB switch.

LIMITING SYSTEM CONTROL

Two systems are included to limit crane overloads and wire rope breakage. When a crane overload occurs, the load sensor will stop winch up, extension out and boom down. To prevent breaking the wire rope, the Anti Two-Block device stops winch up and extension out when either is engaged.

The capacity of boom up is limited by the pressure setting of the relief valve in the manifold.

There is a one second delay before the deactivation of boom down when the load sensor is tripped to prevent false readings caused by pressure spikes.

MISCELLANEOUS

UP LIMIT SWITCH

The up limit switch prevents the elevation cylinder from reaching full extension. If the elevation cylinder were to "dead-head", the resulting pressure would activate the load sensor, preventing boom down. The boom would then have to be lowered using the manual operation buttons on the solenoid valves.

CIRCUIT BREAKER, FUSE

For electric cranes a 150 Amp circuit breaker is supplied with the crane. It should be installed as close to the battery as possible. For hydraulic cranes a 10 Amp blade type fuse is supplied.

DISCONNECT SWITCH

A power disconnect switch is supplied with the crane. Power to the crane should be turned off whenever not in use. This is to prevent inadvertent or unauthorized use and will help prevent corrosion at electrical connections.



HYDRAULIC SYSTEM

Sterling HYD Proportional

The hydraulic system consists of the hydraulic swivel, manifold with solenoid valves, and actuators (cylinders, motors). Hydraulic power is received from an external hydraulic source, typically a PTO driven pump attached to the vehicle transmission. The hydraulic manifold is plumbed in series and uses open center valves so that more than one function can be operated simultaneously.

SWIVEL

The hydraulic swivel is a two-port swivel that allows continuous, unlimited rotation. Refer to drawing for more information.

MANIFOLD

The hydraulic manifold contains the system relief valve, proportional flow control valve, and a directional control valve for each function.

The system relief valve prevents damage that would be caused by over pressurizing the system. It is a cartridge type valve located at the pump port of the manifold.

The proportional valve is an electrically operated flow control valve. Regulated flow is directed to the manifold while excess flow is returned to tank. Before activation, all flow is returned directly to tank, minimizing heat build up. During operation the flow is regulated proportionally to the input voltage⁽¹⁾ allowing the operator to control the speed of the crane. The valve cracks at approximately 2V and allows approximately 6-8 GPM at 6V. Depending on crane model. A screw on top of the valve is used to manually operate the valve.

(1) Technically, flow is directly proportional to amperage. Since the resistance is essentially constant, voltage is proportional to amperage. Within the accuracy required for this application, it can be said that the flow is directly proportional to the voltage.

Each hydraulically operated function is controlled by a 4 way, 3 position open center solenoid valve. It is electrically operated and spring biased to center. A manual operation feature is also incorporated.

CYLINDERS

Hydraulic cylinders are double acting cylinders with integrally mounted counterbalance valves. This valve performs 3 functions:

- Controls the rate of decent when lowering the load.
- Keeps load from falling in the event of sudden loss of system pressure, such as when a hose bursts.
- Acts as a relief valve to prevent damage from induced load or thermal expansion.

It allows free flow to extend, then blocks flow until opened by pilot pressure to the retract port or when the relief pressure is reached.

Some cylinders utilize a pilot operated check valve on the retract port to prevent the cylinder from creeping out under no load conditions. This valve allows flow into, but prevents flow from the retract port, thus hydraulically locking the cylinder until opened by pilot pressure to the extend port.

MOTORS

The hydraulic motors used by the rotation drive and hydraulic winch are high torque, low speed constant displacement motor.



MANUAL VALVE OPERATION

If electrical problems occur the proportional valve and function valves may be operated manually. Refer to the manifold drawing for valve location and directions.

To operate the crane, both the function valve and the proportional valve must be opened. If only the proportional system is not functioning, it will be easiest to manually set the proportional valve and operate the function with the pendant control. If the functions are not operating, it will be easiest to operate both the function valves and proportional valve manually.

To operate the function valves, pull the locking collar back to unlock it. The manual operation button may then be pushed or pulled depending on desired direction. The valve is spring bias to center so the function will stop when the manual operation button is released.

The proportional valve must also be opened for the crane to operate. It uses a screw type manual override that allows precise control of the speed. To set, operate a function valve, then turn knurled knob on the proportional valve counter-clockwise until the crane begins moving. Adjust until the desired speed is reached. When finished be sure to reset the valve by screwing the knob all the way in (clockwise).

CAUTION!

If the proportional valve is not reset the crane will operate without trigger input. This may result in unexpected motion of the crane, resulting in equipment damage or personal injury.

MANUAL LOWERING OF LOAD

WARNING!

The following procedure should be used in extreme cases only. Improper application of this procedure could result in injury or death.

WARNING!

The following procedure requires adjusting a safety valve. If the valve is not returned to the correct setting it may fail to hold a load, resulting in injury or death.

If hydraulic power is lost while a load is suspended, the load may be lowered by decreasing the setting on the counterbalance valve. This should only be done in extreme cases. The valve must be reset and tested before the crane is returned to normal use.

WARNING!

When the valve setting is decreased, the boom and cylinder may come down suddenly. Do not position yourself under the boom or position any part of your body between the cylinder and boom or between the cylinder and housing.

To decrease the setting, loosen the locknut on the valve, then **SLOWLY** turn the adjustment stem **CLOCKWISE** until the load begins to lower. Count the number of turns so that the valve can be immediately returned to its approximate setting.

Before the crane is returned to regular service, the valve must be precisely set and tested. Contact Liftmoore for exact setting and procedure information. The setting may be tested by lifting a known load near the moment rating.



TROUBLESHOOTING THE PROPORTIONAL SYSTEM

If no functions work or if all functions are slow when controlled by the pendant, but work correctly when the manual operation button is pressed on the proportional valve then the problem is with the proportional electronic control system.

Proportional Valve Parameters

Cracking voltage	2.6V
Full open voltage	7.75V
Coil Resistance	3.66Ω

CHECK VOLTAGE AT VALVE

Have the engine running to generate sufficient voltage (13-14V). As the trigger is pulled the valve voltage should start near zero, jump to the valve cracking voltage after slight trigger travel, increase steadily as the trigger is pulled, reaching the full open voltage.

If the voltages are correct, check the resistance across the coil. If the resistance differs significantly from the nominal resistance replace the coil.







DEUTSCH CONNECTIONS & PINS



FEMALE'S



MALE'S



THIS PAGE INTENTIONALLY LEFT BLANK


SECTION V CRANE SPECIFICATIONS MODEL 72100 CRANES

MOMENT RATING 72,000 FT-LBS

MAX SINGLE LINE LOAD 5,000 LBS

MAX DOUBLE LINE LOAD 10,000 LBS

LIFTING CAPACITIES AT VARIOUS LOAD RADII



POWERED FUNCTIONS AND EXPECTED TIMES

WINCH	UP: 14 s	DOWN: 16 s	1 REVOLUTION
BOOM ELEVATION	UP: 30 s	DOWN: 25 s	
BOOM EXTENSION	OUT: 54 s	IN: 44 s	
ROTATION	90°	11 s	

HYDRAULIC REQUIREMENTS

PRESSURE	2,900 PSI
FLOW	8 GPM

ELECTRICAL REQUIREMENTS

VOLTAGE	12 VDC
FUSE	15 AMP (REFER TO EWH DIAGRAM IN "PARTS" SECTION)
FUSE	30 AMP (REFER TO ELECTRICAL INSTALLATION IN "CRANE INSTALLATION INSTRUCTIONS" SECTION)

NOTE: FUNCTION TIMES ARE BASED ON THESE INPUT VALUES




F1285-D
07/07/21

HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmoore.com

PERIODIC MAINTENANCE SCHEDULE		
MODEL 72100 CRANES		
BOLTS		
MOUNTING BOLTS	1.25-8 GRADE 8 TORQUE DRY 1545 FT-LBS	EVERY 4 MONTHS
BEARING BOLTS	5/8-11 GRADE 8 TORQUE DRY 175 FT-LBS	EVERY 4 MONTHS
LUBRICATION		
GREASE FITTINGS	SEE DRAWING 50048	EVERY OTHER WEEK
HYDRAULIC FLUID	STANDARD Chevron AW Hydraulic Oil 46 or equivalent SAE 15 weight oil COLD WEATHER AW 32 or equivalent SAE 10 weight oil	CHECK DAILY, FILL AS NEEDED
WINCH (DINAMIC OIL A55)	HLP ISO VG 46	EVERY MONTH
ROTATION GEARBOX	Sunco Prestige 740 EP or NLGI Grade 0	EVERY MONTH
BEARING (ZERK AND TEETH)	Oil Center Research PM 600 Military grease or equivalent NGLI Grade 2 grease	EVERY 6 HOURS OF OPERATION





CRANE LUBRICATION POINTS



F1285-D
07/07/21

HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmoore.com

THIS PAGE INTENTIONALLY LEFT BLANK



F1285-D
07/07/21

HOUSTON, TEXAS
FAX: (800) 824-5559 (USA & Canada)
FAX: (713) 688-6324
PHONE: (713) 688-5533
www.liftmoore.com

LIST FOR BOX, CRANE PARTS 72100DX-30


Items with * have detailed DWG's.

P/N 29704 - BOX, CRANE PARTS 72100DX-30

- | | | |
|-----|---|------|
| 1) | P/N 29705 - MANUAL, CRANE 72100DX-30 WP..... | 1pc |
| 2) | *P/N 29145 - BLOCK, TRAV ASSY 10K lbs/9.0D..... | 1pc |
| 3) | P/N 19487 - CW, 10 GA X 300"..... | 1pc |
| 4) | P/N 18457 - FUSE HOLDER, ATO 12GA SEALED..... | 1pc |
| 5) | P/N 21154 - FUSE, 30 AMP BLADE..... | 1pc |
| 6) | P/N 32613 - ADAPTER, 8MJ-10MJ..... | 1pc |
| 7) | P/N 17012 - SWITCH, TOGGLE SPST MAINT. /S | 1pc |
| 8) | P/N 17011 - BRACKET, SWITCH MNT. HYD. CRN..... | 1pc |
| 9) | P/N 16781 - TERMINAL, RING 10-12 GA #8..... | 2pcs |
| 10) | P/N 17013 - PLATE, ON-OFF FOR TOGGLE SWCH. | 1pc |
| 11) | P/N 18600 - PLATE, CRANE-TRUCK STABILITY CHART..... | 1pc |
| 12) | P/N 23144 - LEVEL AND TAPE ASSEMBLY..... | 1pc |
| 13) | P/N 30675 - COVER, TOGGLE SWITCH..... | 1pc |
| 14) | P/N 70053 - NUT, TOGGLE SWITCH..... | 1pc |
| 15) | P/N 70054 - WASHER, LOCK TOGGLE SWITCH..... | 1pc |
| 16) | P/N 70055 - SCREW, MH FH 6-32 X 0.25..... | 2pcs |
| 17) | P/N 29410 - DECAL, LOAD CAPACITY 72,000..... | 1pc |




ITEM	PART NUMBER	DESCRIPTION	QTY	ITEM	PART NUMBER	DESCRIPTION	QTY
1	29702	BOOM-BODY ASSY 72100DXP-30	1	50	27132	SWITCH, LIMIT ATB ASSY 2W DTCH	1
2	29515	EWHT, DTCH HYD XP 72/60100 WP	1	51	32639	WASHER, LOCK #10 GR2 PLATED	2
3	29549	REEL, CORD 34 FT ASSY 4 WIRE	1	52	26852	COVER, SMALL BAIL ATB	1
4	70052	BRACKET, CORD REEL ZECA	1	53	26909	SCREW, SOC HD 10-24 X 0.37	4
5	28703	NUT, HEX NYLOC 0.25-20 SS	3	54	26910	WASHER, FLAT #10 316SS	4
6	29405	WASHER, FLAT 0.25 SS 316	3	55	23135	ADAPTER, 4FP-6FJ SWIVEL	1
7	28705	SCREW, HHC 0.25-20 X 1.00 SS	3	56	23123	PRESSURE GAUGE, 0-3000 PSI	1
8	19845	CONNECTOR, DTCH 2P RECPT	1	57	32533	ADAPTER, 90° 4MP-4FP	1
9	19848	WEDGE, DEUTSCH 2P RECPT	1	58	28794	TRANSDUCER, PRESSURE 5000 PSI	1
10	22394	PENDULUM, LOAD RADIUS DIA. HD	2	59	28963	SCREW, SOC HD 8-32 X 0.37 SS	2
11	31017	SCREW, SHOULDER 0.31-18 X 0.75	2	60	17882	WASHER, LOCK #8 GR2 PLATED	2
12	28690	WASHER, LOCK 0.25 316 SS	10	61	28853	INCLINOMETER, BOOM ANGLE CAN	1
13	34069	SCREW, HHC 0.25-20 X 0.50 SS	10	62	18310	DECAL, WARNING TAG-DO NOT EXT	1
14	32500	ADAPTER, CAPNUT #10	1	63	24062	ROPE, WIRE 0.43 X 135' W/THMBL	1
15	32499	ADAPTER, CAPNUT #8	1	64	21544	PLATE, SERIAL 72100-30	1
16	28041	SCREW, SHEAVE SINGLE 1-8 4 MAC	2	65	21546	DECAL KIT 72100X-30	1
17	30838	NUT, HEX NYLOC 1.00-8 GRADE 5	2	66	25704	TAPE, REFLECTIVE 6" WHITE/6" RED 90" LG	4
18	30936	ZERK, 0.25-28 STRAIGHT	2	67	29299	WASHER, LOCK 0.25 STAR SS	1
19	31224	COVER, ZERK 1/4	2	68	PFORM137	TEST SHEET 72100DXP-30 REV-0	1
20	24063	SHEAVE ASSY 8.09PPD X 0.43 ROPE	2	69	PFORM141	FM INSTRUCTIONS 28790, 28792	1
21	19846	WEDGE, DEUTSCH 2P PLUG	1				
22	19847	CONNECTOR, DTCH 2P PLUG	1				
23	29752	NUT, HEX NYLOC 0.50-13 SS	6				
24	21634	SCREW, HHC 0.50-13 X 8.50 GR5	2				
25	21631	ROLLER, ROPE 4064 NYLON	1				
26	29739	ROLLER, ROPE NYLON	2				
27	29751	SCREW, HHC 0.50-13 X 9.50 SS	4				
28	31948	CLIP, HAIRPIN 0.187 - 1.00	1				
29	32658	PIN, CLEVIS 0.87 X 3.50 PLATED	1				
30	24960	CLAMP, HOSE SUPPORT 0.25 ID	6				
31	26582	SCREW, SOC HD 0.25-20 X 0.37SS	6				
32	30889	WASHER, LOCK 0.25 GR5 PLATED	2				
33	17164	SCREW, SOC HD 10-24 X 0.62 SS	10				
34	25347	SCREW, SHOULDER 0.375 X 3.75	1				
35	34256	NUT, HEX NYLOC 0.31-18 SS 304	1				
36	32368	WASHER, FLAT 0.37 SAE 304SS	4				
37	33424	BUSHING, 0.37 X 0.50 X 0.50L N	5				
38	25144	LEVER, ATB ANTI-TWO BLK MACH.	1				
39	25130	SCREW, SHOULDER 0.375 X 0.625	3				
40	25152	SCREW, SHOULDER 0.313 X 2.25	1				
41	33352	WASHER, FLAT 0.25 SS	1				
42	25151	SPRING, COMPRESSION, 76LBS.	1				
43	25128	ALL THREAD STUD 3/8-24 X 5.75"	1				
44	26045	NUT, HEX 0.37-24 SS GR8	2				
45	25129	BALL JOINT ROD END	2				
46	29071	LEVER, ATB BAIL 15.3 LT MACH	1				
47	29072	LEVER, ATB BAIL 15.3" RT MACH	1				
48	25345	SPACER, LEVER	1				
49	29073	LEVER, BAIL SUPPORT 72.60 MACH	2				



FINAL ASSEMBLY VIEW

- NOTES**
- 1. - ITEMS ARE LOCATED IN FM BOX PARTS.
 - 2. - RUN CORD REEL AND INCLINOMETER WIRES THRU CLAMPS.
 - 3. - APPLY VIBRA-TITE VC-3 TO THREADS.
 - 4. - HAND TIGHT USING APPROPRIATE TOOL.
 - 5. - TORQUE TO 5 FT-LBS.
 - 6. - SEE PAGE 8 SCHEMATIC.
 - 7. - APPLY TEFLON TAPE ON THREADS.
 - 8. - INSTALL ITEMS # (66) ON TOP CORNERS OF 1ST & 2ND INNER BOOMS ON BOTH SIDES 2.75" & 1.00" RESPECTIVELY AWAY FROM THE BOOM EDGE.
 - 9. - CONNECT GROUND WIRES.
 - 10. - HAND TIGHT AND MAKE SURE SHEAVE SPINS FREELY.
 - 11. - WIRE SEQUENCE: BROWN ↔ PIN1
BLUE ↔ PIN2
 - 12. - MAKE SURE TO GREASE ALL ZERKS.
 - 13. - FROM PORT "E" ON ELEV. CYL. TO PORT "A" ON MANIFOLD.
 - 14. - FROM PORT "R" ON ELEV. CYL. TO PORT "B" ON MANIFOLD.

UNLESS SPECIFIED:		DRAWING IS THE SOLE PROPERTY OF LIFTMOORE INC. AND REPRODUCTION WITHOUT WRITTEN PERMISSION OF LIFTMOORE INC. IS PROHIBITED.	
THIRD ANGLE PROJECTION	THIRD ANGLE PROJECTION	CHECKED	JE 05/26/2021
DIM. TOLERANCES	XXX ± .005	ENG APPR.	DP 05/26/2021
ALL WELDS TO BE MINIMUM 1/4"	XXX ± .030	FRAC.	1/16
	XX ± .1°		
DRAWN: NA 05/26/2021		DWG. NO. 29703	
MIRL: SHEET 1 - 8		REV B	
WEIGHT: 3075.000 LBS.		DYNAMIC OIL PERFEC-GEAR ZECA	
LIFTMOORE INC.			
CRANE ASSY 72100DXP-30 WP			



1	28705	2X
	28690	2X
	29405	2X
	28792	2X

LIFTMOORE INC.
CRANE ASSY 72100DXP-30 WP
 DYNAMIC OIL PERFEC-GEAR, ZECA

UNLESS SPECIFIED: PROPRIETARY & CONFIDENTIAL
 DRAWING IS THE SOLE PROPERTY OF
 LIFTMOORE INC. AND REPRODUCTION
 WITHOUT WRITTEN PERMISSION OF LIFTMOORE
 INC. IS PROHIBITED.


THIRD ANGLE
 PROJECTION

CHECKED: JE 05/26/2021
 ENG APPR: DF 05/26/2021

DRAWN: JNA 05/26/2021 DWG. NO. 29703
 MTRL: SHEET 2 - 8
 WEIGHT: 3075.000 Lbs.

REV B

STEP 1



STEP 2

UNLESS SPECIFIED
 MACHINED PART
 MINIMUM .250 RMS
 ALL WELDS TO BE
 MINIMUM 1/4"
 DIM. TOLERANCES
 .XXX ± .005
 .XX ± .030
 .X ± .116
 FRACTION ± 1/16
 XX° ± .5°

THIRD ANGLE PROJECTION

CHECKED JE 05/26/2021
 ENG APPR DF 05/26/2021

PROPRIETARY & CONFIDENTIAL
 DRAWING IS THE SOLE PROPERTY OF
 LIFTMOORE INC. AND REPRODUCTION
 WITHOUT WRITTEN PERMISSION OF LIFTMOORE
 INC. IS PROHIBITED.

DRAWN INA 05/26/2021
 MTRL: SHEET 3 - 8
 WEIGHT: 3075.000 Lbs

LIFTMOORE INC.
 CRANE ASSY 72100DXP-30 WP
 DYNAMIC OIL PERFEC-GEAR ZECA


BY INA 05/26/2021 REV B

REV B
 29703
 SOLIDWORKS

DESC: Corrected wiring schematic wiring, winch & elevation.

STEP 3

ATB ASSEMBLY



UNLESS SPECIFIED:
 PROPRIETARY & CONFIDENTIAL
 MACHINED PART
 MINIMUM 250 RMS
 ALL WELDS TO BE
 MINIMUM 1/4"
 DIM. TOLERANCES
 .XXX ± .005
 .XX ± .030
 .X ± .116
 FRAC. ± .116
 XX° ± .5°

THIRD ANGLE
 PROJECTION

CHECKED: JE
 DATE: 05/26/2021

ENG APPR: DP
 DATE: 05/26/2021

DRAWN: JNA
 DATE: 05/26/2021

MTRL: SHEET 4 - 8
 DWG. NO.: 29703

WEIGHT: 3075.000 LBS


DYNAMIC OIL PERFEC-GEAR, ZECA

CRANE ASSY 72100DXP-30 WP


LIFTMOORE INC.

BY	JNA	05/26/2021	REV	B
DESC: Corrected wiring schematic wiring, winch & elevation.				
DYNAMIC OIL PERFEC-GEAR, ZECA				
CRANE ASSY 72100DXP-30 WP				
LIFTMOORE INC.				
WEIGHT: 3075.000 LBS				
DWG. NO.: 29703				
MTRL: SHEET 4 - 8				
DATE: 05/26/2021				
DYNAMIC OIL PERFEC-GEAR, ZECA				
REV B				

STEP 4-b



STEP 4-a



UNLESS SPECIFIED
 MACHINED PART
 MINIMUM 250 RMS
 ALL WELDS TO BE
 MINIMUM 1/4"
 DIM. TOLERANCES
 .XXX ± .005
 .XX ± .030
 .X ± .116
 FRAC. ± 1/16
 XX° ± .5°

THIRD ANGLE PROJECTION



CHECKED JE 05/26/2021
 ENG APPR. DF 05/26/2021

PROPRIETARY & CONFIDENTIAL
 DRAWING IS THE SOLE PROPERTY OF
 LIFTMOORE INC. AND REPRODUCTION
 WITHOUT WRITTEN PERMISSION OF LIFTMOORE
 INC. IS PROHIBITED.

LIFTMOORE INC.
 CRANE ASSY 72100DXP-30 WP
 DYNAMIC OIL PERFEC-GEAR ZECA

DRAWN: NA 05/26/2021 DWG. NO. 29703
 MRL: SHEET 5 - 8
 WEIGHT: 3075.000 Lbs

REV B



ELEV. CYL. HOSES LAYOUT


UNLESS SPECIFIED		PROPRIETARY & CONFIDENTIAL	
MACHINED PART		DRAWING IS THE SOLE PROPERTY OF	
MINIMUM .250 RMS		LIFTMOORE INC. AND REPRODUCTION	
ALL WELDS TO BE		WITHOUT WRITTEN PERMISSION OF LIFTMOORE	
MINIMUM 1/4"		INC. IS PROHIBITED.	
DIM. TOLERANCES		THIRD ANGLE	
.XXX ± .005		PROJECTION	
.XX ± .030		CHECKED JE 05/24/2021	
FRAC. ± 1/16		ENG APPR: DP 05/24/2021	
XX° ± .5°			

LIFTMOORE INC.		CRANE ASSY 72100DXP-30 WP	
DYNAMIC OIL PERFEC-GEAR ZECA		DRAWN: NA 05/26/2021 DWG. NO.	
MIRL: SHEET 6 - 8		REV: B	
WEIGHT: 3075.000 Lbs.		29703	


DISC: Corrected wiring schematic wiring, winch & elevation.

BY: NA 05/24/2021 REV: B

DECALS ARE LOCATED IN ITEM # 65 P/N 21546 - DECAL KIT 72100X-30



DECALS



DECALS

UNLESS SPECIFIED:
 MACHINED PART
 MINIMUM .250 RMS
 ALL WELDS TO BE
 MINIMUM 1/4"
 DIM. TOLERANCES
 .XXX ± .005
 .XX ± .030
 FRACTIONS ± 1/16
 XX° ± .5°

THIRD ANGLE
 PROJECTION
 CHECKED: JE 05/24/2021
 ENG APPR: DP 05/24/2021

PROPERTY & CONFIDENTIAL
 DRAWING IS THE SOLE PROPERTY OF
 LIFTMOORE INC. AND REPRODUCTION
 WITHOUT WRITTEN PERMISSION OF LIFTMOORE
 INC. IS PROHIBITED.

DRAWN: NA 05/26/2021
 MTRL: SHEET 7 - 8
 WEIGHT: 3075.000 Lbs


DYNAMIC OIL PERFEC-GEAR, ZECA
 CRANE ASSY 72100DXP-30 WP

LIFTMOORE INC.

DESC: Corrected wiring schematic, wiring, winch & elevation.

BY: NA 05/24/2021 REV: B

REV: B
 29703



UNLESS SPECIFIED
 PROPRIETARY & CONFIDENTIAL
 MACHINED PART
 MINIMUM 250 RMS
 ALL WELDS TO BE
 MINIMUM 1/4"
 DIM. TOLERANCES
 .XXX ± .005
 .XX ± .030
 .X ± .1/16
 FRAC. ± .1/16
 XX° ± .5°

THIRD ANGLE
 PROJECTION
 CHECKED JE 05/24/2021
 ENG APPR. DP 05/24/2021


CRANE ASSY 72100XP-30 WP
 DYNAMIC OIL PERFEC-GEAR, ZECA
 DWG. NO. 05/26/2021
 SHEET 8 - 8
 WEIGHT: 3075.000 Lbs.

LIFTMOORE INC.

NOTES

- 1 - USE IMPACT GUN SET ON SETTING 2 W/115 PSI TO TIGHTEN, CHECK TO MAKE SURE SCREWS CAN BE TURNED WITH A WRENCH AFTER TIGHTENING TO AVOID OVER TIGHTENING.
- 2 - TORQUE TO 5 FT.-LBS.
- 3 - COVER LEFT LOOSE
- 4 - DO NOT INSTALL ELEVATION HOSES, TO BE INSTALLED IN FINAL ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY
1	29699	BOOM ASSEMBLY 72100DXP-30	1
2	29701	BODY ASSEMBLY 72100/60100 DXP	1
3	19802	CYLINDER ASSY 72100 ELEV DTCH	1
4	19775	SCREW, HHC 1.50-6 X 12.00 GR8	3
5	31293	NUT, HEX NYLOC 1.50-6 GRADE 8	3
6	23051	HORN, 108 DB	1
7	29405	WASHER, FLAT 0.25 SS 316	1
8	28690	WASHER, LOCK 0.25 316 SS	1
9	34069	SCREW, HHC 0.25-20 X 0.50 SS	1
10	19822	COVER, BACK 72100 METAL	1
11	PFORM16	CHECKLIST FORM	1



LIFTMOORE INC.
BOOM-BODY ASSY 72100DXP-30

UNLESS SPECIFIED: MACHINED PART MINIMUM 250 RMS ALL WELDS TO BE MINIMUM 1/4" DIM. TOLERANCES: .XXX ± .005 .XX ± .030 .X ± .1/16 XX° ± .5°


PROPERTY & CONFIDENTIAL DRAWING IS THE SOLE PROPERTY OF LIFTMOORE INC. AND REPRODUCTION WITHOUT WRITTEN PERMISSION OF LIFTMOORE INC. IS PROHIBITED.

THIRD ANGLE PROJECTION

CHECKED: JE 04/30/2021
 ENG APPR: DP 05/03/2021

DRAWN: JNA 04/30/2021 | DWG. NO. 29702
 MTRL: SHEET 1 - 2
 WEIGHT: 2955.367 Lbs

REV B



WINCH : PORT D
MANIFOLD : TANK

WINCH : PORT V2
MANIFOLD : PORT A

EXT. CYL. : PORT E
MANIFOLD : PORT A

WINCH : PORT V1
MANIFOLD : PORT B

EXT. CYL. : PORT R
MANIFOLD : PORT B

**WINCH HOSES
LAYOUT**

WINCH : PORT V2
MANIFOLD : PORT A

WINCH : PORT V1
MANIFOLD : PORT B

EXT. CYL. : PORT E
MANIFOLD : PORT A

EXT. CYL. : PORT R
MANIFOLD : PORT B

**EXT. CYL. HOSES
LAYOUT**

WINCH : PORT D
MANIFOLD : TANK

**MANIFOLD - HOSES LAYOUT
INSIDE BODY VIEW**

UNLESS SPECIFIED
MACHINED PART
MINIMUM 250 RMS
ALL WELDS TO BE
MINIMUM 1/4"
DIM. TOLERANCES
XXX ± .005
.XX ± .030
FRACTION ± 1/16
XX° ± .5°

PROPRIETARY & CONFIDENTIAL
DRAWING IS THE SOLE PROPERTY OF
LIFTMOORE INC. AND REPRODUCTION
WITHOUT WRITTEN PERMISSION OF LIFTMOORE
INC. IS PROHIBITED.


THIRD ANGLE
PROJECTION

CHECKED JE 04/30/2021
ENG APPR DF 05/03/2021

<p>LIFTMOORE INC.</p> <p>BOOM-BODY ASSY 72100DXP-30</p>		<p>DRAWN INA 04/30/2021</p>	<p>REV B</p>
		<p>MIRL SHEET 2 - 2</p>	<p>29702</p>
		<p>DWG. NO.</p>	<p>WEIGHT: 2955.367 Lbs</p>

P.O. CHECK VALVE

COUNTER BALANCE VALVE





REPLACEMENT PARTS FOR CYLINDER	
DESCRIPTION	PART NUMBER
SEAL KIT	TM*SK-00934
COUNTERBALANCE VALVE	TM*PP-00184
P.O. CHECK VALVE	TM*PP-00394

P/N 31412
HOSE, HYD #6 36.00"
2 PLCS

P/N 31408
WRAP, 3/4" BLACK SPIRAL CUT

P/N 31135
2 PLCS


SWITCH, PRES ASSY DTCH
(NOT PART OF ASSEMBLY)




P/N 20004
ZERK, 0.12 NPT 90°

P/N 31224
COVER, ZERK 1/4

P/N 19668
CYLINDER, 6.0 X 28.0 X 3.0



Houston TX
(713)-688-5533
www.liftmoore.com




CYLINDER ASSY 72100 ELEV LS

DRWN BY: JC
DATE: 01/03/08

DRAWING NO.

19802-D

ITEM	PART NUMBER	DESCRIPTION	QTY
1	29700	BASE-HOUSING ASSY 72100DXP	1
2	29725	MANIFOLD ASSY 72/60100 DTCH	1
3	30473	WASHER, LOCK 0.37 GR5 PLATED	4
4	30813	SCREW, HHC 0.37-16 X 1.00 GR8	4
5	29720	TUBE, HYD ROT 72100/60100 (A)	1
6	29721	TUBE, HYD ROT 72100/60100 (B)	1
7	25788	TUBE, HYD 72100 TANK UPPER	1
8	25787	TUBE, HYD 72100 TANK LOWER	1
9	25786	TUBE, HYD 72100/60100 PRESSURE	1
10	20863	ADAPTER, TEE 8MJ-8MJ-8MJ	1
11	20864	ADAPTER, 6MJ-8FJ	1
12	20413	SWITCH, LIMIT UP 2WNC-22 DTCH	1
13	33126	SCREW, MH RD 6-32 X 1.25	2
14	31124	WASHER, LOCK #6 GR2 PLATED	2
15	33606	WASHER, FLAT #6 GR2 PLATED	2
16	31123	NUT, HEX 6-32 GR2 PLATED	2
17	19916	CONNECTOR, DTCH 1P PLUG	1
18	29407	SCREW, SOC HD 0.25-20 X 0.63SS	1
19	28690	WASHER, LOCK 0.25 316 SS	1
20	24923	ADAPTER, TEE 8MJ-6MJ-8FJX	1



NOTES:

- 1 - TORQUE TO 20 FT.-LBS.
- 2 - HAND TIGHT WITH FLAT SCREW DRIVER
- 3 - TORQUE TO 5 FT.-LBS.

UNLESS SPECIFIED:
 MACHINED PART
 MINIMUM 250 RMS
 ALL WELDS TO BE
 MINIMUM 1/4"
 DIM. TOLERANCES
 .XX ± .005
 .XX ± .030
 FRAC. ± 1/16
 XX° ± .5°

THIRD ANGLE
 PROJECTION
 CHECKED JE 07/07/2021
 ENG APPR DF 07/07/2021


PROPRIETARY & CONFIDENTIAL
 DRAWING IS THE SOLE PROPERTY OF
 LIFTMOORE INC. AND REPRODUCTION
 WITHOUT WRITTEN PERMISSION OF LIFTMOORE
 INC. IS PROHIBITED.

BY NA 07/07/2021 REV B

DRAWN NA 07/07/2021 DWG. NO.
 MTRL: SHEET 1 - 2
 WEIGHT: 764.176 lbs

REV B
 29701

LIFTMOORE INC.
 BODY ASSEMBLY 72100/60100 DXP



NOTES:

- ① - TORQUE TO 20 FT.-LBS.
- ② - HAND TIGHT WITH FLAT SCREW DRIVER
- ③ - TORQUE TO 5 FT.-LBS.

DETAIL C
SCALE 1 : 4

DETAIL B
SCALE 1 : 4

DETAIL A
SCALE 1 : 4



UNLESS SPECIFIED		PROPRIETARY & CONFIDENTIAL	
MACHINED PART		DRAWING IS THE SOLE PROPERTY OF	
MINIMUM .250 RMS		LIFTMOORE INC. AND REPRODUCTION	
ALL WELDS TO BE		WITHOUT PERMISSION OF LIFTMOORE	
MINIMUM 1/4"		INC. IS PROHIBITED.	
DIM. TOLERANCES		THIRD ANGLE	
.XXX ± .005		PROJECTION	
.XX ± .030		CHECKED JE 07/07/2021	
FRAC. ± 1/16		ENG APPR DF 07/07/2021	
XX° ± .5°		DRAWN INA 07/07/2021	
		DWG. NO. 29701	
		SHEET 2 - 2	
		REV B	

LIFTMOORE INC.

BODY ASSEMBLY 72100/60100 DXP

REV	B
DWG. NO.	29701
SHEET 2 - 2	
DATE	07/07/2021
WEIGHT	764.176 LBS

ITEM	PART NUMBER	DESCRIPTION	QTY
1	24993	MANIFOLD PRE-ASSY XP DTCH	1
2	31063	ADAPTER, 6MJ-6MO	2
3	31513	ADAPTER, 90° 6MJ-6FJX	4
4	31908	ADAPTER, 8MJ-8MO X 1.48	4
5	32547	ADAPTER, 90° 8FJX-8MJ	3
6	30898	ADAPTER, 6MJ-8MO	3
8	20864	ADAPTER, 6MJ-8FJ	1
9	32204	ADAPTER, 90° 8MJ-8MO	1



NOTES

- 1 - 4X P/N 24432 VALVE, 4W/3P/12V/OC DTCH - OPEN CENTER VALVES (12X P/N 30956 SCREW, SOC HD 10-24 X 2.00 GR5)
- 2 - HAND TIGHT (LEAVE LOOSE TO BE ADJUSTED IN FUTURE ASSEMBLIES)
- 3 - TIGHTEN

UNLESS SPECIFIED:
 MACHINED PART
 MINIMUM 250 RMS
 ALL WELDS TO BE
 MINIMUM 1/4"

DIM. TOLERANCES
 .XXX ± .005
 .XX ± .030
 FRACTIONS ± 1/16
 XX° ± .5°

THIRD ANGLE PROJECTION


CHECKED: JE 04/14/2021
 ENG APPR: DF 04/14/2021

PROPRIETARY & CONFIDENTIAL
 DRAWING IS THE SOLE PROPERTY OF
 LIFTMOORE INC. AND REPRODUCTION
 WITHOUT WRITTEN PERMISSION OF LIFTMOORE
 INC. IS PROHIBITED.

MANIFOLD ASSY 72/60100 DTCH
 WIDELSTICH VALVES.

DRAWN: INA 04/14/2021 DWG. NO.
 MRL: SHEET 1-1
 WEIGHT: 32.672 Lbs


REV A
 29725



**1- ON THE SIDE OF THE VALVE MAKE SURE
A IS ON TOP & B ON THE BOTTOM.**

2- INSTALL 4 VALVES P/N 24432 4W/3P/12V/IOC DTCH

NOTES



Houston TX
(713)-688-5533
www.liftmoore.com

DRWN BY: JE
DATE: 6/4/12

MANIFOLD PRE-ASSY XP DTCH


DRAWING NO.

24993-C



NOTES:

- 1 - TORQUE TO 170 FT-LBS.
- 2 - TORQUE TO 65 FT-LBS.
- 3 - TORQUE TO 28 FT-LBS.
- 4 - TORQUE TO 11 FT-LBS.
- 5 - TORQUE TO 5 FT-LBS.
- 6 - TORQUE TO 2 FT-LBS. & DO NOT OVERTIGHTEN
- 7 - RUN WIRE THRU CONNECTOR.
- 8 - APPLY LOC-TITE VC-3 TO THREADS.
- 9 - APPLY LOC-TITE 565 TO THREADS
- 10 - ADD TEFLON TAPE
- 11 - ADD SILICONE AROUND ITEM # (36)
- 12 - ADD MILITARY GREASE TO GEAR TEETH
- 13 - USE EXISTING HARDWARE
- 14 - TIGHTEN WITH WRENCH
- 15 - RUN WIRE THRU ITEM# (34)
- 16 - WHEN LINING UP GREASE ZERK TO HOUSING MAKE SURE WEEP HOLE IS FACING THE FRONT OF BODY.



FRONT SIDE OF BODY

ITEM	PART NUMBER	DESCRIPTION	QTY
1	19638	PLATE, BASE 72100	1
2	21178	HOUSING WELDMENT 72100	1
3	19687	BEARING, GEAR 72100 GP	1
4	31100	SCREW, HHC 0.62-11 X 2.25 GR8	16
5	31054	WASHER, FLAT 0.62 SAE GR8	36
6	30867	SCREW, SOC HD 0.62-11 X 2.25	4
7	19766	SCREW, HHC 0.62-11 X 3.50 GR8	20
8	29116	REDUCER, SPEED P GEAR 14 TOOTH	1
9	27332	RING, ECCENTRIC PERFECTION GEA	1
10	17473	O-RING, 155 BUNA 70 DUROMETER	1
11	17472	O-RING, 158 BUNA 70 DUROMETER	1
12	29282	SPACER, SPEED REDUCER 4075/4064	2
13	19323	WASHER, FLAT 0.50 SAE GR8	4
14	30474	WASHER, LOCK 0.50 GR5 PLATED	4
15	30455	SCREW, HHC 0.50-13 X 2.75 GR8	4
16	27858	GROMMET, RUBBER 0.875" I.D.	2
17	27990	PLATE, GROMMET HOLDER - MACH	2
18	30889	WASHER, LOCK 0.25 GR5 PLATED	16
19	30457	SCREW, HHC 0.25-20 X 0.75 GR5	4
20	19719	COVER, GEAR 72100	1
21	30809	SCREW, HHC 0.25-20 X 0.50 GR5	12
22	19720	COVER, GEAR PINION 72100	1
23	23389	PLATE, SERIAL NO. MACHINING	1
24	22406	SCREW, DRIVE	2
25	18263	PROTECTOR, SWIVEL SLOTTED WELD	1
26	30888	WASHER, FLAT 0.31 GR5 PLATED	7
27	30458	SCREW, HHC 0.31-18 X 0.75 GR5	3
28	28145	SWIVEL, HYD/ELEC ASSY 4064	1
29	31713	SPACER, HYD SWIVEL SUPPORT	2
30	26163	PLATE, SWIVEL MOUNT SLIDE MACH	1
31	30890	WASHER, LOCK 0.31 GR5 PLATED	2
32	31096	SCREW, HHC 0.31-18 X 1.25 GR5	2
33	18714	CONNECTOR, CGB 0.25NPT 0.20	1
34	20877	ADAPTER, 90° 2FP-2MP	1
35	19824	ZERK, 0.12 NPT STRAIGHT X 2.62	1
36	31224	COVER, ZERK 1/4	1
37	28835	WIRE, GROUND #6 X 96" W/TRM	1
38	30459	SCREW, HHC 0.37-16 X 0.75 GR8	1
39	30473	WASHER, LOCK 0.37 GR5 PLATED	1
40	31500	ADAPTER, 90° 6MJ-10MO	1
41	27344	ADAPTER, 6FO-10MO	1
42	33506	ADAPTER, 90° LL 6MJ-6MOL	1

PROPRIETARY AND CONFIDENTIAL
 INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF LIFTMOORE INC.
 REPRODUCTION IN ANY MANNER WITHOUT THE WRITTEN PERMISSION OF LIFTMOORE INC. IS PROHIBITED.

MACH. PART TO BE A MINIMUM 250 RMS UNLESS SPECIFIED
 DEFAULT TOLERANCES UNLESS SPECIFIED:
 .XX ± .005
 .X ± .030
 .X ± .100
 .XX ± .5
 .X ± .1/16

CHECKED: JE DATE: 04/27/2021
 ENG APPR: DP DATE: 04/27/2021


DRAWN: JNA DATE: 04/27/2021
 MTRL: SHEET 1 - 4
 WEIGHT: 726.184 LBS

LIFTMOORE INC.
 BASE-HOUSING ASSY 72100DXP
 PERFECTION GEAR SPEED REDUCER

REV B
 29700

BY: JNA	DATE: 04/27/2021	REV: B
---------	------------------	--------


DESC:




PROPRIETARY AND CONFIDENTIAL		MACH. PART TO BE A MINIMUM 250 RMS UNLESS SPECIFIED	
CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF LIFTMOORE INC.		DEFAULT TOLERANCES UNLESS SPECIFIED:	
REPRODUCTION IN WHOLE OR IN PART WITHOUT THE WRITTEN PERMISSION OF LIFTMOORE INC. IS PROHIBITED.		XX ± .030	
		X ± .100	
		FRAC ± 1/16	
		XX ± .5	
CHECKED	JE	04/27/2021	DP
ENG APPR	DP	04/27/2021	DP
DRAWN		NA	04/27/2021
MTRL		SHEET 2 - 4	
REV		29700	
DWG. NO.		29700	
WEIGHT		726.184 Lbs	

LIFTMOORE INC.
BASE-HOUSING ASSY 72100DXP
 PERFECTION GEAR SPEED REDUCER


BY NA 04/27/2021 REV B
 DISC.




DETAIL C/STEP 6



BOTTOM ISO VIEW



DETAIL B/STEP 4



FRONT ISO VIEW

BOTTOM ISO/STEP 5

PROPRIETARY AND CONFIDENTIAL INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF LIFTMOORE INC. REPRODUCTION IN WHOLE OR IN PART WITHOUT THE WRITTEN PERMISSION OF LIFTMOORE INC. IS PROHIBITED.



MACH. PART TO BE A MINIMUM 250 RMS UNLESS SPECIFIED
 DEFAULT TOLERANCES UNLESS SPECIFIED:
 .XX ± .005
 .X ± .030
 .X ± .100
 FRACTION ± 1/16
 XX ± .5
 CHECKED: JE DATE: 04/27/2021
 ENG APPR: DP DATE: 04/27/2021

LIFTMOORE INC.

BASE-HOUSING ASSY 72100DXP
 PERFECTION GEAR SPEED REDUCER

DRAWN: N/A DATE: 04/27/2021
 MTRL: SHEET 3 - 4
 WEIGHT: 726.184 Lbs

REV B
 29700



BACK ISO/STEP 7

ISO VIEW/STEP 8

ISO VIEW/STEP 9

LIFTMOORE INC.

BASE-HOUSING ASSY 72100DXP
PERFECTION GEAR SPEED REDUCER

PROPRIETARY AND CONFIDENTIAL INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF LIFTMOORE INC. REPRODUCTION IN WHOLE OR IN PART OR AS A GUIDE FOR THE FABRICATION OF SIMILAR PARTS WITHOUT THE WRITTEN PERMISSION OF LIFTMOORE INC. IS PROHIBITED.


MACH. PART TO BE A MINIMUM 250 RMS UNLESS SPECIFIED
DEFAULT TOLERANCES UNLESS SPECIFIED:
XX ± .005
X ± .030
± .100
FRAC: ± 1/16
XX ± .5"

CHECKED	JE	04/27/2021
ENG APPR	DP	04/27/2021

DRAWN	INA	04/27/2021
MTRL		SHEET 4 - 4
WEIGHT		726.184 Lbs

REV	B
29700	

NOTE: ATTACH MOUNTING BOLTS AND LOCK WASHER TO SWIVEL WITH TAPE ITEM # 25 & 26.



#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY	#	PN	DESCRIPTION	QTY
1	34256	NUT, HEX NYLOC 0.31-18 SS 304	1	10	28144	SWIVEL, HYDRAULIC 1/2" PORTS CTB	1	19	31451	INSULATOR, BOLT ELECTRIC	1
2	32278	WIRE, SWIVEL SUPPLY W/TERMINAL	1	11	31382	SPACER, SWIVEL STUD INSULATOR	1	20	31995	ADAPTER, 8FP-8MJ	3
3	34255	NUT, HEX 0.31-18 SS 304	1	12	31381	SPACER, SWIVEL UPPER - BRONZE	1	21	23063	SCREW, HHC 0.37-16 X 1.25 GR8	1
4	33353	WASHER, FLAT 0.31 SAE SS304	1	13	30674	BOOT, RUBBER 1 & 1/0	1	22	32368	WASHER, FLAT 0.37 SAE SS GR304	1
5	32277	STUD, 5/16-18 X 6 DOUBLE END	1	14	22238	ADAPTER, NIPPLE 4.50" LG #8	1	23	34256	NUT, HEX NYLOC 0.31-18 SS 304	1
6	32468	ADAPTER, 8FP-10MJ	1	15	32112	ADAPTER, NIPPLE 6.00" LG #8	1	24	32279	SLEEVE, SWIVEL SCREW INSULATOR	1
7	31383	SPACER, SWIVEL STUD INSULATOR	1	16	20500	WIRE, SWIVEL HOT PLATE ASSY D	1	25	28146	SCREW, HHC 0.37-16 X 5.50 GR8	2
8	31996	ADAPTER, NIPPLE 2.50" LG #8	1	17	32562	WASHER, FLAT 0.50 SS GRADE 304	1	26	30473	WASHER, LOCK 0.37 GR5 PLATED	2
9	32321	ADAPTER, NIPPLE 4.00" LG #8	1	18	31452	SPRING, SWIVEL	1				

Houston TX
(713)-688-5533
www.liftmoore.com

DRWN BY: JE


DATE: 8/11/16

SWIVEL, HYD/ELEC ASSY SHORT CTB

COUNTER BORE MOUNTING HOLES

DRAWING NO. **28145-0**

ITEM	PART NUMBER	DESCRIPTION	QTY
1	29698	BOOM, OUTER ASSY 72100DXP-30	1
2	29737	BOOM, INNER ASSY 72100DXP-30	1
3	19833	PIN, TEARDROP 1.00 X 8.00	1
4	30459	SCREW, HHC 0.37-16 X 0.75 GR8	1
5	30473	WASHER, LOCK 0.37 GR5 PLATED	1
6	25693	PLATE, MOUNT SIDE WEAR PAD	2
7	30813	SCREW, HHC 0.37-16 X 1.00 GR8	8
8	33436	WASHER, LOCK 0.37 GR5 PLT I.T.	8
9	25691	PAD, NYLON 0.750 X 1 X 4 TAP	2
10	25692	PAD, NYLON 1" X 4" X 4" TAP	1
11	30655	SCREW, HHC 0.50-13 X 1.50 GR8	2
12	19323	WASHER, FLAT 0.50 SAE GR8	2
13	25706	PLATE, MOUNT BOTTOM WEAR PAD	1
14	31425	SCREW, HHC 0.50-13 X 1.25 GR8	4
15	30474	WASHER, LOCK 0.50 GR5 PLATED	6
16	33367	SCREW, EYE 0.25-20 W/ NUT	5
17	30812	SCREW, HHC 0.37-16 X 1.25 GR8	1
18	30467	NUT, HEX 0.37-16 GR2 PLATED	1



ISO VIEW

NOTES

- 1 - ADD VIBRA-TITE VC-3 TO THREADS AND SET TORQUE TO 10 FT-LBS.
- 2 - ADD VIBRA-TITE VC-3 TO THREADS AND SET TORQUE TO 30 FT-LBS.
- 3 - ADD VIBRA-TITE VC-3 TO THREADS AND SET TORQUE TO 70 FT-LBS.
- 4 - HAND TIGHT.

UNLESS SPECIFIED:
 MACHINED PART
 MINIMUM 250 RMS
 ALL WELDS TO BE
 MINIMUM 1/4"
 DIM. TOLERANCES
 .XXX ± .005
 .XX ± .030
 FRACTIONS ± 1/16
 XX° ± .5°

THIRD ANGLE PROJECTION
 THIRD ANGLE PROJECTION
 CHECKED: JE 04/14/2021
 ENG APPR: DF 04/14/2021

PROPRIETARY & CONFIDENTIAL
 DRAWING IS THE SOLE PROPERTY OF
 LIFTMOORE INC. AND REPRODUCTION
 WITHOUT WRITTEN PERMISSION OF LIFTMOORE
 INC. IS PROHIBITED.

DRAWN: JNA 04/14/2021 DWG. NO.
 MTRL: SHEET 1 - 2
 WEIGHT: 1916.328 Lbs.

BY: NA 04/14/2021 REV. A

LIFTMOORE INC.



BOOM ASSEMBLY 72100DXP-30

REV A
 SHEET 1 - 2
 29699


NOTES

- 1 - ADD VIBRA-TITE VC-3 TO THREADS AND SET TORQUE TO 10 FT.-LBS.
- 2 - ADD VIBRA-TITE VC-3 TO THREADS AND SET TORQUE TO 30 FT.-LBS.
- 3 - ADD VIBRA-TITE VC-3 TO THREADS AND SET TORQUE TO 70 FT.-LBS.
- 4 - HAND TIGHT.

DETAIL A



ASSEMBLY STEPS



DETAIL B

UNLESS SPECIFIED
 MACHINED PART
 MINIMUM 250 RMS
 ALL WELDS TO BE
 MINIMUM 1/4"

PROPRIETARY & CONFIDENTIAL
 DRAWING IS THE SOLE PROPERTY OF
 LIFTMOORE INC. AND REPRODUCTION
 WITHOUT WRITTEN PERMISSION OF LIFTMOORE
 INC. IS PROHIBITED.

THIRD ANGLE
 PROJECTION

CHECKED: JE 04/14/2021
 ENG APPR: DP 04/14/2021

DWG. NO. 04/14/2021
 SHEET 2 - 2
 WEIGHT: 1916.328 Lbs

LIFTMOORE INC.



BOOM ASSEMBLY 72100DXP-30

REV	A
29699	
DWG. NO.	04/14/2021
SHEET	2 - 2
WEIGHT	1916.328 Lbs

BY	NA	04/14/2021	REV	A
----	----	------------	-----	---

DESC.

ITEM	PART NUMBER	DESCRIPTION	QTY
1	29697	BOOM, OUTER 72100XP-30 WELD	1
2	29472	WINCH, HYD. DYNAMIC OIL A55	1
3	19323	WASHER, FLAT 0.50 SAE GR8	4
4	19571	SCREW, HHC 0.50-13 X 2.25 GR8	4
5	20866	ADAPTER, 8MJ-8MJ BH	2
6	30477	WASHER, FLAT 0.75 GR5 SAE PL.	2
7	20849	ADAPTER, 6MJ-6MJ BH W/ NUT	1
8	32547	ADAPTER, 90° 8FJX-8MJ	3
9	29234	ADAPTER, 1/4NPT-1/4BSPP	1
10	30893	ADAPTER, 90° 4MP-6MJ	1
11	31513	ADAPTER, 90° 6MJ-6FJX	1
12	31911	ADAPTER, 90° 8MJ-10MO	2
13	29726	TUBE, HYD WINCH 72100 RIGHT	1
14	29727	TUBE, HYD WINCH 72100 LEFT	1
15	29728	TUBE, HYD WINCH 72100 DRAIN	1
16	33481	BUSHING, 1.50 X 1.75 X 1.50L N	2
17	30936	ZERK, 0.25-28 STRAIGHT	1
18	33920	PLUG, BOOM HOLE 1.375 PLASTIC	2
19	20808	HOSE, HYD #6 34.00" 45°-ST	1
20	20034	HOSE, HYD #8 36.00" 90°-ST	1
21	20035	HOSE, HYD #8 36.00" 90°L-ST	1
22	31408	WRAP, 3/4" BLACK SPIRAL CUT 40" LG	3



UNLESS SPECIFIED:
 MACHINED PART
 MINIMUM 250 RMS
 ALL WELDS TO BE
 MINIMUM 1/4"

DIM. TOLERANCES
 .XX ± .005
 .XX ± .030
 FRACTIONS ± 1/16
 XX° ± .5°

THIRD ANGLE PROJECTION

CHECKED: JE 04/30/2021
 ENG APPR: DP 05/03/2021

DRAWN: JNA 04/30/2021
 MTRL: SHEET 1-1
 DWG. NO. 29698

LIFTMOORE INC.
 BOOM, OUTER ASSY 72100DXP-30
 DYNAMIC OIL A55


REV B

- NOTES**
- 1 - ADD VIBRA-TITE VC-3 TO THREADS AND SET TORQUE TO 70 FT-LBS.
 - 2 - ADD TEFLON TAPE TO BOTTOM THREADS
 - 3 - CONNECT HOSE (ITEM# 19) FROM BOTTOM FITTING (DRAIN) TO THE TEE FITTING
 - 4 - CONNECT HOSE (ITEM# 20) TO TOP FRONT FITTING (PORT V2 ON THE WINCH)
 - 5 - CONNECT HOSE (ITEM# 21) TO TOP BACK FITTING (PORT V1 ON THE WINCH)
- DISC: CHANGED NOTES 4 & 5

ITEM	PART NUMBER	DESCRIPTION	QTY
1	29736	BOOM, INNER 1ST 72100XP-30 WLD	1
2	29065	BOOM, INNER 2ND 72100XP-30 WLD	1
3	21547	CYLINDER ASSY 72100XP-30 EXT	1
4	27681	SCREW, SOC HD 0.37-16 X 1.00	8
5	19715	PAD, NYLON 0.260 X 6 X 7.5 CSK	1
6	20396	PAD, NYLON 0.20 X 6 X 2 CSK	2
7	34032	PAD, NYLON 0.20 X 4 X 3.62 CSK	2
8	33614	SCREW, SOC FH 0.25-20 X 0.50	20
9	18046	CS, 1.00 DIA X 5.25	1
10	30692	RING, SNAP 1" INTERNAL CS	2
11	25693	PLATE, MOUNT SIDE WEAR PAD	2
12	25691	PAD, NYLON 0.750 X 1 X 4 TAP	3
13	33436	WASHER, LOCK 0.37 GR5 PLT I.T.	14
14	30813	SCREW, HHC 0.37-16 X 1.00 GR8	8
15	29714	PLATE, SPACER 0.50" BOOM PC	1
16	29717	PLATE, MOUNT BOTTOM WEAR PAD	1
17	30861	SCREW, HHC 0.37-16 X 1.50 GR8	2
18	30812	SCREW, HHC 0.37-16 X 1.25 GR8	4

ITEM# 3 CYLINDER ASSEMBLY

ITEM	PART NUMBER	DESCRIPTION	QTY
3-A	19667	CYLINDER, 3.0 X 156.0 X 2.00	1
3-B	31063	ADAPTER, 6MJ-6MO	2
3-C	31412	HOSE, HYD #6 36.00"	2
3-D	31408	WRAP, 3/4" BLACK SPIRAL CUT	84



DETAIL A

- NOTES**
- 1 -ADD VIBRA-TITE VC-3 TO THREADS AND SET TORQUE TO 12 FT.-LBS.
 - 2 -ADD VIBRA-TITE VC-3 TO THREADS AND SET TORQUE TO 40 FT.-LBS.
 - 3 -ADD VIBRA-TITE VC-3 TO THREADS AND SET TORQUE TO 10 FT.-LBS.
 - 4 -ADD VIBRA-TITE VC-3 TO THREADS AND SET TORQUE TO 30 FT.-LBS.

PROPRIETARY AND CONFIDENTIAL
 INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF LIFTMOORE INC.
 REPRODUCTION IN ANY MANNER WITHOUT THE WRITTEN PERMISSION OF LIFTMOORE INC. IS PROHIBITED.

MACH. PART TO BE A MINIMUM 250 RMS UNLESS SPECIFIED
 DEFAULT TOLERANCES UNLESS SPECIFIED:
 .XX ± .030
 .X ± .100
 XX ± .1/16
 XX ± .5


CHECKED: JE DATE: 04/14/2021
 ENG APPR: DP DATE: 04/14/2021

BY: NA DATE: 04/14/2021 REV: A

LIFTMOORE INC.
BOOM, INNER ASSY 72100XP-30
 WEAR PADS, EXT. CYL. SPACERS

DRAWN: NA DATE: 04/14/2021
 MTRL: SHEET 1 - 2
 WEIGHT: 1123.229 Lbs.

REV: 29737
 A



PROPRIETARY AND CONFIDENTIAL
 INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF LIFTMOORE INC. REPRODUCTION IN WHOLE OR IN PART OR AS A GUIDE FOR THE FABRICATION OF ANY PART IS PROHIBITED.


MACH. PART TO BE A MINIMUM 250 RMS UNLESS SPECIFIED OTHERWISE.
 DEFAULT TOLERANCES UNLESS SPECIFIED:
 .XX ± .005
 .X ± .030
 .X ± .100
 XX ± .1/16
 XX ± .5

CHECKED: JE 04/14/2021
 ENG APPR: DP 04/14/2021

LIFTMOORE INC.
BOOM, INNER ASSY 72100DXP-30
 WEAR PADS, EXT. CYL.SPACERS

DRAWN: NA 04/14/2021 DWG. NO. 29737
 MTRL: SHEET 2 - 2
 WEIGHT: 1123.229 Lbs


REV A



Pos	Code	Q.ty	Description
1	425026100	1	Engine
2	02981085	1	Brake unit
3	415002200	1	Oil retainer seal
24	410001900	2	Hex socketed head cap screw
25	438041600	1	Valve
26	440000100	2	90° Connection (Conical)
27	02671089	1	Brake pipe
28	410403000	8	Hex socketed head cap screw
29	029911207	1	Side flange (motor side)
30	023410272	1	Motor side support
31	024510174	2	Fastening surface plate
32	400002600	1	Ball bearing
33	421102100	1	Retaining ring
34	419000700	1	Plug
35	423000600	1	Copper washer

LIFTMOORE CRANES	Winch	Variant	Machine	A55 EZ5 OWC DOPPIA
		Machine	Machine	9205003401

1/1



Pos	Code	Q.ty	Description
6	99102500	1	Reduction gear unit (RE 110)
7	99143000	1	Reduction gear unit
8	421104000	1	Seeger
9	02741008	1	Insert
10	410101200	2	Hex socket countersunk head
11	241002000	1	Thimble
12	024510175	2	Cross member
13	410201100	16	Hexagon screw
14	421101700	1	Seeger
15	415006900	1	Oil retainer seal
16	400022100	1	Ball bearing
17	02371015	1	Antirotation flange
18	410022600	8	Hex socketed head cap screw
19	023410273	1	Gear side support
20	410407000	4	Hex socketed head cap screw
21	029912241	1	Side flange (gear side)
22	410409500	8	Hex socketed head cap screw
23	434014700	2	Spring pin
37	02611366	1	Sun gear
38	02611070	1	Sun gear
39	023010141	1	Winch drum
40	406023600	2	O-ring joint
42	427006200	2	Shim ring

Brake unit


Variant

Machine

A55 EZ5 OWC DOPPIA



1/1

9205003401



Pos	Code	Q.ty	Description
1	406001100	1	O-ring joint
2	406001200	2	O-ring joint
3	02271007	1	Piston
4	02461087	1	Flange
5	415061900	1	Seal
6	400003900	1	Ball bearing
7	02241087	1	Gear
8	416201400	2	Belleville washer
9	415021200	1	Shoulder ring
10	406016700	1	O-ring joint
11	415067500	1	Antiextrusion ring
12	410403800	8	Hex socketed head cap screw
13	02431013	1	Brake body
14	406015900	1	O-ring joint
15	415069000	1	Antiextrusion ring
16	02941016	7	Disc
17	02941017	6	Disc
18	406005800	1	O-ring joint
19	02741005	1	Insert
20	421100400	1	Seeger
21	427004900	1	Shim ring
22	400003000	1	Ball bearing
23	02331058	1	Supporting flange

ITEM NO.	PART NUMBER	DESCRIPTION	QTY
1	3309	SEAL, OIL #19831	1
2	AT14553P	OUTPUT PINION	1
3	AT3263	SEAL, OIL #12355PTC	1
4	AT3651	SNAP RING, INT SHR175STPA	1
5	AT4301LA-2	HOUSING	1
6	AT4306A-1	CAP, GEAR	1
7	AT4309	CAP, WORM	1
8	AT4327-2	SPACER, GEAR	1
9	AT4332-1SBP	SHIM, GEAR CAP .010 BROWN	1
9	AT4332-1SHP	SHIM, GEAR CAP .0075 NATURAL	1
9	AT4332-1SMP	SHIM, GEAR CAP .005 BLUE	1
9	AT4332-1SYP	SHIM, GEAR CAP .003 GREEN	1
10	AT4345G	GEAR, WORM 45:1	1
11	AT4345X6	WORM 45:1	1
12	AT4354	O-RING, PARKER 2-043	1
13	AT4354-2	O-RING, PARKER 2-165	1
14	AT4542SHP	SHIM, WORM .0075 NATURAL	1
14	AT4542SMP	SHIM, WORM .005 BLUE	1
14	AT4542SYP	SHIM, WORM .003 GREEN	1
15	AT4552C & AT4552R	BRG, ROLLER CUP NP761714 & CONE NP535811	2
16	HCA3223F	3/8-16 X 1 1/8" HHCS GRD 5	10
17	MA00149	MOTOR, HYD 4.7 CIPR	1
18	PT8061C & PT8061R	BRG, ROLLER CUP-LM104911 & CONE-LM104949	1
19	SB1889	VENT, PRESSURE 1-5 PSIG	1
20	SB2671A	1/4-18 NPT HEX SOC PLUG	2
21	SB4546	1/2" SPLIT LOCKWASHER	2
22	SB4563	OIL SEAL C/R 16084	1
23	SB4567	BUSHING, RED 1/8 X 1/4	1
24	SB4599A	GREASE FITTING 1/8 NPT 45°	1
25	SC4523ES	1/2-13 X 1 1/4" SHCS SS	2
26	SCL4523B	1/2-13 X 1" LSHCS	4
27	SH2161C & SH2161R	BRG, ROLLER CUP LM102910 & CONE LM102949	1
28	WT4356H-1	MOTOR ADAPTER	1



UNLESS OTHERWISE SPECIFIED, ALL DETAILS MUST BE FREE OF BURRS AND SHARP EDGES, WHICH MAY BE DETRIMENTAL TO SATISFACTORY ASSEMBLY, SAFE HANDLING, OR FUNCTION.

PART NO.
AT19549S
MATERIAL NO.

MATERIAL TYPE
SPEC.

HEAT TREAT

UNLESS OTHERWISE SPECIFIED DIMS ARE IN INCHES
TOL ON ANGLE $\pm .5^\circ$
1 PL $\pm .050$ 2 PL $\pm .010$ 3 PL $\pm .005$
SURFACE FINISH TO BE 125 μ IN
INTERPRET DIM AND TOL PER
ASME Y14.5M - 1994

THIRD ANGLE PROJECTION

DRAWN BY:
CHKD. BY:

DRAWN BY DATE:
10-29-19
CHKD. BY DATE:

SCALE
1:4


WEIGHT: 85.31 LBS

REV
B

UNIT
REF LIFTMOORE #29116

NAME
PARTS PAGE

STAMP
LIFTMOORE CRANES



<p>LIFTMOORE CRANES</p>		<p>NAME EXPLODED VIEW</p>
<p>DRAWN BY: 10-29-19</p>	<p>CHKD. BY:</p>	<p>UNLESS OTHERWISE SPECIFIED DIMS ARE IN INCHES TOL ON ANGLE $\pm 5^\circ$ 1 PL $\pm .050$ 2 PL $\pm .010$ 3 PL $\pm .005$ SURFACE FINISH TO BE 125 μIN INTERPRET DIM AND TOL PER ASME Y14.5M - 1994</p>
<p>PART NO. AT19549S</p>	<p>MATERIAL NO.</p>	<p>THIRD ANGLE PROJECTION</p>
<p>MATERIAL TYPE</p>	<p>SPEC.</p>	<p>HEAT TREAT</p>
<p>UNLESS OTHERWISE SPECIFIED, ALL DETAILS MUST BE FREE OF BURRS AND SHARP EDGES, WHICH MAY BE DETRIMENTAL TO SATISFACTORY ASSEMBLY, SAFE HANDLING, OR FUNCTION.</p>		<p>UNIT REF LIFTMOORE #29116</p>
<p>SCALE 1:5</p>	<p>WEIGHT: 85.31 LBS</p>	<p>REV B</p>
<p>Sheet 2 of 2</p>		<p>SIZE B</p>

CIRCUIT NUMBER AND DESCRIPTION				
Color	Length	Connectors		Function
RED	30"	P12B.1	P2-R.1	ROT CW
RED/BLK	26"	P12B.2	P2-RA.1	ROT CCW
GRN	28"	P12B.5	P2-L.1	BOOM UP
ORN	24"	P12B.6	P2-LA.1	BOOM DWN
GRN/BLK	22"	P12B.3	P2-X.1	EXT OUT
ORN/BLK	26"	P12B.4	P2-XA.1	EXT IN
BLU	24"	P12B.7	P2-HA.1	HOIST UP
BLK	20"	P12B.8	P2-H.1	HOIST DWN
WHT	15"	P12B.12	P2-U.2	UP LIMIT SWITCH
RED	14"	P12D.8	P2-U.1	UP LIMIT SW. 12V
WHT/BLK	23"	P12A.10	P2-P.1	PROP
WHT	13"	P12A.2	P4-CH.1	CAN HI MAIN
GRN	13"	P12A.3	P4-CL.1	CAN LOW MAIN
YEL/BLK	13"	P12A.7	P2-ATB.2	ATB
RED	15"	P12A.12	P12D.2	REC. PWR 12V
RED	12"	P12D.3	P2-ATB.1	PWR, ATB 12V
RED	11"	P12D.4	P4-J.1	PWR, CAN 12V
GRN	9"	P4-CL.2	P4-J.3	CAN LOW
WHT	9"	P4-CH.2	P4-J.4	CAN HI
YEL	N/A	P12D.1	MAIN PWR	FUSE HOLDER
BLK	8"	P12A.11	BLU/FEM	HORN 12V
MAIN GROUND TERMINAL				
BRN	7"	P12C.1	TR-1	MAIN GROUND
BRN	13"	P12C.2	P12A.1	RECEIVER GROUND
BRN	23"	P12C.3	P2-RA.2	ROT CCW VALVE GND
BRN	27"	P12C.4	P2-R.2	ROT CW VALVE GND
BRN	25"	P12C.5	P2-L.2	ELEV UP VALVE GND
BRN	21"	P12C.6	P2-LA.2	ELEV DWN VALVE GND
BRN	19"	P12C.7	P2-X.2	EXT OUT VALVE GND
BRN	23"	P12C.8	P2-XA.2	EXT IN VALVE GND
BRN	17"	P12C.9	P2-H.2	WINCH DN VALVE GND
BRN	21"	P12C.10	P2-HA.2	WINCH UP VALVE GND
BRN	20"	P12C.11	P2-P2	PROP. VALVE GND
BRN	9"	P12C.12	P4-J.2	CAN GND
P6-GND GROUND TERMINAL				
BRN	7"	P6-GND.1	TR-1	MAIN GROUND
BRN	23"	P6-GND.5	BF-2	HORN GND

LIFTMOORE, INC

Houston TX
(713)-688-5533

EWH, DTCH HYD XP 60100/72100 WP

TRANSDUCER, INCLINOMETER

29515-0

TYPICAL TOLERANCES

MACHINE ±.005
PLASMA ± 1/32
WELD ± 1/16


CAD DRAWING
DO NOT SCALE

DRAWING NO. 3/31/21
DATE: 3/31/21
MATRL:
DRWN BY: JE
CHK'D BY:





PRE-BUILD

REPORT ERRORS OR CHANGES TO
ENGINEERING IMMEDIATELY

DESCRIPTION BY DATE REV.



<p>PRE-BUILD</p> <p>REPORT ERRORS OR CHANGES TO ENGINEERING IMMEDIATELY</p>		<p>LIFTMOORE, INC Houston TX (713)-688-5533</p>		
		<p>EWB, DTCH HYD XP 60100/72100 WP TRANSDUCER, INCLINOMETER</p>		
<p>TYPICAL TOLERANCES</p> <p>MACHINE ± .005 PLASMA ± 1/32 WELD ± 1/16</p>	<p>CAD DRAWING</p>	<p>DRWN BY: JE</p>	<p>DATE: 3/31/21</p>	<p>DRAWING NO.</p>
	<p>DO NOT SCALE</p>	<p>CHK'D BY:</p>	<p>MATRL:</p>	<p>29515-0</p>



LIFTMOORE, INC Houston TX (713)-688-5533		29515-0	
		DRAWING NO.	DATE: 3/31/21
EWB, DTCH HYD XP 60100/72100 WP TRANSDUCER, INCLINOMETER		DRWN BY: JE	CHK'D BY:
		CAD DRAWING DO NOT SCALE	MTRL:


DESCRIPTION	BY	DATE	REV.

***ELEVATION**

ROTATION

***EXTENSION**

WINCH




SV = PROPORTIONAL VALVE
 LC = LOGIC VALVE
 RV = RELIEF VALVE
 D03 = OPEN CENTER VALVES

*NOTE: CYLINDER COUNTER BALANCE VALVE & PO CHECK VALVE ARE INTERNAL IN THE CYLINDER.

LIFTMOORE, INC Houston TX (713)-688-5333	
HYD. SCHEM. - PROP. CONTROL CRANES 72100 CRANES, DYNAMIC OIL WINCH, CASE DRAIN WINCH	DRAWING NO. 50940-0
TYPICAL TOLERANCES MACHINE ±.005 PLASMA ± 1/32 WELD ± 1/16	DRWN BY: JE DATE: 2/9/21
CAD DRAWING DO NOT SCALE	CHK'D BY: MATRL.

DESCRIPTION	BY	DATE	REV.

ITEM NO.	PART NUMBER	PART DESC	QTY.
1	29148	PLATE, SIDE TRAV BLK 72100 MC	2
2	22621	SHEAVE ASSY. 8.31PD X 0.43 ROPE	1
3	22523	SPACER, TRAV BLK 1X0.39X1.625MC	2
4	22761	SCREW, HHC 0.37-16 X 3.75 GR8	2
5	30834	NUT, HEX NYLOC 0.37-16 GRADE 2	2
6	22578	SPACER, TRAV BLK 1X1.5X1.625	1
7	21322	SCREW, SHEAVE SINGLE 1-8 4.62	1
8	30838	NUT, HEX NYLOC 1.00-8 GRADE 5	1
9	32658	PIN, CLEVIS 0.87 X 3.50 PLATED	1
10	31948	CLIP, HAIRPIN 0.187 - 1.00	1
11	30759	HOOK, SWIVEL 6 TON W/LATCH	1
12	19769	DECAL, TRAVEL BLOCK 10,000 LBS	2
13	22818	DECAL, BLOCK & HOOK WT. 75 LBS	1



CAUTION:
 NEVER USE A HOOK WHEN THROAT OPENING HAS BEEN INCREASED.
 ALSO INCLUDES, WHEN BENT MORE THAN 10 DEGREES OUT OF PLANE
 FROM THE HOOK BODY, OR IS DISTORTED.

PROPRIETARY AND
 CONFIDENTIAL
 INFORMATION
 CONTAINED IN THIS
 DRAWING IS THE
 SOLE PROPERTY OF
 LIFTMOORE INC.
 REPRODUCTION IN
 WHOLE OR AS A
 PART OF ANY
 INSTRUMENTATION
 WITHOUT THE WRITTEN
 PERMISSION OF
 LIFTMOORE INC. IS
 PROHIBITED.

MACH. PART TO BE A MINIMUM
 250 RMS UNLESS SPECIFIED
 DEFAULT TOLERANCES
 UNLESS SPECIFIED:
 XX ± .030
 XX ± .030
 XX ± .100
 XX ± .5"

FRAC: 1/16
 XX: .5"



CHECKED: JE 05/07/2021
 ENG APPR: DP 05/07/2021

LIFTMOORE INC.

BLOCK, TRAV ASSY 10K lbs/9.0D

8.31PD X 0.43 ROPE: 10,000LBS

DRAWN: NA	05/07/2021	REV: A
MTRL: SHEET 1 - 1		
WEIGHT: 75.506 Lbs	29145	



A : THROAT OPENING DIMENSION= 1.88"
 P/N ML-M291804005
 LATCH, SAFETY 5 TON HOOK KIT

PROPRIETARY AND
 CONFIDENTIAL
 INFORMATION
 CONTAINED IN THIS
 DRAWING IS THE
 SOLE PROPERTY OF
 LIFTMOORE INC.
 REPRODUCTION IN
 WHOLE OR AS A
 PART OF ANY
 INFORMATION
 SYSTEM WITHOUT
 THE WRITTEN
 PERMISSION OF
 LIFTMOORE INC. IS
 EXPRESSLY
 PROHIBITED.

MACH. PART TO BE A MINIMUM
 250 RMS UNLESS SPECIFIED
 DEFAULT TOLERANCES
 UNLESS SPECIFIED:
 XX ± .05
 XX ± .030
 XX ± .100
 FRAC. ± 1/16
 XX ± .5"
 CHECKED JE 05/07/2021
 ENG APPR. DP 05/07/2021

LIFTMOORE INC.
 BLOCK, TRAV ASSY 10K lbs/9.0D
 8.31PD X 0.43 ROPE: 10,000LBS

DRAWN: N/A 05/07/2021
 MTRL: SHEET 2 - 2
 WEIGHT: 75.806 Lbs
 REV A
 29145

THIS DRAWING INTENTIONALLY LEFT BLANK

FOR FUTURE ADDITIONS
OR

A PART OR FEATURE IS NOT APPLICABLE TO THIS CRANE



Houston TX
(713)-688-5533
www.liftmoore.com

DRWN BY:

DATE:

DRAWING NO.

LIFTMOORE LIMITED WARRANTY

Parts and Structural

Liftmoore, Inc. warrants each LIFTMOORE crane to be free from defects in materials and workmanship for twelve (12) months from the date of delivery to the original customer. Under the terms of this warranty the crane structural components manufactured by LIFTMOORE, Inc. are warranted for thirty-six (36) months from the date of delivery to the original customer. LIFTMOORE, Inc. will repair or replace, as its sole discretion, any equipment or part that is returned f.o.b. to LIFTMOORE, Inc.'s plant at 7810 Pinemont Drive, Houston, Texas 77040, or to one of its authorized dealers, and is found by LIFTMOORE, Inc. or its authorized dealer to have been defective at the time of original delivery.

The foregoing warranty is the exclusive warranty made by LIFTMOORE, Inc. with respect to its cranes and is in lieu of all other warranties. ANY AND ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS OF ANY CRANE FOR A PARTICULAR PURPOSE OR OPERATION, ARE HERBY EXPRESSLY DISCLAIMED.

The foregoing warranty applies only to LIFTMOORE cranes under normal use and service and does not apply in the event of damage caused by repair or alteration or damage during shipment, accident, negligence, overloading, or misuse, including operator's failure to follow any of the instructions issued with the crane.

This warranty is limited to the original purchaser and is not assignable. In order to submit a claim, the original purchaser must provide a copy of the original invoice for the crane in question within twelve (12) months following the delivery date and within 30 days from the date of repair.

The warranty applies only when the LIFTMOORE crane is used for commercial purposes and does not cover any purchase for use for personal, family or household purposes.

LIMITATION OF LIABILITY: LIFTMOORE, Inc.'s liability for any losses or damages resulting from any cause whatsoever, including LIFTMOORE, Inc.'s NEGLIGENCE or from a defective crane irrespective of whether such defects are discoverable or latent, shall in no event exceed the purchase price of the crane to which losses or damages are claimed, or at the election of LIFTMOORE, Inc., the repair or replacement of the defective crane.

In no event shall LIFTMOORE, Inc. be liable for any special, incidental, or consequential damages, including commercial losses or costs of any kind sustained by purchaser or any other person or for any damages for which purchaser may be liable to other persons by reason of any defect in any LIFTMOORE crane or any part thereof.

LIFTMOORE, Inc. reserves the right to make changes in design or construction of its cranes at any time without obligating itself to make such changes on cranes previously manufactured.

No agent, employee, or representative of LIFTMOORE, Inc. has authority to amend or modify the foregoing warranty or to bind LIFTMOORE, Inc. by any other warranty, guaranty, or assumption of liability.

In the event any provision of this warranty is for any reason held ineffective, the remaining provisions shall remain in full force and effect.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other legal rights that vary from state to state.

